

NOTE: DOD-STD-2003-5 has been redesignated as a standard practice. The cover page has been changed for Administrative reasons. There are no other changes to this Document.

INCH - POUND

DOD-STD-2003-5(SH)
24 June 1987
SUPERSEDING
NAVSEA S9300-AW-EDG-010/EPISM
(INCLUDING NAVSEA DWG. NO.
803-5001027) AND NAVSEC NO.
9000-S6202-73980

DEPARTMENT OF DEFENSE
STANDARD PRACTICE

ELECTRIC PLANT INSTALLATION
STANDARD METHODS FOR
SURFACE SHIPS AND SUBMARINES
(CONNECTORS)

SECTION 5 OF 5 SECTIONS



AMSC N/A

AREA GDRQ

DISTRIBUTION STATEMENT B. Distribution limited to U.S. Government agencies only for administrative and operational use. Other requests for this directive must be referred to NAVSEA (SEA 05Q).

DOD-STD-2003-5(NAVY)
24 June 1987

SECTION 5

CONNECTORS

DEPARTMENT OF THE NAVY
NAVAL SEA SYSTEMS COMMAND

Washington, DC 20362-5101

Electric Plant Installation Standard Methods For Surface Ships and Submarines

1. This Military Standard is approved for use by the Naval Sea Systems Command, Department of the Navy, and is available for use by all Departments and Agencies of the Department of Defense.
2. Beneficial comments (recommendations, additions, deletions) and any pertinent data which may be of use in improving this document should be addressed to: Commander, Naval Sea Systems Command, SEA 5523, Department of the Navy, Washington, DC 20362-5101 by using the self-addressed Standardization Document Improvement Proposal (DD Form 1426) appearing at the end of this document or by letter.

DOD-STD-2003-5(NAVY)
24 June 1987

FOREWORD

1. The criteria contained herein for the installation of the electrical plant on ships of the United States Navy supersede the data contained in Sections 1 through 5 of NAVSHIPS Drawing 9000-S6202-73980, NAVSEA Drawing No. 803-5001027 and NAVSEA PUBLICATION S9300-AW-EDG-010/EPISM.
2. This standard disseminates up-to-date information detailing Requirements for Standard Installation Methods Employed for Submarine and Surface Ship Electrical Distribution Systems.
3. These criteria apply to work on a specific ship or ships only when invoked by the Ship Specifications or similar contractual documents.
4. Although these criteria are primarily for application to new construction, their use may be considered in the conversion or alteration of existing ships. In such cases the degree of applicability of these criteria will be specified by the activity preparing the instructions for the work.
5. Considering the magnitude of this standard, along with the changing requirements imposed on the Electric Plant, it is inevitable that changes will be required to up-date these criteria. Therefore, as comments arise they should be forwarded to Naval Sea Systems Command (NAVSEA) 55Z3 to keep this standard as current as possible through subsequent revisions. Revisions will be accomplished by the issuance of additional or revised figures to be inserted in the basic standard sections. Document Improvement Proposal Form DD 1426 attached. Super-seeded pages may be retained for reference if so desired.
6. This standard is available in a 8-1/2 X 11 hard copy, in microfilm aperture cards, or in microfiche. It is available in 8-1/2 X 11 hard copy from Commanding Officer, Naval Publications and Forms Center, 5801 Tabor Avenue, Philadelphia, PA 19120. Microfilm aperture card or microfiche are available from Commanding Officer, Portsmouth Naval Shipyard, Code 202.2, Portsmouth, NH 03801. All revisions on microfilm aperture cards, or on microfiche are automatically distributed to a previously approved distribution list. (Tel: (207) 439-1000, Ext. 1718, Autovon 684-1718). Activities having a requirement to be placed on the distribution or for additional copies should forward these requests to Commander, Naval Sea Systems Command, SEA 55Z3, Department of the Navy, Washington, DC 20362-5101. Aperture cards have been distributed to those activities presently on the distribution for NAVSEA Standard and Type Drawing microfilm aperture card sets. Microfiche has been distributed to all active ships.

DOD-STD-2003-5(NAVY)
24 June 1987

CONTENTS

		<u>Page</u>
Paragraph 1.	SCOPE	1
1.1	Purpose	1
1.1.1	Application	1
2.	REFERENCED DOCUMENTS	1
	Not applicable	
3.	DEFINITIONS	1
3.1	Glossary of terms	1
4.	GENERAL REQUIREMENTS	1
4.1	Instruction for use of DOD-STD-2003-5	1
5.	DETAILED REQUIREMENTS	2
	See figures	
6.	NOTES	2
6.1	Intended use	2
6.2	Designation of electric plant installation standard methods figures	2
6.3	Subject term (key word) listing	2
Group A - Cable Lead Preparation		
Figure 5A1	Cable preparation	3
5A2	Cable preparation	4
5A3	Cable diameter build-up procedures	5
5A4	Cable diameter build-up procedures	6
5A5	Individual lead stripping techniques	7
5A6	Individual lead stripping techniques	8
5A7	Individual lead stripping techniques	9
5A8	Individual lead stripping techniques	10
5A9	Individual lead stripping techniques	11
5A10	Individual lead stripping techniques	12
5A11	Connector contact crimping techniques	13
5A12	Connector contact crimping techniques	14
5A13	Tinning techniques	15
5A14	Tinning techniques	16
5A15	Connector contact soldering techniques	17
5A16	Connector contact soldering techniques	18
5A17	Connector contact soldering techniques	19
5A18	Connector contact soldering techniques	20
5A19	Conductor shield termination procedures	21
5A20	Connector shield termination procedures	22
5A21	Conductor shield termination procedures	23
5A22	Gross shield termination procedures	24
5A23	Gross shield termination procedures	25

DOD-STD-2003-5(NAVY)

24 June 1987

CONTENTS - Continued

Group A - Cable Lead Preparation (Continued)

		<u>Page</u>
Figure	5A24 Connector lockwiring	26
	5A25 Cable transflexing procedure	27
	5A26 Cable transflexing procedure	28
	5A27 Cable bifurcation procedure	29
	5A28 Cable bifurcation procedure	30
	5A29 Glossary of terms	31
	5A30 Glossary of terms	32
	5A31 Tooling and materials list	33
	5A32 Connector part number nomenclature	34
	5A33 Connector part number nomenclature	35
	5A34 Connector part number nomenclature	36
	5A35 Connector part number nomenclature	37
	5A36 Connector part number nomenclature	38

Group B - MIL-C-81511 Connectors

5B1	MIL-C-81511 series 1 and 2 gang contact release connector assembly procedure	39
5B2	MIL-C-81511 series 1 and 2 gang contact release connector assembly procedure	40
5B3	MIL-C-81511 series 1 and 2 gang contact release connector assembly procedure	41
5B4	MIL-C-81511 series 1 and 2 gang contact release connector assembly procedure	42
5B5	MIL-C-81511 series 1 and 2 gang contact release connector assembly procedure	43
5B6	MIL-C-81511 series 3 and 4 individual contact release connector assembly procedure	44
5B7	MIL-C-81511 series 3 and 4 individual contact release connector assembly procedure	45
5B8	MIL-C-81511 series 3 and 4 individual contact release connector assembly procedure	46
5B9	MIL-C-81511 series 3 and 4 individual contact release connector assembly procedure	47

Group C - MIL-C-5015 Connectors

5C1	MIL-C-5015 solder connector assembly procedure	48
5C2	MIL-C-5015 solder connector assembly procedure	49
5C3	MIL-C-5015 (crimp) connector assembly procedure	50
5C4	MIL-C-5015 (crimp) connector assembly procedure	51
5C5	MIL-C-5015 (crimp) connector assembly procedure	52
5C6	MIL-C-5015 (crimp) connector assembly procedure	53
5C7	MIL-C-5015 (crimp) connector assembly procedure	54
5C8	MIL-C-5015 (crimp) connector assembly procedure	55

DOD-STD-2003-5(NAVY)
24 June 1987

CONTENTS - Continued

Group D - MIL-C-26482 Connectors

		<u>Page</u>
Figure	5D1 MIL-C-26482 connector assembly procedure	56
	5D2 MIL-C-26482 connector assembly procedure	57
	5D3 MIL-C-26482 connector assembly procedure	58
	5D4 MIL-C-26482 connector assembly procedure	59
	5D5 MIL-C-26482 connector assembly procedure	60

Group E - MIL-C-28840 Connectors

5E1	MIL-C-28840 connector assembly procedure	61
5E2	MIL-C-28840 connector assembly procedure	62
5E3	MIL-C-28840 connector assembly procedure	63
5E4	MIL-C-28840 connector assembly procedure	64

Group F - MIL-C-27599 Connectors

5F1	MIL-C-27599 connector assembly procedure	65
5F2	MIL-C-27599 connector assembly procedure	66
5F3	MIL-C-27599 connector assembly procedure	67

Group G - MIL-C-22992 Connectors

5G1	MIL-C-22992 connector assembly procedure (excluding class L)	68
5G2	MIL-C-22992 connector assembly procedure (excluding class L)	69

Group H - MIL-C-38999 Connectors

5H1	MIL-C-38999 connector assembly procedure	70
5H2	MIL-C-38999 connector assembly procedure	71
5H3	MIL-C-38999 connector assembly procedure	72
5H4	MIL-C-38999 connector assembly procedure	73

DOD-STD-2003-5(NAVY)
24 June 1987

1. SCOPE

1.1 Purpose. The purpose of DOD-STD-2003-5 is to disseminate up-to-date information for connector fabrication on surface ships and submarines.

1.1.1 Application. These installation standards shall be used by all installing activities. These standards do not identify ship or type, but do establish minimum standards of acceptance for NAVSEA ships. It is the responsibility of the user activity to determine which standard satisfies their requirements. It does not authorize relaxation of any requirement specifically invoked by new construction, conversion, overhaul, or refurbishment contracts. In instances where deviated design requirements (for example, ship type, ship class, and so forth) conflict with the requirements of this standard, the requirements of this standard shall govern. Any deviation for electric plant installation identified in this standard shall be submitted to NAVSEA 56Z2 for resolution.

2. REFERENCED DOCUMENTS

Not applicable.

3. DEFINITIONS

3.1 Glossary of terms. Refer to figures 5A29 and 5A30.

4. GENERAL REQUIREMENTS

4.1 Instruction for use of DOD-STD-2003-5. This standard is designed to be utilized by a connector assembly technician and is formatted to be utilized as follows:

- (a) Determine the governing Military specification for the connector being assembled.
- (b) Proceed to the applicable Connector Assembly Procedure (figure 5B1, 5C1, and so forth) and review to determine tools and materials required. Each group is designed to assemble a connector starting with the basic components and proceeding in a step-by-step manner to the completed assembly.
- (c) Instruction shown on figures 5A1 through 5A35 identify a sequence of processes common to any connector assembly (that is, lead stripping, crimping, soldering, and so forth). The conduct of these procedures will be sequenced by the Connector Assembly Procedures. The technician should review these procedures to familiarize himself with their content.
- (d) Terminate the connector/backshell to the cable utilizing the appropriate Connector Assembly Procedure.

These procedures are designed for use with Military specification connectors and backshells. Commercial substitutions may result in deviations from these procedures. Manufacturer assembly instructions should be consulted in these cases. Equivalent tooling and materials may be substituted provided the intent of the required specification is achieved.

DOD-STD-2003-5(NAVY)
24 June 1987

5. DETAILED REQUIREMENTS

See figures.


6. NOTES

6.1 Intended use. This standard specifies the requirements for Standard Methods to be employed both on surface ships and submarines. Standard Methods identified for electric plant installation are intended for new construction only.

6.2 Designation of Electric Plant Installation Standard Methods drawings (figures). The Electric Plant Installation Standard Methods (DOD-STD-2003-5) contains drawings that depict Standard Methods that are applicable for general electric plant installation on both surface ships and submarines. Each drawing has been assigned a figure number. The methods shown on the figures are grouped together providing similar functions. These groups are:

- DOD-STD-2003-5 (Connectors) Group
- A. Cable Lead Preparation
 - B. MIL-C-81511 Connectors
 - C. MIL-C-5015 Connectors
 - D. MIL-C-26482 Connectors
 - E. MIL-C-28840 Connectors
 - F. MIL-C-17599 Connectors
 - G. MIL-C-22992 Connectors
 - H. MIL-C-38999 Connectors

The methods shown on the figures are identified by the following alphanumeric designation system:



Thus, method 5A142 identifies method 2, sequential number 14 in group A of DOD-STD-2003-5.

6.3 Subject term (key word) listing.

Cable lead preparation
Connectors

Preparing activity:
Navy - SH
(Project GDRQ-N066-5)

1. ENSURE THE CABLE IS THE CORRECT TYPE AS SPECIFIED ON THE APPLICABLE CABLING DIAGRAM
 - 1.1 ENSURE THAT THE MINIMUM ACCEPTANCE REQUIREMENTS OF THE APPLICABLE MIL-C-915 OR MIL-C-177 SPECIFICATIONS ARE MET AND VERIFIED BY CHECKING THE SPECIFICATION PAPERWORK FOR INSPECTION ACCEPTANCE STAMP IF NO STAMP EXISTS OR PAPERWORK IS MISSING. DO NOT USE THE CABLE.
 2. MEASURE THE CABLE TO THE REQUIRED LENGTH
 - 2.1 WHEN THE CONNECTOR IS PRE-FABRICATED IN THE SHOP, ADD 5 FEET OR 5% (WHICHEVER IS GREATER).
 - 2.2 WHEN MEASURING THE CABLE TO TERMINATE AT EQUIPMENT ON BOARD, ENSURE THAT SUFFICIENT LENGTH EXISTS TO ALLOW FOR AT LEAST ONE, BUT WHERE PRACTICAL, THREE DETERMINATIONS OF THE CABLE BEND RADIUS. THE REQUIRED CABLE BEND RADIUS IS MAINTAINED.
 3. VISUALLY INSPECT THE CABLE JACKET FOR DEFORMITIES, CUTS, OR PUNCTURES.
 4. WIPE THE CABLE JACKET OR ARMOR WITH AN APPROVED SOLVENT FROM TABLE 1 IN ORDER TO REMOVE GREASE, OIL DIRT, AND OTHER DEBRIS IN THE AREA WHERE THE CONNECTOR AND BACKSHELL WILL BE INSTALLED.

TABLE 1

1. 1. TRICHLOROETHANE	G-T-620
TRICHLOROFLUOROETHANE	MIL-C-81302
ISOPROPYL ALCOHOL	TT-1-735
PERCHLOROETHYLENE	O-T-236
1. 1. TRICHLOROETHANE (VAPOR DEGREASING)	MIL-T-81533
REAGENT WATER (TYPE II)	ASTM D-1193
DETERGENT CLEANERS	AS APPROVED BY THE GOVERNMENT AGENCIES PURSUING ACTIVITY

5. CUT THE CABLE PERPENDICULAR TO THE CABLE AXIS UTILIZING CABLE SHEARS (H K PORTER CO 6990FS OR EQUIVALENT) (FIGURE 1) ENSURE A CLEAN SHARP CUT. ALL CONDUCTORS THE SAME LENGTH AND NO DAMAGE TO THE CABLE.



FIGURE 1
CABLE SHEARS

6. VERIFY CABLE DIAMETER IS COMPATIBLE WITH CABLE CLAMP SIZE
 - 6.1 PLACE THE CLAMP ASSEMBLY OVER THE OUTER MOST CABLE COVERING AND TIGHTEN THE CLAMP SADDLES TO THE VALUES SHOWN IN TABLE 2. CHECKING THE VALUE OF THE CLAMP SADDLES TO THE ARMOR OR P/C. MAINTAINING A MINIMUM GAP OF 1/16 INCH BETWEEN CLAMP SADDLES AND SUP. CONT. (SEE FIGURE 3) IF SATISFACTORY CLAMPING PER FIGURE 5A1.

TABLE 2. CLAMP SCREW TORQUE VALUES

CABLE DIAMETER	TORQUE VALUE
0.0 TO 0.50 IN	25 ± 2 IN / OZS
0.50 IN TO 1.0 IN	40 ± 2 IN / OZS
1.0 IN TO 2.0 IN	50 ± 2 IN / OZS

NOTE: THESE TORQUE SPECIFICATIONS MUST BE MAINTAINED THROUGHOUT THE LIFE OF THE CLAMP. SUPPORT AND THE CLAMP SADDLES.




FIGURE 3

7. ARMOR PREPARATION
 - 7.1 BACKSHELL WITHOUT ARMOR CINCING RFI FERRULES (PCS 6 AND 7)
 - 7.1.1 MEASURE THE LENGTH OF THE ASSEMBLED BACKSHELL (PCS 2 THROUGH 9) FROM THE CONNECTOR END TO THE FRONT END OF THE CLAMP SADDLE (PC 9) (SEE FIGURE 2).
 - 7.1.2 ADD 2 INCHES AND MARK THIS DIMENSION ON THE CABLE ARMOR AT THIS MARK USING THE CABLE STRIPPER (TYPE 1) WHICH MEETS THE REQUIREMENTS OF FED. SPEC GGG-S-665 (SEE FIGURE 4). DIAGONAL CUTTING PLIERS ALSO BE USED TO REMOVE THE ARMOR.

NOTE: FOR ARMORED CABLE, PREPARE THE CABLE USING STEPS 7 THROUGH 15 FOR UNARMORED CABLE. PREPARE THE CABLE USING STEPS 8 THROUGH 15.

NOTE ON ANGLED BACKSHELLS: MEASURE THE CENTER RADIUS DIMENSION.

NOTE: THESE TORQUE SPECIFICATIONS MUST BE MAINTAINED THROUGHOUT THE LIFE OF THE CLAMP. SUPPORT AND THE CLAMP SADDLES.

NOTE: THESE TORQUE SPECIFICATIONS MUST BE MAINTAINED THROUGHOUT THE LIFE OF THE CLAMP. SUPPORT AND THE CLAMP SADDLES.


NOTE: THESE TORQUE SPECIFICATIONS MUST BE MAINTAINED THROUGHOUT THE LIFE OF THE CLAMP. SUPPORT AND THE CLAMP SADDLES.

NOTE: THESE TORQUE SPECIFICATIONS MUST BE MAINTAINED THROUGHOUT THE LIFE OF THE CLAMP. SUPPORT AND THE CLAMP SADDLES.

NOTE: THESE TORQUE SPECIFICATIONS MUST BE MAINTAINED THROUGHOUT THE LIFE OF THE CLAMP. SUPPORT AND THE CLAMP SADDLES.

NOTE: THESE TORQUE SPECIFICATIONS MUST BE MAINTAINED THROUGHOUT THE LIFE OF THE CLAMP. SUPPORT AND THE CLAMP SADDLES.

FIGURE 4
CABLE STRIPPER



ADJUSTABLE CUTTING DEPTH




FIGURE 2
TYPICAL CONNECTOR ASSEMBLY

FIGURE 5A1. Cable preparation.

DOD-STD-2003-5 (NAVY)

24 JUNE 1987

NOTES:

1. THIS FIGURE SUPERSEDES SHEET 5A2 OF DWG. #03-5001027.

NOTE: ENSURE THE CUT DOES NOT PENETRATE THE JACKET COMPLETELY (FIGURE 5).

- 9.4.1 SCORE THE CIRCUMFERENCE OF THE JACKET WITH A MULTIPURPOSE CUTTER (OLFA 300 OR EQUIVALENT) AT THE MARK MADE IN STEP 9.3.

- 9.4.2 SCORE THE JACKET PIECE TO BE REMOVED ALONG ITS LENGTH WITH A MULTIPURPOSE CUTTER.

- 9.4.3 REMOVE THE JACKET PIECE UTILIZING NEEDLE NOSE PLIERS.

10. PREPARE GROSS SHIELD IN ACCORDANCE WITH FIGURE 5A22 IF APPLICABLE.

11. CUT BACK AS CLOSE TO THE JACKET AS POSSIBLE AND REMOVE ANY GLASS OR ASBESTOS BELT TAPE, FILLERS, OR CORE USED IN THE CABLE CONSTRUCTION.

12. PREPARE INDIVIDUAL CONDUCTOR SHIELDS IN ACCORDANCE WITH FIGURE 5A19 IF APPLICABLE.

13. INSPECT THE INDIVIDUAL CONDUCTORS TO ENSURE THE INSULATION IS NOT CUT, NICKED, OR SCRAPPED AND THAT NONE OF THE CONDUCTORS ARE CRUSHED.

14. PREPARE TWISTED PAIRS OR TRIADS AS FOLLOWS (IF APPLICABLE):

- 14.1 FOR CABLES IDENTIFIED WITH MIL-C-915 STANDARD IDENTIFICATION CODE, EACH TRIAD OR TWISTED PAIR SHOULD BE IDENTIFIED BY PLACING A 1/4 INCH LENGTH OF PRE-MARKED SHRINK TUBING OVER EACH TRIAD OR PAIR AND SHRINKING IN PLACE.

- 14.2 FOR CABLES IDENTIFIED WITH THE MIL-C-915 TELEPHONE IDENTIFICATION CODE, EACH TWISTED PAIR SHOULD BE IDENTIFIED BY PLACING A 1/8 INCH PIECE OF INSULATING SLEEVING OVER EACH TWISTED PAIR.

NOTE: DO NOT USE ADHESIVE BACKED MARKERS.

- 14.3 THE TUBING SHOULD BE LOCATED CLOSE TO THE CABLE JACKET END AND STAGGERED SO AS TO PREVENT FORMATION OF A BULKY LUMP.

15. IDENTIFY THE INDIVIDUAL LEADS AS FOLLOWS (NOT REQUIRED IF CONDUCTOR SIZE AND BACKSHELL SIZE PREVENTS INSTALLATION):

- 15.1 SLIDE PRE-MARKED ELECTRICAL INSULATING SLEEVING WHICH MEETS THE REQUIREMENTS OF MIL-23053/5, LENGTH AND SIZE TO SUIT OVER EACH CONDUCTOR.

- 15.1.1 THE SLEEVES SHALL BE MARKED WITH THE CONTACT LETTER OR NUMBER OF THE CONTACT POSITION TO WHICH THEY ARE CONNECTED IN ACCORDANCE WITH MIL-M-81531.

- 7.1.3 CENTER A 3/4 TO 1 INCH LENGTH OF APPROPRIATELY SIZED HEAT SHRINK TUBING MEETING THE REQUIREMENTS OF MIL-23053/5 OVER THE ARMOR TERMINATION POINT AND SHRINK IN PLACE USING A HEAT GUN. PRIOR TO TIGHTENING THE SADDLE CLAMPS.

- 7.2 BACKSHELL WITH ARMOR CINCHING FERRULES.

- 7.2.1 MEASURE THE LENGTH OF THE ASSEMBLED BACKSHELL (PCS 2 THROUGH 6) FROM THE CONNECTOR END TO THE INNER ARMOR CLINCHING RFI FERRULE (PC 6). (SEE FIGURE 2).

NOTE: ON ANGLED BACKSHELLS, MEASURE THE CENTER RADIUS DIMENSION.

- 7.2.2 ADD 2 INCHES AND MARK THIS DIMENSION ON THE ARMOR. CUT AND REMOVE THE CABLE ARMOR AT THIS MARK USING A CABLE STRIPPER (TYPE 1) WHICH MEETS THE REQUIREMENTS OF GGG'S 685.

CAUTION: DO NOT DAMAGE THE CABLE JACKET BENEATH THE ARMOR.

8. VERIFY CABLE DIAMETER IS COMPATIBLE WITH GROMMET SIZE FOR ENVIRONMENTAL SEAL.

- 8.1 WIPE THE CABLE JACKET WITH AN APPROVED SOLVENT PROMPTLY IN ORDER TO REMOVE GREASE, OIL, DIRT, AND OTHER DEBRIS.

- 8.2 ASSEMBLE IN CORRECT ORDER AND ORIENTATION THE REQUIRED BACKSHELL HARDWARE TO COMPRESS THE GROMMET TO THE CABLE JACKET.

NOTE: TORQUE SPECIFICATIONS MUST BE OBTAINED WITHOUT BOTTOMING OF ADJOINING ASSEMBLIES.

- 8.3 ATTEMPT TO PUSH BACKSHELL STRAIGHT ALONG CABLE. APPLYING MODERATE PRESSURE TO GROMMET AND BACKSHELL. IF THE GROMMET OR BACKSHELL SEALING CANNOT BE OBTAINED, BUILD UP THE CABLE DIAMETER PER FIGURE 5A4.

- 8.4 REMOVE ALL BACKSHELL COMPONENTS FROM THE CABLE.


9. JACKET PREPARATION FOR ENVIRONMENTAL SEALING.

- 9.1 MEASURE THE LENGTH OF THE ASSEMBLED BACKSHELL FROM THE CONNECTOR END TO THE NEAREST GROMMET END (PC 3, FIGURE 2).

- 9.2 ADD 2 INCHES AND MARK THIS DIMENSION ON THE JACKET.

- 9.3 DISASSEMBLE AND RELOCATE THE BACKSHELL AND CLAMP COMPONENTS ON THE CABLE. VERIFY THAT ALL PARTS ARE INCLUDED AND ARE IN CORRECT ORDER AND ORIENTATION. ASSEMBLE THE BACKSHELL AND LOCATE IT ON THE CABLE SO THAT IT WILL NOT INTERFERE WITH CONNECTOR WIRING.

- 9.4 REMOVE THE CABLE JACKET TO THE PREDETERMINED LENGTH AS FOLLOWS.



SET CUTTING DEPTH TO LESS THAN CABLE JACKET THICKNESS.

SH 132317310

FIGURE 5A2. Cable preparation.

NOTES:
1. THIS FIGURE SUPERSEDES SHEET 5A3 OF DWG. 803-5001027.

4.1.6 CONTINUE APPLYING HEAT SHRINK TUBING UNTIL THE CABLE OUTSIDE DIAMETER IS COMPATIBLE WITH THE CABLE SEALING RANGE OF THE ENVIRONMENTAL GROMMET AND/OR CABLE CLAMP

5. THE FOLLOWING METHOD SHALL BE USED IN CONJUNCTION WITH A MS3420A TELESCOPING BUSHING (FIGURE 2).
NOTE: THE MS3420 WILL NOT BE INSTALLED UNDER THE GROMMET. THE MS3420 ARE ONLY USED TO BUILD UP CABLE DIAMETER UNDER THE CABLE CLAMP.

5.1 MEASURE THE INSTALLED LENGTH OF THE GROMMET. THE GROMMET LENGTH SHOULD BE LESS THAN THE AVAILABLE BUSHING LENGTH. USE HEAT SHRINK TUBING TO BUILD UP CABLE DIAMETER

4.1.3 INSTALL THE HEAT SHRINK TUBING ON THE CABLE IN THE AREA WHERE THE ENVIRONMENTAL SEAL AND CABLE CLAMP WILL BE APPLIED AND SHRINK IN PLACE USING A HEAT GUN.
4.1.4 VERIFY THAT SATISFACTORY ENVIRONMENTAL SEALING IS OBTAINED WITHIN THE TORQUE SPECIFICATION WITHOUT BOTTOMING OF ADJOINING BACKSHELL ASSEMBLIES.
4.1.5 VERIFY THAT THE CLAMP SECURELY HOLDS THE CABLE AND THAT THERE IS A MINIMUM GAP OF 1/16 INCH BETWEEN CLAMP SADDLES AND SUPPORT (FIGURE 1).




FIGURE 1
CABLE CLAMP GRIPPING

TABLE 2

DASH NO.	A DIA.	B DIA.	C DIA.	D LENGTH
3	130	210	379	2 875
4	220	302	505	2 750
5	300	382	550	2 500
8	437	552	744	2 500
10	562	615	889	2 375
12	625	740	1 084	2 250
16	750	927	1 314	2 125
20	875	1 100	1 560	2 000
24	1 250	1 386	1 847	1 875
28	1 375	1 614	2 065	1 750
32	1 624	1 864	2 335	1 625
40	1 874	2 364	2 835	1 500




FIGURE 2
INSTALLING MS3420 (MS3420A) TELESCOPING BUSHING

FIGURE 5A3. Cable diameter build-up procedures.

CABLE DIAMETER BUILD UP PROCEDURES

1. THESE PROCEDURES SHALL BE USED WHEN THE CABLE IS TO BE BUILT UP TO A DIAMETER TO WHICH THE CONNECTOR BACKSHELL ASSEMBLY IS BEING ATTACHED.
2. THE MATERIAL USED FOR CABLE BUILD UP MUST EXTEND COMPLETELY THROUGH THE SEALING GROMMET AND/OR CABLE CLAMP ASSEMBLY.
3. THE FIRST METHOD DEPICTS THE USE OF HEAT SHRINK SLEEVING AS THE MEANS TO INCREASE THE CABLE DIAMETER. THE SECOND METHOD DEPICTS THE USE OF TELESCOPING BUSHINGS AS THE MEANS OF CABLE DIAMETER BUILD UP. EACH METHOD IS DESIGNED SUCH THAT IT CAN BE USED INDIVIDUALLY OR IN COMBINATION WITH THE OTHER AS THE METHOD FOR CABLE BUILD UP.
4. THE FOLLOWING METHOD SHALL BE USED IN CONJUNCTION WITH HEAT SHRINK SLEEVING.

4.1. BUILD UP THE CABLE JACKET IN THE VICINITY OF THE ENVIRONMENTAL SEAL AND/OR CABLE CLAMP AS FOLLOWS

4.1.1 MEASURE THE INSTALLED LENGTH OF THE GROMMET, GROMMET FOLLOWER, AND CABLE CLAMP.

4.1.2 CUT A CORRECTLY SIZED PIECE OF HEAT SHRINKABLE TUBING MEETING THE REQUIREMENTS OF MIL-1-23053.5 CLASS 1 OR MIL-1-23053.10 TO A LENGTH EQUAL TO THAT MEASURED IN STEP 4.1.1.

4.1.2.1 THE SIZE OF THE HEAT SHRINK TUBING SHALL BE SELECTED FROM TABLE 1 SUCH THAT THE INNER DIAMETER AFTER SHRINKING IS EQUAL TO OR LESS THAN THE CABLE DIAMETER.

MILITARY PART NO	AS SUPPLIED ID MIN	AS SUPPLIED ID MAX	AFTER UNRESTRICTED SHRINKAGE WALL THICKNESS
CLASS 1			
W23053 5-101-C	046	023	016 ± 003
102-C	063	031	017 ± 003
103-C	093	046	020 ± 003
104-C	125	062	020 ± 003
105-C	145	070	020 ± 003
106-C	250	125	025 ± 003
107-C	375	187	025 ± 003
108-C	500	250	025 ± 003
109-C	750	375	025 ± 003
110-C	1 000	500	030 ± 003
111-C	1 500	750	030 ± 003
112-C	2 000	1 000	040 ± 006
113-C	3 000	1 500	045 ± 007
114-C	4 000	2 000	050 ± 008
			055 ± 009
CLASS 1 OVEREXPANDED			
115-C	1 000	275	045 ± 005
116-C	2 000	550	045 ± 005
117-C	3 000	810	045 ± 005
118-C	4 000	1 080	045 ± 005
119-C	1 000	1 450	045 ± 005
120-C	2 375	680	045 ± 005
121-C	3 000	840	045 ± 005
122-C	3 750	930	045 ± 005
123-C	4 500	1 450	045 ± 005
W23053 10-001-C	125	071	020 ± 006
002-C	175	100	020 ± 006
003-C	214	125	040 ± 010
004-C	375	214	040 ± 010
005-C	500	300	048 ± 015
006-C	625	357	052 ± 015
007-C	750	428	057 ± 015
008-C	875	500	062 ± 015
009-C	1 000	570	070 ± 020
010-C	1 250	714	087 ± 020
011-C	1 500	857	095 ± 020
012-C	1 750	1 000	107 ± 020
013-C	2 000	1 150	110 ± 025
014-C	2 280	1 280	110 ± 025


DOD-STD-2003-5 (NAVY)
24 JUNE 1987

NOTE:
1. THIS FIGURE SUPERSEDES SHEET 5A4 OF DWG. 803-5001027.

5.2.2 VERIFY THAT SATISFACTORY ENVIRONMENTAL SEALING CAN BE OBTAINED WITHIN TORQUE SPECIFICATION, WITHOUT BOTTOMING OF ADJOINING BACKSHELL ASSEMBLIES.

5.2.3 VERIFY THAT THE CABLE CLAMP SECURELY HOLDS OVER THE BUSHING AND MAINTAINS A MINIMUM GAP OF 1/16 INCH BETWEEN CLAMP SADDLES AND SUP. PORT (FIGURE 1).

NOTE: MORE THAN ONE BUSHING MAY BE USED TO ACHIEVE THE DESIRED CABLE DIAMETER. (SEE FIGURE 3).



5.2 SLIDE A CORRECTLY SIZED MS3420A TELESCOPING BUSHING ON THE CONDUCTOR BUNDLE

5.2.1 TABLE 3 PROVIDES INFORMATION ON THE MS 3420A TELESCOPING BUSHING IN ORDER TO SELECT THE PROPER SIZE BASED ON THE CABLE DIAMETER

TABLE 3

DASH NO.	A DIA.	B DIA.
3	175	210
4	212	302
6	312	427
8	438	531
10	438	615
12	576	597
18	938	1115
20	938	1240
24	1125	1365
28	1250	1614
32	1375	1865
40	1875	2365





FIGURE 3
USING MORE THAN ONE TELESCOPING BUSHING



SH 132317312

FIGURE 5A4. Cable diameter build-up procedure.

INDIVIDUAL LEAD STRIPPING TECHNIQUES

- 1 THERMAL STRIPPING IS THE PREFERRED METHOD WHEN COMPATIBLE WITH THE INSULATION TYPE
- 2 OBSERVE THE FOLLOWING PRECAUTIONS WHEN STRIPPING WIRE WITH EITHER THERMAL OR MECHANICAL STRIPPERS
 - 2.1 ENSURE THE BLADES OR HEATED STRIPPING ELEMENTS OF THERMAL STRIPPERS ARE KEPT CLEAN AT ALL TIMES
 - 2.2 ENSURE ALL STRIPPING BLADES ARE SHARP AND FREE FROM NICKS, BURRS, OR MECHANICAL DEFORMITIES THAT MAY PREVENT PROPER OPERATION
 - 2.3 ENSURE THE CORRECT STRIPPING HOLE IS USED FOR THE WIRE TYPE AND INSULATION TO SHOW CONSTRUCTION OF A COMMON CONDUCTOR
- CAUTION THERE ARE SIGNIFICANT DIFFERENCES BETWEEN THERMAL AND MECHANICAL (AWG) WIRE GAGES. ENSURE ALL COMPARISONS ARE TAKEN USING THE SAME CONVENTION
- 2.4 WHEN STRIPPING THE LEAD, HOLD THE WIRE PERPENDICULAR TO THE CUTTING OR THERMAL BLADE (SEE FIGURES 2 AND 7 FOR EXAMPLE)
- 2.5 AVOID NICKING, CUTTING, OR OTHERWISE DAMAGING THE WIRE STRANDS
- 2.6 ENSURE THERE ARE NO FRAVED OR RAGGED EDGES AFTER THE INSULATION HAS BEEN REMOVED
- 2.7 ENSURE ALL INSULATION HAS BEEN REMOVED FROM THE STRIPPED AREA
- 2.8 CONDUCTOR STRANDS MAY BE BETWISTED, IF REQUIRED TO RESTORE THE NATURAL LAY AND TIGHTNESS OF THE STRANDS. AVOID BARE FINGER CONTACT WITH THE WIRE STRANDS
- 3 GLASS BRAID OR TAPE AND SYNTHETIC RUBBER SHALL BE REMOVED UTILIZING PRECISION MECHANICAL STRIPPERS IN ACCORDANCE WITH STEP 6
- 4 STRIP INDIVIDUAL LEAD
 - 4.1 STRIP LEAD USING THERMAL OR MECHANICAL STRIPPING METHOD (STEP 5 OR 6) TABLE 1 CONTAINS CONDUCTOR INFORMATION FOR COMMON NAVY CABLES AND RECOMMENDED STRIPPING METHOD
 - 4.1.1 STRIPPERS WILL BE TESTED AND ADJUSTED ON A TEST CONDUCTOR PRIOR TO STRIPPING ACTUAL CABLE CONDUCTOR
 - 4.1.2 AVOID NICKING, CUTTING, OR DAMAGING WIRE STRANDS DURING STRIPPING
 - 4.1.3 TAKE CARE TO PREVENT SMALL PARTICLES, ESPECIALLY THOSE WHICH ARE CONDUCTIVE, FROM REMAINING ON THE CONDUCTOR CONTACTS. PARTICLES MAY PREVENT PROPER SEATING OF CONTACTS AND CAUSE SHORT CIRCUITS

- 5.1 WHEN REQUIRED FOR PERSONNEL SAFETY, AN EXHAUST SYSTEM AND AN EXHAUST SYSTEM SHALL BE USED. POLYETHYLENE, POLYFLUOROETHYLENE, OR POLYVINYL CHLORIDE
- 5.2 OBSERVE THE FOLLOWING WHEN USING THERMAL WIRE STRIPPERS
 - 5.2.1 DETERMINE THE INSULATION MATERIAL USING TABLE 1 AS GUIDANCE
 - 5.2.2 EMPLOY THE LOWEST TEMPERATURE SETTING THAT WILL GIVE SATISFACTORY RESULTS
 - 5.2.3 MINIMIZE THE TIME HEAT IS APPLIED FOR STRIPPING. INSURE STRIPPERS ARE KEPT CLEAN TO MELTING AT NO TIME SHOULD THE INSULATION DECOMPOSITION TEMPERATURE BE UTILIZED
 - 5.2.4 ASSURE THE ADEQUACY OF EXHAUST VENTILATION
- 5.3 ENSURE THE STRIPPERS IS SIMILAR TO IDEAL INDUSTRY PRACTICES. THE STRIPPER IDEAL PART NO. AS-1301. ADJUST THE WIRE STRIPPER FOR THE DEPTH OF THE CONTACT WIRE BARREL SPECIFIED FOR THE TYPE OF CONNECTOR ASSEMBLED PLUS THE ALLOWABLE INSULATION CLEARANCE SPECIFIED IN STEP 7. (SEE FIGURE 2)
- 5.4 ADJUST THE TEMPERATURE TO THE INSULATION TO BE STRIPPED. THE TEMPERATURE SPECIFIED IN TABLE 1 FOR THE INSULATION TYPE IS THE MAXIMUM TEMPERATURE IS NOT LISTED USE A PRECISION MECHANICAL STRIPPER IN ACCORDANCE WITH STEP 6
- 5.5 CHECK STRIP LENGTH ON SEVERAL TEST PIECES
 - 5.5.1 STRIP LENGTH SHOULD MEET CRITERIA OF INSULATION CLEARANCE (SEE STEP 7). ADJUST STRIP LENGTH AS NECESSARY

NOTES:
1. THIS FIGURE SUPERSEDES SHEET 6A6 OF DWG. 803-5001027.




FIGURE 3
PRECISION MECHANICAL STRIPPER




FIGURE 2
THERMAL STRIPPER DEPTH ADJUSTMENT

- 5.6 INSERT THE CONDUCTOR TO BE STRIPPED BETWEEN THE HEATING ELEMENTS OR STRIPPER BLADES
- 5.7 TWIST THE TOOL SLIGHTLY OR ROTATE THE WIRE TO PING THE INSULATION WHILE APPLYING HEAT (SEE FIGURE 1)
- 5.8 DRAW THE WIRE FROM THE TOOL. THE INSULATION SLUG WILL BE REMOVED WITH THE HEATING ELEMENTS
6. PRECISION MECHANICAL STRIPPER (FIGURE 3)
 - 6.1 ENSURE STRIPPER IS A PRECISION FIXED DIE CUTTING WHICH MEETS THE REQUIREMENTS OF FIG. 5. THE STRIPPER SHALL BE ADJUSTED BY THE OPERATOR. OPERATOR ADJUSTMENT SHALL NOT BE USED (SEE FIGURE 4)




FIGURE 4
UNACCEPTABLE WIRE STRIPPER




FIGURE 1
THERMAL STRIPPER

SH 132317313

FIGURE 5A5. Individual lead stripping techniques.

NOTES:
1. THIS FIGURE SUPERSEDES SHEET 5A6 OF DWG. 803-5001027.

TABLE 2

NUMBER OF STRANDS LESS THAN 7	MAXIMUM ALLOWABLE NICKED OR BROKEN STRANDS
7-15	0
16-18	2
19-25	3
26-30	4
31-40	5
41 OR MORE	6

8 2 FOR CRIMPED CONTACTS, NO CONDUCTOR STRAND DAMAGE IS ACCEPTABLE

9 REWORK REJECTED CONDUCTORS AS FOLLOWS

9 1 CUT THE CONDUCTOR SQUARE WHERE THE DAMAGE ENDS

9 2 RESTRIP THE CONDUCTOR IN ACCORDANCE WITH STEP 4




FIGURE 7
CONDUCTOR POSITIONED IN STRIPPER

6 6 SQUEEZE THE HANDLES

7 EXAMINE THE STRIPPED WIRE FOR INSULATION DAMAGE AND PROPER INSULATION CLEARANCE. WIRES WITH DAMAGED INSULATION SHALL NOT BE USED

7 1 CRIMP CONTACT INSULATION CLEARANCE SPECIFICATION

7 1 1 CONDUCTOR MUST BE BOTTOMED IN CONTACT WIRE BARREL

7 1 2 CONDUCTOR MUST BE VISIBLE IN INSPECTION HOLE

7 1 3 CONDUCTOR SHOULD ONLY BE VISIBLE TO A MAXIMUM OF 1/32-INCH (20 GAUGE AND SMALLER), 1/16-INCH (18 GAUGE AND LARGER) AT REAR OF CONTACT

7 1 4 CONTOUR OF THE CONDUCTOR SHALL BE VISIBLE AT THE INSULATION GAP

7 2 SOLDER CONTACT INSULATION CLEARANCE SPECIFICATION

7 2 1 CONDUCTOR MUST BE BOTTOMED IN CONTACT WIRE BARREL

7 2 2 MINIMUM CLEARANCE, INSULATION MUST NOT BE EMBEDDED IN THE SOLDER JOINT

7 2 3 CONTOUR OF THE CONDUCTOR SHALL BE VISIBLE AT THE INSULATION GAP

7 2 4 MAXIMUM CLEARANCE, LESS THAN TWO TIMES THE INSULATION CLEARANCE SPECIFICATION OR 1/16 INCH, WHICHEVER IS LARGER, BUT SHALL NOT PERMIT SHORTING BETWEEN ADJACENT CONDUCTORS

8 EXAMINE THE WIRE WITH A MAGNIFYING GLASS (6X TO 10X POWER) TO ENSURE THE STRANDS HAVE NOT BEEN SCRATCHED, NICKED, CUT, SCRAPED, BROKEN OR OTHERWISE DAMAGED

8 1 SEE TABLE 2 FOR REJECTION CRITERIA FOR SOLDER CONTACTS

6 2 EXAMINE THE STRIPPER TO ENSURE THE BLADES LINE UP FOR PROPER OPERATION (SEE FIGURE 5)




FIGURE 5
STRIPPING BLADE ALIGNMENT

6 3 SET THE WIRE STOP FOR THE DEPTH OF THE CONDUCTOR INSULATION CLEARANCE IN THE CONNECTOR. FOR ASSEMBLY PROCEDURE FOR THE CONNECTOR TYPE BEING ASSEMBLED, PLUS THE ALLOWABLE INSULATION CLEARANCE SPECIFIED IN STEP 7 (SEE FIGURE 6)




FIGURE 6
MECHANICAL STRIPPER DEPTH ADJUSTMENT

6 4 CHECK STRIP LENGTH ON SEVERAL TEST PIECES

6 4 1 STRIP LENGTH SHOULD MEET CRITERIA OF INSULATION CLEARANCE SPECIFICATION (STEP 7). ADJUST STRIP LENGTH AS NECESSARY

6 4 2 ENSURE CORRECT STRIPPING HOLE IS USED FOR CORRESPONDING CONDUCTOR GAUGE. SEE TABLE 1 FOR CONDUCTOR SIZE

6 5 POSITION THE CONDUCTOR IN THE STRIPPER JAWS (SEE FIGURE 7)




FIGURE 3
TYPICAL CONDUCTOR CONSTRUCTION

FIGURE 5A6. Individual lead stripping techniques.

SH 132317314

NOTES:
1. THIS FIGURE SUPPLEMENTS SHEET 5A7 OF DWG. 803-5001027.

CABLE TYPE	CONDUCTOR WIRE MATERIAL	SIZE OF WIRE (NAVY STANDARD)	NO. OF STRANDS PER CONDUCTOR	MAX WIRE DIAMETER	MAX CONDUCTOR DIAMETER	CONDUCTOR INSULATION MATERIAL	INSULATION TEMPERATURE (UNDETERMINED)	INSULATION TEMPERATURE (UNDETERMINED)	CONDUCTOR INSULATION MATERIAL	INSULATION TEMPERATURE (UNDETERMINED)	INSULATION TEMPERATURE (UNDETERMINED)	INSULATION JACKET DECOMPOSITION TEMP.	RECOMMENDED STRIPPING METHOD
DHOF-3	COPPER UNCOATED	21/2(26) STANDARD	26	0.061	0.123	SEPARATOR NOTE 2	TEMPERATURE UNDETERMINED	TEMPERATURE UNDETERMINED	SYNTHETIC RUBBER	248°F NOTE 7	248°F	248°F	MECHANICAL
DHOF-4	COPPER UNCOATED	4(41)	41	0.077	0.139	SEPARATOR NOTE 2	TEMPERATURE UNDETERMINED	TEMPERATURE UNDETERMINED	SYNTHETIC RUBBER	248°F NOTE 7	248°F	248°F	MECHANICAL
DHOF-6	COPPER UNCOATED	6(65) STANDARD	65	0.097	0.159	SEPARATOR NOTE 2	TEMPERATURE UNDETERMINED	TEMPERATURE UNDETERMINED	SYNTHETIC RUBBER	248°F NOTE 7	248°F	248°F	MECHANICAL
DSGU-3 NOTE 1	COPPER UNCOATED	3(7) STANDARD	7	0.060	0.130	EXTRUDED SILICONE RUBBER	482°F	482°F	GLASS BRAID	1300°F	—	—	MECHANICAL
DSGU-4 NOTE 1	COPPER UNCOATED	4(7) STANDARD	7	0.076	0.143	EXTRUDED SILICONE RUBBER	482°F	482°F	GLASS BRAID	1300°F	—	—	MECHANICAL
DSGU-50 NOTE 1	COPPER UNCOATED	50(19) STANDARD	19	0.254	0.334	SILICONE RUBBER	482°F	482°F	GLASS TAPE	1300°F	—	—	MECHANICAL
PHOF-4	COPPER UNCOATED	4(41) STANDARD	41	0.077	0.139	SEPARATOR NOTE 2	TEMPERATURE UNDETERMINED	TEMPERATURE UNDETERMINED	SYNTHETIC RUBBER	248°F NOTE 7	248°F	248°F	MECHANICAL
PHOF-9	COPPER UNCOATED	9(90) STANDARD	90	0.120	0.182	SEPARATOR NOTE 2	TEMPERATURE UNDETERMINED	TEMPERATURE UNDETERMINED	SYNTHETIC RUBBER	248°F NOTE 7	248°F	248°F	MECHANICAL
FSGU-3 NOTE 1	COPPER UNCOATED	3(7) STANDARD	7	0.060	0.096	EXTRUDED SILICONE RUBBER	482°F	482°F	GLASS BRAID	1300°F	—	—	MECHANICAL
FSGU-4 NOTE 1	COPPER UNCOATED	4(7) STANDARD	7	0.076	0.112	EXTRUDED SILICONE RUBBER	482°F	482°F	GLASS BRAID	1300°F	—	—	MECHANICAL
FSGU-9 NOTE 1	COPPER UNCOATED	9(7) STANDARD	7	0.108	0.154	EXTRUDED SILICONE RUBBER	482°F	482°F	GLASS BRAID	1300°F	—	—	MECHANICAL
FSGU-23 NOTE 1	COPPER UNCOATED	23(7) STANDARD	7	0.171	0.316	EXTRUDED SILICONE RUBBER	482°F	482°F	GLASS BRAID	1300°F	—	—	MECHANICAL
FSGU-50 NOTE 1	COPPER UNCOATED	50(19) STANDARD	19	0.254	0.334	SILICONE RUBBER	482°F	482°F	GLASS TAPE	1300°F	—	—	MECHANICAL
MCOS 2	COPPER UNCOATED	11/2(16) STANDARD	16	0.049	0.072	POLYVINYL CHLORIDE	300° 375°F	412°F	BRAIDED POLYVINYL CHLORIDE AWG 34 OR 36 COPPER	EXTREMELY HIGH. MUST BE MECHANICALLY STRIPPED	—	—	MECHANICAL
MCOS 6	COPPER UNCOATED	1(10) STANDARD	10	0.038	0.064	POLYVINYL CHLORIDE	300° 375°F	412°F	BRAIDED POLYVINYL CHLORIDE AWG 34 OR 36 COPPER	EXTREMELY HIGH. MUST BE MECHANICALLY STRIPPED	—	—	MECHANICAL
THFWA	COPPER UNCOATED	3/5(7) STANDARD	7	0.030	0.062	POLYVINYL CHLORIDE	300° 375°F	412°F	NONE	—	—	—	THERMAL
TTO ² XX	COPPER UNCOATED	1(10) STANDARD	10	0.038	0.078	POLYVINYL CHLORIDE	300° 375°F	412°F	NONE	—	—	—	THERMAL
TTS XX NOTE 6	COPPER UNCOATED	1(7) STANDARD	7	0.038	0.078	POLYETHYLENE	275° 400°F	440°F	POLYAMIDE	315° 450°F	700°F	700°F	THERMAL

SH 132317315

FIGURE 5A7. Individual lead stripping techniques.

DOD-STD-2003-5 (NAVY)
24 JUNE 1987

NOTES:
1. THIS FIGURE SUPERSEDES SHEET 5A8 OF DWG. 803-5001027.

CABLE TYPE	CONDUCTOR WIRE MATERIAL	SIZE OF WIRE (ASTM B 286)	NO. OF STRANDS PER CONDUCTOR	MAX WIRE DIAMETER	MAX CONDUCTOR DIAMETER	CONDUCTOR PRIMARY INSULATION MATERIAL	INSULATION MELTING TEMPERATURE	INSULATION DECOMPOSITION TEMP	CONDUCTOR INSULATION JACKET MATERIAL	INSULATION MELTING TEMPERATURE	INSULATION JACKET DECOMPOSITION TEMP	RECOMMENDED STRIPPING METHOD
TSU XX NOTE 1	COPPER UNCOATED	18-19 (NAVY STANDARD)	7	0.030	0.047	EXTRUDED SILICONE RUBBER	482°F	530°F	POLYAMIDE	325°-450°F	700°F	THERMAL
ISMWU-70	COPPER TIN COATED	22-7 (ASTM B 286)	7	0.033	0.093	POLYETHYLENE	275°-400°F	440°F	POLYAMIDE	325°-450°F	700°F	THERMAL
ISSOMU-70	COPPER TIN COATED	22-7 (ASTM B 286)	7	0.033	0.093	POLYETHYLENE	275°-400°F	440°F	POLYAMIDE	325°-450°F	700°F	THERMAL
SA-40 NOTE 5	COPPER TIN COATED	22-7 (ASTM B 286)	7	0.033	0.081	POLYETHYLENE	275°-400°F	440°F	POLYAMIDE	325°-450°F	700°F	THERMAL
2SJ 16	COPPER TIN COATED	16-19 (ASTM B 286)	19	0.062	0.091	POLYVINYL CHLORIDE	300°-375°F	412°F	BRAIDED SHIELD TIN COATED COPPER AVG 30	EXTREMELY HIGH BRAID MUST BE MECHANICALLY STRIPPED	—	MECHANICAL
2SJ 20	COPPER TIN COATED	20-19 (ASTM B 286)	19	0.038	0.073	POLYVINYL CHLORIDE	300°-375°F	412°F	BRAIDED SHIELD TIN COATED COPPER AVG 30	EXTREMELY HIGH BRAID MUST BE MECHANICALLY STRIPPED	—	MECHANICAL
2SU XX NOTE 1	COPPER UNCOATED	22-7 (ASTM B 286)	7	0.033	0.059	POLYETHYLENE	275°-400°F	440°F	POLYAMIDE	325°-450°F	700°F	THERMAL
2SWA XX NOTE 5	COPPER UNCOATED	22-7 (ASTM B 286)	7	0.033	0.059	POLYETHYLENE	275°-400°F	440°F	POLYAMIDE	325°-450°F	700°F	THERMAL
2U XX	COPPER TIN COATED	26-7 (ASTM B 286)	7	0.020	0.051	POLYETHYLENE	275°-400°F	440°F	POLYAMIDE	325°-450°F	700°F	THERMAL
2UW XX	COPPER TIN COATED	26-7 (ASTM B 286)	7	0.020	0.044	POLYETHYLENE	275°-400°F	440°F	NONE	—	—	THERMAL
3SJ 12	COPPER UNCOATED	18-19 (NAVY STANDARD)	7	0.092	0.145	POLYVINYL CHLORIDE	300°-375°F	412°F	BRAIDED SHIELD TIN COATED COPPER AVG 30 OR SMALLER	EXTREMELY HIGH BRAID MUST BE MECHANICALLY STRIPPED	—	MECHANICAL
3SJ 14	COPPER TIN COATED	14-19 (ASTM B 286)	19	0.072	0.105	POLYVINYL CHLORIDE	300°-375°F	412°F	BRAIDED SHIELD TIN COATED COPPER AVG 30 OR SMALLER	EXTREMELY HIGH BRAID MUST BE MECHANICALLY STRIPPED	—	MECHANICAL
3SJ 16	COPPER TIN COATED	16-19 (ASTM B 286)	19	0.062	0.091	POLYVINYL CHLORIDE	300°-375°F	412°F	BRAIDED SHIELD TIN COATED COPPER AVG 30 OR SMALLER	EXTREMELY HIGH BRAID MUST BE MECHANICALLY STRIPPED	—	MECHANICAL
3SJ 18	COPPER TIN COATED	18-19 (ASTM B 286)	19	0.051	0.084	POLYVINYL CHLORIDE	300°-375°F	412°F	BRAIDED SHIELD TIN COATED COPPER AVG 30 OR SMALLER	EXTREMELY HIGH BRAID MUST BE MECHANICALLY STRIPPED	—	MECHANICAL
3SU XX NOTE 1	COPPER UNCOATED	18AWG	7	0.050	0.096	POLYETHYLENE	275°-400°F	440°F	POLYAMIDE	325°-450°F	700°F	THERMAL
3SU 3 NOTE 1	COPPER UNCOATED	18-19 (NAVY STANDARD)	7	0.060	0.130	EXTRUDED SILICONE RUBBER	482°F	530°F	GLASS BRAID	1300°F	—	MECHANICAL
7SGU 4 NOTE 1	COPPER UNCOATED	18-19 (NAVY STANDARD)	7	0.076	0.143	EXTRUDED SILICONE RUBBER	482°F	530°F	GLASS BRAID	1300°F	—	MECHANICAL
WHOF XX	COPPER UNCOATED	21-19 (NAVY STANDARD)	19	0.057	0.097	POLYVINYL CHLORIDE	300°-375°F	412°F	NONE	—	—	THERMAL

SH 132317316

FIGURE 5A8. Individual lead stripping techniques.

DOD-STD-2003-5 (NAVY)
24 JUNE 1987

NOTES:
1. THIS FIGURE SUPERSEDES SHEET 5A9 OF
DWG. 803-4001027

CABLE TYPE	CONDUCTOR WIRE MATERIAL	SIZE OF WIRE (NAVY STANDARD)	NO OF STRANDS PER CONDUCTOR	MAX WIRE DIAMETER	MAX CONDUCTOR DIAMETER	CONDUCTOR PRIMARY INSULATION MATERIAL	INSULATION MELTING TEMPERATURE	INSULATION DECOMPOSITION TEMP	INSULATION JACKET MATERIAL	INSULATION MELTING TEMPERATURE	INSULATION DECOMPOSITION TEMP	RECOM. MENDED PING METHOD
MHF	COPPER UNCOATED	21 (218)	26	0.061	0.082	SYNTHETIC RESIN	475°-600°F	482°-662°F	FELTED ASBESTOS OR GLASS FIBER TO 0.125 DIA. OF STRIPPED NOTE 8	EXTREMELY HIGH BRAID MUST BE MECHANICALLY STRIPPED NOTE 8	EXTREMELY HIGH BRAID MUST BE MECHANICALLY STRIPPED NOTE 8	MECHANICAL
MSCU-XX NOTE 1	COPPER UNCOATED	217 (NAVY STANDARD)	7	0.048	0.084	EXTRUDED RUBBER	482°F	530°F	GLASS BRAID	1300°F	—	MECHANICAL
MSP NOTE 4	COPPER TIN COATED	22-7 (ASTM B-286)	7	0.031	0.119	FLUORO-CARBON RESIN	475°-600°F	800°-900°F	BRAIDED SHIELD AWG 34 OR 38 COPPER	EXTREMELY HIGH, MUST BE MECHANICALLY STRIPPED	EXTREMELY HIGH	MECHANICAL
	COPPER TIN COATED	20-7 (ASTM B-286)	7	0.038	0.088	POLYVINYL CHLORIDE	300°-375°F	412°F	POLYAMIDE	325°-450°F	700°F	THERMAL
	COPPER TIN COATED	31-7 (NAVY STANDARD)	7	0.060	0.094	POLYVINYL CHLORIDE	300°-375°F	412°F	POLYAMIDE	325°-450°F	700°F	THERMAL
MSTCP-65 NOTE 3	COPPER TIN COATED	22 (A W G)	7	0.033	0.064 (DIAMETER OF CONDUCTOR WITH RUBBER INSULATION ONLY)	NATURAL RUBBER OR NATURAL POLYCHLOROPRENE LAYER	NOTE 9	NOTE 9	3 LAYERS OF BRAID RAYON, TINNED COPPER, RAYON	MECHANICALLY STRIP JACKET	—	MECHANICAL
	COPPER TIN COATED	22 (A W G)	7	0.033	0.064	SAME AS ABOVE	NOTE 9	NOTE 9	SAME AS ABOVE	MECHANICALLY STRIP JACKET	—	MECHANICAL
	COPPER TIN COATED	22 (A W G)	7	0.033	0.072	SAME AS ABOVE	NOTE 9	NOTE 9	SAME AS ABOVE	MECHANICALLY STRIP JACKET	—	MECHANICAL
	COPPER TIN COATED	18 (A W G)	7	0.062	0.082	SAME AS ABOVE	NOTE 9	NOTE 9	SAME AS ABOVE	MECHANICALLY STRIP JACKET	—	MECHANICAL
	COPPER TIN COATED	16 (A W G)	7	0.062	0.092	SAME AS ABOVE	NOTE 9	NOTE 9	SAME AS ABOVE	MECHANICALLY STRIP JACKET	—	MECHANICAL
	COPPER TIN COATED	19 (A W G)	7	0.045	0.077	SAME AS ABOVE	NOTE 9	NOTE 9	SAME AS ABOVE	MECHANICALLY STRIP JACKET	—	MECHANICAL
RG-108A-U	COPPER TIN COATED	20 (A W G)	7	0.038	0.079	POLYETHYLENE	275°-400°F	440°F	NONE	—	—	THERMAL
SHOF-3	COPPER UNCOATED	21-2 (65) (NAVY STANDARD)	65	0.061	0.123	SEPARATOR NOTE 2	TEMPERATURE UNDETERMINED SEE NOTE 2	TEMPERATURE UNDETERMINED SEE NOTE 2	SYNTHETIC RUBBER	248°F NCTE 7	248°F	MECHANICAL
SSGU-50 NOTE 1	COPPER UNCOATED	50-19 (NAVY STANDARD)	19	0.254	0.334	SILICONE RUBBER	482°F	530°F	GLASS TAPE	1300°F	—	MECHANICAL
THOF-3	COPPER UNCOATED	21-7 (26) (STANDARD)	26	0.061	0.123	SEPARATOR NOTE 2	TEMPERATURE UNDETERMINED SEE NOTE 2	TEMPERATURE UNDETERMINED SEE NOTE 2	SYNTHETIC RUBBER	243°F NCTE 7	248°F	MECHANICAL
THOF-9	COPPER UNCOATED	9-90 (NAVY STANDARD)	90	0.120	0.182	SEPARATOR NOTE 2	TEMPERATURE UNDETERMINED SEE NOTE 2	TEMPERATURE UNDETERMINED SEE NOTE 2	SYNTHETIC RUBBER	243°F NCTE 7	248°F	MECHANICAL
THOF-14	COPPER UNCOATED	141-140 (NAVY STANDARD)	140	0.145	0.225	SEPARATOR NOTE 2	TEMPERATURE UNDETERMINED SEE NOTE 2	TEMPERATURE UNDETERMINED SEE NOTE 2	SYNTHETIC RUBBER	249°F NCTE 7	248°F	MECHANICAL
TSGU-3 NOTE 1	COPPER UNCOATED	31-7 (NAVY STANDARD)	7	0.060	0.130	EXTRUDED SILICONE RUBBER	482°F	530°F	GLASS BRAID	1300°F	—	MECHANICAL

FIGURE 5A9. Individual lead stripping techniques.

SH 132317317

NOTES:
1. THIS FIGURE SUPERSEDES SHEET 5A10 OF DWG. 803-5001027.

CABLE TYPE	CONDUCTOR WIRE MATERIAL	CONDUCTOR SIZE OF WIRE (NAVY STANDARD)	NO. OF STRANDS PER CONDUCTOR	MAX WIRE DIAMETER	MAX CONDUCTOR DIAMETER	CONDUCTOR PRIMARY INSULATION MATERIAL	INSULATION TEMPERATURE	INSULATION DECOMPO. TEMPERATURE	CONDUCTOR INSULATION MATERIAL	INSULATION MELTING TEMPERATURE	INSULATION DECOMPO. SITION TEMP	RECOMMENDED STRIPPING METHOD
TSGU-4 NOTE 1	COPPER UNCOATED	4/7 (NAVY STANDARD)	7	0.108	0.143	EXTRUDED SILICONE RUBBER	482°F	530°F	GLASS BRAID	1300°F	-	MECHANICAL
TSGU-9 NOTE 1	COPPER UNCOATED	8/7 (NAVY STANDARD)	7	0.136	0.187	EXTRUDED SILICONE RUBBER	482°F	530°F	GLASS BRAID	1300°F	-	MECHANICAL
TSGU-14 NOTE 1	COPPER UNCOATED	14/7 (NAVY STANDARD)	7	0.171	0.230	EXTRUDED SILICONE RUBBER	482°F	530°F	GLASS BRAID	1300°F	-	MECHANICAL
TSGU-23 NOTE 1	COPPER UNCOATED	23/7 (NAVY STANDARD)	7	0.457	0.284	EXTRUDED SILICONE RUBBER	482°F	530°F	GLASS BRAID	1300°F	-	MECHANICAL
TSGU-150 NOTE 1	COPPER UNCOATED	150/61 (NAVY STANDARD)	61		0.557	SILICONE RUBBER	482°F	530°F	GLASS TAPE	1300°F	-	MECHANICAL

TABLE 3

IDEAL CAT. NO.	BLADE ONLY	BLADE HOLE SIZE											
		10	12	14	16	18	20	22	24	26	28	30	
45-169	L-9300 CUTTER DIA COUNTERBORE DIA							024	024	018	014	012	
45-170	L-5210 CUTTER DIA COUNTERBORE DIA	116	0937	076									
45-180	L-5210 CUTTER DIA COUNTERBORE DIA	154	136	113									
45-171	L-5211 CUTTER DIA COUNTERBORE DIA				062	052	042	035	0292	022			
45-181	L-5211 CUTTER DIA COUNTERBORE DIA				096	086	073	0635	0585	052			
45-176	L-5436 CUTTER DIA COUNTERBORE DIA										024	016	
45-182	L-5436 CUTTER DIA COUNTERBORE DIA										043	037	
45-173	L-5562 CUTTER DIA COUNTERBORE DIA	119	096	076									
45-183	L-5562 CUTTER DIA COUNTERBORE DIA	144	125	104									
45-174	L-5563 CUTTER DIA COUNTERBORE DIA				061	052	042	034	028	023			
45-184	L-5563 CUTTER DIA COUNTERBORE DIA				089	0785	067	0595	0465	045			
45-185	L-5564 CUTTER DIA COUNTERBORE DIA										022	018	
45-175	L-5559 CUTTER DIA COUNTERBORE DIA	119	096	076							043	042	
45-186	L-5559 CUTTER DIA COUNTERBORE DIA	136	113	0935									
45-177	L-5560 CUTTER DIA COUNTERBORE DIA				081	052	042	034	028	023			
45-187	L-5560 CUTTER DIA COUNTERBORE DIA				081	070	0556	043	039	035			
45-178	L-5561 CUTTER DIA COUNTERBORE DIA										023	019	
45-188	L-5561 CUTTER DIA COUNTERBORE DIA										035	032	
45-179	L-7625 CUTTER DIA COUNTERBORE DIA											012	
												020	

NOTE 1 WHEN THIS CABLE IS MANUFACTURED WITH AN ARMOR THE LAST LETTER OF THE CABLE DESIGNATION CHANGES FROM U TO A.

NOTE 2 SEVERAL TYPES OF WIRES ARE MANUFACTURED WITH AN INSULATION PACKET CALLED THE SEPARATOR THE SEPARATOR MAY CONSIST OF ANY ONE OF THE FOLLOWING MATERIALS

- A. GLASS FIBERS
- B. SYNTHETIC FIBERS
- C. COTTON
- D. COTTON TAPE
- E. SYNTHETIC FIBER TAPE
- F. PAPER TAPE
- G. POLYESTER TAPE

ENSURE THE SEPARATOR IS REMOVED ALONG WITH THE INSULATION

NOTE 3 REFER TO MIL-C-19787

NOTE 4 WHEN MANUFACTURED IN THE WATER TIGHT VERSION THE LETTER W IS ADDED TO THE CABLE DESIGNATION

NOTE 5 IN THE UNARMORED VERSION THE LETTER U IS ADDED TO THE CABLE DESIGNATION

NOTE 6 WHEN THIS CABLE IS MANUFACTURED WITH AN ARMOR THE TYPE DESIGNATION SHALL CHANGE TO TRSA

NOTE 7 SYNTHETIC RUBBER DECOMPOSES AND FUMES HEAVILY AT THE TEMPERATURE OF MATERIAL PLACED

NOTE 8 TAKE PRECAUTIONS FOR ASBESTOS DUST

NOTE 9 NATURAL RUBBER DOES NOT MELT WITHOUT FUMING AND CHIPPING

SH 132317318

FIGURE 5A10. Individual lead stripping techniques.


- 1 OBSERVE THE FOLLOWING WHEN CRIMPING CONTACTS
 - 1.1 ENSURE THE CRIMPING TOOL IS CALIBRATED IN ACCORDANCE WITH MIL-C-22520
 - 1.2 THE CRIMPING TOOL AND POSITIONER SHALL CONFORM TO MIL-C-22520
 - 2 SELECT THE CRIMPING TOOL (SEE FIGURE 1) AND POSITIONER IN ACCORDANCE WITH THOSE SPECIFIED FOR THE CONNECTOR BEING ASSEMBLED
 - 3 CHECK THE CRIMPING TOOL FOR PROPER OPERATION AS FOLLOWS
 - 3.1 CHECK PROPER ACTION OF TOOL
 - 3.1.1 SQUEEZE HANDLES TOGETHER
 - 3.1.2 CHECK LOCKING MECHANISM (RATCHET) RELEASES WHEN HANDLES ARE FULLY CLOSED
 - 3.1.3 RELEASE THE HANDLES
 - 3.2 CHECK PROPER ACTION OF CRIMPERS
 - 3.2.1 SELECT CORRECT INSPECTION GAGE (GO/NO GO GAGE) FOR CRIMPING TOOL PER MIL-C-22520 (REFER TO POSITION SHEET PROVIDED WITH CRIMPING TOOL)
 - 3.2.2 ROTATE SELECTOR KNOB TO CORRECT POSITION FOR INSPECTION SHEET
 - 3.2.3 ACTIVATE THE TOOL TO THE FULLY CLOSED POSITION AND HOLD THE SPACE BETWEEN OPPOSING CLOSED INDENTERS. RELEASE PRESSURE ON THE HANDLES AND ALLOW THE TOOL TO OPEN AUTOMATICALLY
 - 3.2.4 ACTIVATE THE TOOL TO THE FULLY CLOSED POSITION AND HOLD THE "NO GO" GAGE. SHALL NOT BE INSERTABLE BETWEEN OPPOSING INDENTERS
- NOTE: DO NOT CRIMP THE GAGE. IT WILL DAMAGE THE INDENTERS
- 3.3 CONDUCT A PULL TEST ON A TEST CONDUCTOR AS FOLLOWS
 - 3.3.1 SELECT A SAMPLE WIRE WHICH MATCHES THE POSITION AND SIZE
 - 3.3.2 STRIP THE SAMPLE CONDUCTOR TO THE SAME DISTANCE AS DETERMINED FOR THE CRIMPING TOOL (REFER TO POSITION SHEET PROVIDED IN ACCORDANCE WITH SHEET 5A5)
 - 3.3.3 CRIMP A CONTACT IDENTICAL TO CONTACTS BEING UTILIZED IN APPLICABLE CONNECTOR ASSEMBLY (PROCEDURE) TO THE SAMPLE WIRE FOLLOWING STEPS 4 THROUGH 11
 - 3.3.4 CONDUCT A PULL TEST IN ACCORDANCE WITH STEP 12 OF THIS PROCEDURE
 - 3.3.5 IF THE SAMPLE WIRE BREAKS OR PULLS OUT OF THE CONTACT, REPERFORM STEP 3.1 THROUGH 3.3 TO OBTAIN A NEW CRIMPING TOOL AND REPERFORM STEPS 1 THROUGH 3.3.4
 - 4 MOUNT THE POSITIONER ON THE CRIMPING TOOL IN ACCORDANCE WITH THE APPROPRIATE INSTRUCTIONS FOR THE TOOL BEING USED

NOTE: THE TOOL HANDLES MUST BE FULLY OPEN WHEN INSERTING THE POSITIONER OR CHANGING THE SELECTOR SETTING
 - 5 SET THE WIRE SIZE SELECTOR KNOB FOR THE WIRE SIZE BEING CRIMPED. THE CORRECT WIRE SIZE SELECTOR NUMBER IS DETERMINED FROM THE CHART ON THE SIDE OF THE TURRET HEAD


- 6 INSERT THE STRIPPED WIRE INTO THE CONTACT. THE STRIPPED WIRE MUST BE VISIBLE IN THE INSPECTION HOLE AND AT THE REAR OF CONTACT AND INSULATION DEPENDS ON CONTACT SIZE (SEE FIGURE 2)



- 11 INSPECT THE CRIMPED CONTACT FOR THE FOLLOWING
 - 11.1 EVEN CRIMP
 - 11.2 NO CRACKS UNDER A MAGNIFYING GLASS (3X POWER)
 - 11.3 WIRE VISIBLE IN INSPECTION HOLE
 - 11.4 1/32 INCH MAXIMUM GAP BETWEEN CONTACT AND INSULATION. 1/16 INCH MAXIMUM GAP BETWEEN CONTACT AND INSULATION FOR 18 GAGE AND LARGER (SEE FIGURE 2)
- 12 CONDUCT A PULL TEST ON ALL CRIMPED CONDUCTORS AS FOLLOWS
 - 12.1 INSTALL THE PULL TEST ADAPTER (NAVSEA DWG NUMBER OR EQUIVALENT) ON THE TENSION END OF THE TENSION/COMPRESSION GAGE (CHATILLON DPP SERIES OR EQUIVALENT). (SEE FIGURE 4)



- 6.1 ENSURE ALL WIRE STRANDS ARE INSERTED INTO THE CONTACT WIRE BARREL
- 7 TURN THE CRIMPING TOOL SO THE FRONT IS FACING THE OPERATOR
- 8 INSERT THE WIRE AND CONTACT THROUGH THE INDENTERS UNTIL IT BOTTOMS IN THE POSITIONER (SEE FIGURE 3)



- 12.2 INSERT THE CRIMPED CONTACT INTO THE PULL TEST ADAPTER
- 12.3 PULLING AGAINST THE CONTACT SHOULDER. PULL TEST THE CRIMPED CONTACT TO THE VALUE SPECIFIED IN TABLE 1
- 12.4 THE LEAD SHOULD NOT PULL OUT OF OR BREAK WITHIN THE CONTACT BARREL
- 12.5 RELEASE THE CONTACT
- 13 REWORK ANY FAILED CRIMPED CONTACT
 - 13.1 FAILED CRIMPED CONTACTS SHOULD BE REMOVED BY CUTTING THE CONTACT JUST ABOVE THE CRIMPED AREA

- 9 HOLD THE WIRE IN PLACE AND SQUEEZE THE HANDLES UNTIL THE RATCHET RELEASES AND THE TOOL OPENS. THE RATCHET WHICH WAS NOT RELEASED UNTIL THE CRIMPING CYCLE HAS BEEN COMPLETED
- 10 REMOVE THE CRIMPED CONTACT AFTER RELEASING THE HANDLES

FIGURE 5A11. Connector contact crimping techniques

DOD-STD-2003-5 (NAVY)
24 JUNE 1987

NOTES:
1. THIS FIGURE SUPERSEDES SHEET 5A12 OF DWG. 803-5001027.





FIGURE 1
MIL-C-22670
CRIMPING TOOLS

TABLE 1

WIRE BARREL SIZE	WIRE SIZE RANGE	AXIAL LOAD (POUNDS)		
		SILVER, OR TIN-PLATED COPPER WIRE	NICKEL-PLATED COPPER WIRE	COPPER ALLOY WIRE
0000	0000	25	25	25
0	0	25	25	25
2	2	25	25	25
4	4	25	25	25
6	6	25	25	25
8	8	25	25	25
10	10	25	25	25
12	12	25	25	25
14	14	25	25	25
16	16	25	25	25
20	20	10	6.5	25
22	22	4	3	15
24	24	6.5	4.5	9
26	26	1.5	1.0	3.5
28	28	2.2	1.4	5.5
32	32	0.7	0.6	2.7
		0.5	0.5	1.2


*WITH ELECTRICALLY CONDUCTIVE BUSHING



SH 132317320



FIGURE 5A12. Connector contact crimping techniques.

NOTES:
1. THIS FIGURE SUPERSEDES SHEET 5A13 OF DWG. 803-5001027.



- 2.3 SELECT A SOLDERING IRON TIP WHICH WILL GIVE THE MAXIMUM WICKING AND REPRESENTATIVE TIPS AND IS NOT INTENDED AS A SELECTION GUIDE
 - 2.4 PREPARE THE SOLDERING IRON WITH A SOLDER HEAT BRIDGE (POOL OF SOLDER) (FIGURE 2A)
 - 2.5 PLACE THE STRIPPED END OF THE CONDUCTOR TO BE TINNED ON THE IRON TIP IN THE POOL OF SOLDER (FIGURE 2B)
 - 2.6 APPLY ROSIN CORE SOLDER TO THE WIRE (FIGURE 2C)
 - 2.7 SEPARATE THE WIRE FROM THE IRON WITH A WIPING MOTION (FIGURE 2D)
- NOTE: DO NOT PERMIT SOLDER TO WICK UP UNDER THE INSULATION. AN ANTI-WICKING TOOL IS RECOMMENDED TO PREVENT EXCESSIVE WICKING.
- 2.8 ALLOW WIRE TO COOL
 - 2.9 INSPECT THE TINNED WIRE IN ACCORDANCE WITH STEP 3

- 3.1 INSPECT THE TINNED WIRE AS FOLLOWS
- 3.2 EXAMINE THE TINNED WIRE FOR EVIDENCE OF REJECTABLE DEFECTS
- 3.2.1 REJECTABLE DEFECTS INCLUDE INSUFFICIENT OR EXCESS SOLDER, BALLED SOLDER, FRACTURED SOLDER, PITS, HOLES, CRACKS, INCLUSIONS, GULLY SURFACE, INSULATION, OR BUCKLED WIRE STRANDS



TINNING TECHNIQUES

1. OBSERVE THE FOLLOWING PRIOR TO COMMENCING WORK

- 1.1 SOLDER SN 60 OR SN 63 TIN LEAD FORM W OR B, TYPE R, RMA, OR S CONFORMING TO QQ S-571 SHALL BE USED FOR PRETINNING
- 1.2 ONLY ROSIN FLUX SHALL BE USED IN ALL SOLDERING OPERATIONS. LIQUID ROSIN FLUX SHALL CONFORM TO MIL-F-14256 TYPE RMA, EXCEPT FOR MIL-C-1258 WHICH IS NOT REQUIRED, AND THE RESISTIVITY OF THE WATER EXTRACT SHALL BE AT LEAST 45,000 OHM CENTIMETERS.
- 1.3 SOLDERING GUNS WILL NOT BE USED AND THE USE OF A SOLDER POT IS NOT RECOMMENDED. WHEN CONDUCTORS ARE TINNED WITH A SOLDERING IRON, ONLY IRON CLAD TIPS SHALL BE USED. THE FOLLOWING NOTES APPLY TO SOLDERING IRON MAINTENANCE

1.3.1 THE SOLDERING IRON TIP SHALL ALWAYS BE CLEANED BY SCOURING IT INTO THE CERAMIC ELEMENT AND TIGHT ATTACHMENT TO THE IRON. OXIDATION SCALE SHALL NOT BE ALLOWED TO ACCUMULATE BETWEEN THE HEATING ELEMENT AND THE IRON. SHALL BE CLEANED WITH A SOFT PIPE CLEANER OR SIMILAR OBJECT WHEN TIP IS REMOVED. OR ONCE A WEEK A BRIGHT BRUSH SHOULD BE MAINTAINED ON THE TIP WORKING SURFACE TO ENSURE PROPER HEAT TRANSFER AND TO AVOID TRANSFER OF IMPURITIES TO THE SOLDER CONNECTION

1.3.2 PLATED TIPS SHALL BE CLEANED BY SCRUBBING ACTION ON AN ALUMINA SUBSTRATE (CERAMIC) WHILE THE IRON IS HOT. SOLDER AND FLUX UNTIL A BRIGHT SHINY SOLDER COATED SURFACE IS VISIBLE. FINE EMERY CLOTH MAY BE SUBSTITUTED FOR CERAMIC SUBSTRATE

1.3.3 NEVER FILE AN IRON CLAD SOLDERING TIP DURING USE AND JUST BEFORE EACH APPLICATION TO THE HEATED AND TINNED SOLDERING TIP SHOULD BE MAINTAINED BY PASSING THE TIP (WITH A ROTARY MOTION) THROUGH THE FOLDS OF THE SURFACE DRESS AND REMOVE EXCESS SOLDER FROM THE WORKING SURFACE. NEVER SHAKE OR "WHIP" THE IRON TO REMOVE EXCESS SOLDER

2. TINNING WITH SOLDERING IRON (SEE FIGURE 1)

- 2.1 CHECK THE WIRE FOR ADEQUATE STRIP LENGTH (AS REQUIRED BY OTHER DAMAGE) IF REJECTABLE DEFECTS ARE EVIDENT. REPLACE THE WIRE OR IF WIRE LENGTH IS ADEQUATE, RESTRIP IT IN ACCORDANCE WITH SHEET 5A5
- 2.2 THE SIZE OF THE SOLDERING IRON TO BE USED SHOULD BE DETERMINED FROM TABLE 1 BASED ON THE SIZE OF THE WIRE BEING TINNED

TABLE 1


WIRE SIZE	SOLDERING ELEMENT SIZE MAXIMUM WATTAGE CAPACITY	MAXIMUM TIP TEMPERATURE
0	150 W	1000°F
4	150 W	1000°F
10	75 W	800°F
16	50 W	800°F
20	35 W	800°F
24, 26	24 W	800°F

SH 132317321


FIGURE 5A13. Tinning techniques.

NOTES:
1. THIS FIGURE SUPERSEDES SHEET 5A14
OF DWG. 863-5001027.

EXCESSIVE WICKING/DAMAGED INSULATION



COLD SOLDER



BUCKLED WIRESTRANDS




FIGURE 5A14. Tinning techniques.

SH 132317322

CONNECTOR CONTACT SOLDERING TECHNIQUES

1. SOLDER SN 60 OR SN 63 TIN LEAD FORM W, TYPE R, OR RMA CONFORMING TO QQ-S-571 SHALL BE USED FOR CONNECTOR SOLDERING.
2. ONLY ROSIN FLUX SHALL BE USED IN ALL SOLDERING OPERATIONS. LIQUID ROSIN FLUX SHALL CONFORM TO MIL-C-14256, TYPE RMA, EXCEPT THAT THE COPPER MINOR TEST (SEE PARAGRAPH 3.5 OF MIL-F-14256) IS NOT REQUIRED AND THE RESISTIVITY OF THE EXTRACT SHALL BE AT LEAST 45,000 OHM-CENTIMETERS.
3. SOLDERING IRON TIPS TO BE USED FOR CONNECTOR ASSEMBLY SHALL BE IRON CLAD. THE SOLDERING IRON TIP STYLE SHOULD BE OF THE TYPE SHOWN IN FIGURE 1. THE FOLLOWING NOTES APPLY TO SOLDERING IRON TIP MAINTENANCE:
 - 3.1 THE SOLDERING IRON TIP SHALL ALWAYS BE KEPT CLEANED FOR FULL INSERTION INTO THE HEATING ELEMENT AND TIGHT ATTACHMENT TO THE IRON OXIDATION SCALE SHALL NOT BE ALLOWED TO ACCUMULATE BETWEEN THE HEATING ELEMENT AND THE IRON TIP. THE IRON TIP SHALL BE CLEANED WITH A SOFT BRUSH OR SIMILAR OBJECT WHEN THE TIP IS REMOVED, OR ONCE A WEEK A BRIGHT THIN BUT CONTINUOUS, TINNED SURFACE SHALL BE MAINTAINED ON THE TRANSFER SURFACE OF THE TIP TO AVOID TRANSFER OF IMPURITIES TO THE SOLDER CONNECTION. (SEE FIGURE 1)




FIGURE 1
SOLDERING IRON COMPONENTS

- 3.2 PLATED TIPS SHALL BE CLEANED BY SCRUBBING ACTION ON AN ALUMINA SUBSTRATE (CERAMIC) WHILE THE IRON IS HOT. THE TIP BY IMMERSION IN A BALL OF SOLDER AND FLUX UNTIL A BRIGHT SHINY SOLDER COATED SURFACE IS VISIBLE. THE SWAMP CLOTH MAY BE SUBSTITUTED FOR CERAMIC SUBSTRATE.
- 3.3 NEVER FILE AN IRON CLAD SOLDERING TIP.
- 3.4 DURING USE AND JUST PRIOR TO EACH APPLICATION, THE HEATED AND TINNED SOLDERING TIP SHOULD BE MAINTAINED BY PASSING THE TIP (WITH A ROTARY MOTION) THROUGH THE FOLDS OF A DAMP CLEANING SWAMP CLOTH. REMOVE EXCESS SOLDER FROM THE WORKING SURFACE NEVER SHAKE OR "WHIP" THE IRON TO REMOVE EXCESS SOLDER.
4. CLEANING SOLVENTS — SOLVENTS LISTED IN TABLE 1 SHOULD BE USED FOR THE REMOVAL OF GREASE, OIL AND OTHER DIRT FROM THE PARTS PRIOR TO SOLDERING, AS WELL AS FLUX RESIDUES FROM THE JOINT AREA.

SH 132317323

TABLE 1

1.1.1-TRICHLOROETHANE	O-T-620
TRICHLOROTRIFLUOROETHANE	MIL-C-81302
ISOPROPYL ALCOHOL	TT-1-735
PERCHLOROETHYLENE	O-T-236
1.1.1-TRICHLOROETHANE (VAPOR DEGREASING)	MIL-T-81533
REAGENT WATER (TYPE II)	ASTM D 1193
DETERGENT CLEANERS	AS APPROVED BY THE GOVERNMENT
5. METHOD	PROCURING ACTIVITY

- 5.1 IF REQUIRED, PLACE LENGTHS OF INSULATING SLEEVE ON EACH PRE-TINNED LEAD TO BE SOLDERED AND POSITION OUT OF THE WAY FOR SOLDERING.
 - 5.1.1 INSULATION SLEEVING SHALL MEET THE REQUIREMENTS OF MIL-I-7444, TYPE 1.
 - 5.1.2 INSULATING SLEEVES ARE NOT REQUIRED IN CLASS E OR S CONNECTORS BECAUSE THE SEALING GROMMETS COVER THE SOLDERED CONNECTION. CLASS E CONNECTORS MADE BY BENDIX REQUIRE INSULATING SLEEVES TO BE USED TO COVER THE SOLDERED CONNECTION. THE INSULATING SLEEVE SHALL NOT EXTEND INTO THE GROMMET.
 - 5.1.3 POLYVINYL CHLORIDE PLASTICS SHALL NOT BE USED.
 - 5.1.4 THE SLEEVE LENGTH SHALL COVER THE ENTIRE SOLDER TERMINAL AND OVERLAP CONDUCTOR INSULATION (FIGURE 2).
 - 5.1.4.1 TUBING SHALL BE TIGHT ON TERMINAL INITIALLY, AND WHEN REPOSITIONED AFTER CONNECTOR INSPECTION.
 - 5.1.5 HEAT SHRINK TUBING IS NOT RECOMMENDED IF USED. IT SHOULD NOT BE SHRUNK.




FIGURE 2
TUBING LENGTH

- 5.2 PRE-TIN SOLDER TERMINAL CUPS AS FOLLOWS (FIGURE 2)
 - 5.2.1 SUPPORT SOLDER TERMINAL CUP AT AN ANGLE AS SHOWN (FIGURE 3 A)
 - 5.2.2 APPLY SOLDERING IRON TIP TO THE SIDE OF SOLDERING IRON. THE SOLDERING IRON TIP SHOULD BE SELECTED FROM TABLE 2, BASED ON WRONG SIZE.

TABLE 2

WIRE SIZE	SOLDERING ELEMENT SIZE MAXIMUM WAITAGE CAPACITY	MAXIMUM TIP TEMPERATURE
0	150 W	1000°F
4	150 W	1000°F
8	150 W	1000°F
10	75 W	800°F
12	50 W	800°F
14	50 W	800°F
20	35 W	800°F
22	35 W	800°F
24-26	24 W	800°F

5.2.3 APPLY SOLDER TO THE INSIDE OF THE CUP CAVITY AS THE SOLDER MELTS AND BEGINS TO FLOW INTO THE CUP. THE SOLDERING IRON SHOULD BE WITHDRAWN FROM THE CUP AS THE SOLDER LEVEL (THE PRE-FILL LEVEL) SHOULD BE DETERMINED SUCH THAT THE CUP WILL BE PROPERLY FILLED WHEN THE TINNED WIRE IS PLACED IN THE PRE-FILLED TERMINAL CUP (FIGURE 3 B)





FIGURE 3 PRE-TINNING THE SOLDER TERMINAL CUPS

5.3 WHILE THE SOLDER CUP IS STILL HEATED, INSERT THE TINNED WIRE INTO THE CUP WIRE INTO PLACE TO ALLOW THE SOLDER TO FLOW. ENSURE THAT THE WIRE IS BOTTOMED IN THE SOLDER CUP BEFORE REMOVING THE SOLDERING IRON (FIGURE 4)

NOTE: THE USE OF AN ANTIMOXING TOOL IS RECOMMENDED. CAUTION: STEP 5.3 MUST BE ACCOMPLISHED QUICKLY TO PREVENT EXCESS WICKING UNDER THE WIRE INSULATION.

FIGURE 5A15. Connector contact soldering techniques.



NOTES:
1. THIS FIGURE SUPERSEDES SHEET 5A16 OF DWG. 803-5001027.

FIGURE 5A16. Connector contact soldering techniques.

SH 132317324

NOTES:
1. THIS FIGURE SUPERSEDES SHEET SA17
OF DWG. 803-500.1027.





FIGURE 5A17. Connector contact soldering techniques.

SH 132317325

DOD-STD-2003-5 (NAVY)
24 JUNE 1987

- 5.9 INSTALL INSULATING SLEEVING AS FOLLOWS
- 6 THE FOLLOWING DESOLDERING METHODS SHALL BE USED WHEN THE SOLDERED CONNECTION REQUIRES REPAIR, REWORK OR REPLACEMENT
- 6.1 VACUUM METHOD
- 6.1.1 INSTALL AN ANTI-WICKING TOOL IN ORDER TO PREVENT MIGRATION OF EXCESS HEAT AND SOLDER (FIGURE 6 A)
- 6.1.2 APPLY A VERY LIGHT COAT OF FLUX TO THE SOLDER CONNECTION (FIGURE 6 B)
- 6.1.3 HEAT SOLDER CUP UNTIL MOLTEN AND REMOVE WIRE
- 6.1.4 SELECT A VACUUM TOOL TIP TO PROPERLY FIT THE SOLDER CONNECTION
- 6.1.5 LOAD OR COCK THE VACUUM TOOL
- 6.1.6 PLACE THE VACUUM TOOL TIP ADJACENT TO THE SOLDERED CONNECTION (FIGURE 6 A)
- 6.1.7 HEAT THE SOLDER JOINT UNTIL MOLTEN WITH SOLDERING IRON THEN RELEASE THE VACUUM TOOL TRIGGER DEVICE (FIGURE 6 C)
- 6.1.8 REMOVE THE SOLDERING IRON AND VACUUM TOOL
- 6.1.9 EXAMINE THE CONNECTION FOR ADEQUATE SOLDER REMOVAL
- 6.1.10 REPEAT STEPS 6.1.6 THROUGH 6.1.9 UNTIL ONLY A THIN FILM OF SOLDER REMAINS
- 6.1.11 CLEAN THE CONNECTION WITH AN APPROVED SOLVENT FROM TABLE 1
- 6.2 WICKING BRAID METHOD
- 6.2.1 INS TALL AN ANTI-WICKING TOOL IN ORDER TO PREVENT MIGRATION OF EXCESS HEAT OR SOLDER
- 6.2.2 APPLY A LIGHT COAT OF LIQUID FLUX TO SOLDER CONNECTION
- 6.2.3 HEAT SOLDER CUP UNTIL MOLTEN AND REMOVE WIRE
- 6.2.4 APPLY A LIGHT COAT OF LIQUID FLUX TO THE WICKING WIRE
- 6.2.5 PLACE WICKING BRAID OVER SOLDER TO BE REMOVED
- 6.2.6 PLACE HEAT ON WICKING BRAID REMOVE HEAT AND WICKING BRAID SIMULTANEOUSLY WHEN THE SOLDER HAS SATURATED THE WICKING BRAID (FIGURE 7)
- 6.2.7 REPEAT STEPS 6.2.1 THROUGH 6.2.4 UNTIL DESOLDERING IS COMPLETE LEAVING ONLY A THIN FILM OF SOLDER ON THE CONNECTION
- 6.2.8 CLEAN CONNECTION WITH APPROVED SOLVENT FROM TABLE 1





FIGURE 7
BRAIDED WICKING WIRE SOLDER REMOVAL




FIGURE 6
DESOLDERING (VACUUM METHOD)

NOTES:

1. THIS FIGURE SUPERSEDES SHEET 5A18 OF DWG. 803-5007027.

SH 132317326

FIGURE 5A18. Connector contact soldering techniques.

NOTES:
1. THIS FIGURE SUPERSEDES SHEET 5A19 OF DWG. 803-5001027.




FIGURE 3
SOLDER HAS FLOWED

4.9 USING A HEAT GUN AND THERMAL REFLECTOR AS SPECIFIED IN MIL-K-81786, HEAT THE ASSEMBLY WHILE ROTATING TO ACHIEVE UNIFORM PENETRATION AND UNIFORM SLEEVE SHRINKAGE (FIGURE 4).




FIGURE 4
TYPICAL HEAT GUN

- 4.9.1 APPLY HEAT UNTIL THE SOLDER BRIGHTENS AND STARTS TO FLOW TOWARD THE THERMOPLASTIC INSERTS
- CAUTION USE EXTREME CARE WHILE APPLYING HEAT IN ORDER TO AVOID DAMAGING THE CONDUCTOR INSULATION DUE TO MELTING
- 4.10 HOLD THE ASSEMBLY FIRMLY UNTIL THE SOLDER JOINT IS SET
- 4.11 INSPECT THE SOLDER FERRULE
- 4.11.1 THE EXPOSED SHIELD WIRE MUST BE VISIBLE ON BOTH SIDES OF THE SOLDER RING BUT NOT EXTEND BEYOND THE HEAT SHRINKABLE INSERTS
- 4.11.2 THE FERRULE SOLDER SHOULD APPEAR CONTINUOUS AND SMOOTH WITH CONCAVE FILLET BETWEEN SHIELD AND RETURN WIRE LEAD
- 4.11.3 THE INSULATION OF THE SHIELD RETURN MUST BE ENCLOSED UNDER THE HEAT SHRINKABLE INSERT

NOTE THE SHIELD RETURN WIRE MAY EXTEND FROM THE FRONT (WHEN TERMINATING TO A CONTACT) OR REAR (WHEN TERMINATING TO ANOTHER SHIELD) OF THE SOLDER FERRULE AS REQUIRED

4.6.1 ENSURE THE SHIELD RETURN WIRE STRANDS AND SHIELD BRAID STRANDS ARE FLAT AND SMOOTH

4.7 SELECT A SOLDER FERRULE THAT MEETS THE REQUIREMENTS OF MIL-K-81786, WHICH STATES THAT THE SHIELD AND SHIELD RETURN LEAD CONNECTION (TABLE 1 IS PROVIDED AS AN EXAMPLE OF SOLDER FERRULE SIZES AVAILABLE)

4.7.1 SOLDER FERRULES CONSIST OF A HEAT SHRINKABLE SLEEVE CONTAINING A CENTER FORM OF THERMOPLASTIC SEALING RING IN EACH END (SEE FIGURE 2)

TABLE 1

PART NO	DIMENSIONS (INCH)					
	AS SUPPLIED		AFT SHRINKING		OUTSIDE DIAMETER	
	A	B	C	MIN	MAX	MAX
M81786/7-1	62 ± .06	110	125			120
M81786/7-2	62 ± .06	180	200			150
M81786/7-3	75 ± .06	280	300			210




FIGURE 2
TYPICAL SOLDER FERRULE

4.8 POSITION THE SOLDER FERRULE OVER THE ASSEMBLY SO THAT THE SOLDER RING IS CENTERED OVER THE SHIELDING AND SHIELD RETURN WIRE CONDUCTOR (SEE FIGURE 3)

CONDUCTOR SHIELD TERMINATION PROCEDURES
1. VERIFY THAT THE SHIELD BRAIDING IS NOT CUT, NICKED, OR DAMAGED

2. INSPECT ALL TERMINATION HARDWARE (I.E. RINGS, FERRULES, SOLDER SLEEVES, ETC) TO ENSURE THEY ARE THE CORRECT TYPE AND SIZE OF TARNISH, CORROSION OR DAMAGE

3. SHIELD TERMINATION SHALL BE IN ACCORDANCE WITH APPLICABLE SYSTEM WIRING TABLES AND DESIGN DATA IN ADDITION, THE FOLLOWING APPLIES

3.1 SHIELD TERMINATIONS SHALL BE STAGGERED IN ORDER TO LIMIT BUILDUP OF THE ASSEMBLY DIAMETER

3.2 STRIP TERMINATIONS SHALL NOT BE POSITIONED AS TO OCCUR UNDER CABLE CLAMPS OR WITHIN THE POTTED AREAS OF CONNECTORS

3.3 THE USE OF A HEAT BARRIER WHEN SHRINKING SOLDER SLEEVES IS PREFERRED TO MINIMIZE DAMAGE TO CONDUCTOR INSULATION

4. SHIELD TERMINATION TO A CONNECTOR USING THE SOLDER FERRULE METHOD

NOTE IF A SOLDER FERRULE OF THE CORRECT SIZE CAN NOT BE UTILIZED, TERMINATE THE SHIELD USING STEP 5

4.1 STRIP OUTER JACKET FROM CONDUCTORS STAGGERING THE DISTANCES BETWEEN EACH (SEE FIGURE 1)

4.1.1 ENSURE CONDUCTORS ARE IDENTIFIED BEFORE REMOVING INSULATION




FIGURE 1
STAGGERED SHIELD TERMINATIONS

4.2 TRIM THE SHIELDS TO 3/8 INCH LENGTH (FIGURE 3)

4.3 STRIP 3/8 INCH OF INSULATION FROM THE SHIELD RETURN WIRE IN ACCORDANCE WITH SHEET 5A5 (FIGURE 3)

4.3.1 THE SHIELD RETURN WIRE SHALL BE FABRICATED FROM INSULATED, FLEXIBLE STRANDED WIRE WITH THE SAME PHYSICAL CHARACTERISTICS AS THE CONDUCTOR

4.3.2 WHEN TERMINATED TO A CONNECTOR CONTACT THE WIRE SIZE SHALL BE GOVERNED BY THE CONTACT TO WHICH IT IS BEING ATTACHED

4.3.3 THE LENGTH SHALL ALLOW THE SHIELD RETURN WIRE TO EXTEND BEYOND THE SHIELDED CONDUCTOR AFTER ATTACHMENT TO THE SHIELD

4.4 TIN THE STRIPPED SHIELD RETURN WIRE USING A SOLDER WITH THE SAME MELTING TEMPERATURE AS THE PREFORMED SOLDER IN THE FERRULE (SEE FIGURE 5A13)

4.5 WHEN A HEAT BARRIER IS USED (PREFERRED METHOD) SPREAD THE BRAIDED SHIELD SLIGHTLY OPEN, AND SLIDE THE HEAT BARRIER UNDER THE BRAID UNTIL IT BOTTOMS

4.6 POSITION THE STRIPPED END OF THE CONDUCTOR AGAINST AND PARALLEL TO THE EXPOSED SHIELDING

FIGURE 5A19. Conductor shield termination procedures.

NOTES:
1. THIS FIGURE SUPERSEDES SHEET 5A20
OF DWG. 803-5001027.

- 5.6 STRIP INSULATION TO MATCH THE LENGTH OF THE SHIELD PREPARED FROM THE SHIELD RETURN WIRE IN ACCORDANCE WITH FIGURE 5A6
- 5.6.1 THE SHIELD RETURN SHALL BE FABRICATED FROM INSULATED, FLEXIBLE, STRANDED WIRE WITH THE SAME PHYSICAL CHARACTERISTICS AS THE CONDUCTOR
- 5.6.2 WHEN TERMINATED TO A CONNECTOR CONTACT THE WIRE SIZE SHALL BE GOVERNED BY THE CONTACT TO WHICH IT IS BEING ATTACHED
- 5.6.3 THE LENGTH SHALL ALLOW THE SHIELD RETURN WIRE TO EXTEND BEYOND THE CONDUCTOR AFTER ATTACHMENT TO THE SHIELD DUCTOR OUTER JACKET (IF PRESENT) AND BRAIDED SHIELD (FIGURE 5.8)
- 5.8 ROTATE THE CONDUCTOR WITH A CIRCULAR MOTION TO FLARE OUT THE BRAID (FIGURE 5.C)
- 5.9 PLACE THE INNER FERRULE UNDER THE SHIELD BRAID SO THAT 1/16 INCH OF SLEEVE STICKS OUT BEYOND THE BRAID (FIGURE 5.D)
- 5.9.1 ENSURE THE SHIELD RETURN WIRE STRANDS AND SHIELD BRAID STRANDS ARE FLAT AND SMOOTH
- 5.10 INSERT THE STRIPPED END OF THE SHIELD RETURN WIRE UNDER THE OUTER FERRULE AND PUSH FORWARD OVER THE SHIELD BRAID AND INNER FERRULE UNTIL FLUSH WITH THE BRAID AND INNER FERRULE
- NOTE: THE SHIELD RETURN WIRE MAY EXTEND FROM THE FRONT (WHEN TERMINATED TO A CONTACT) OR REAR (WHEN TERMINATED TO ANOTHER SHIELD) OF THE OUTER FERRULE AS REQUIRED
- 5.11 SELECT A CRIMPING TOOL AND DIES MEETING THE REQUIREMENTS OF MIL-C-22520/9 OR MIL-C-22520/10
- 5.11.1 TEST THE CRIMPING TOOL USING AN INSPECTOR'S CRIMP GAGE MEETING THE REQUIREMENTS OF MIL-C-22520/6
- 5.12 PLACE THE FERRULE ASSEMBLY INTO THE CRIMPING TOOL AND CRIMP UNTIL THE HANDLE RELEASES
- 5.13 VISUALLY INSPECT THE CRIMPED FERRULE ASSEMBLY FOR FRACTURES OR SPALLING. ENSURE THE INTEGRITY OF THE CONNECTION BY GIVING THE SHIELD RETURN WIRE A LIGHT FINGER TUG. REJECT ANY FERRULES THAT DO NOT MEET THE ABOVE CRITERIA
- 5.14 TERMINATE THE SHIELD RETURN WIRE WITH OTHER CONDUCTORS IN ACCORDANCE WITH THE APPLICABLE CONNECTOR ASSEMBLY PROCEDURE
- 6 TIEING BACK AND INSULATION OF SHIELDS
- 6.1 WHEN SYSTEM DESIGN DOES NOT REQUIRE CONTINUITY OF THE CONDUCTOR SHIELD THROUGH A CONDUCTOR OR TO GROUND THE SHIELD SHALL BE TERMINATED AS FOLLOWS
- 6.1.1 STRIP THE CONDUCTOR INSULATION TO THE LENGTH REQUIRED BY THE APPLICABLE CONNECTOR ASSEMBLY PROCEDURE WITH FIGURE 5A5
- 6.1.2 TRIM THE SHIELD TO A LENGTH OF 3/8 INCH
- 6.1.3 COMB OUT THE SHIELD BRAID USING A SPUDGER (OR EQUIVALENT)
- 6.1.4 FOLD THE SHIELD BACK OVER THE CONDUCTOR JACKET. ENSURE THAT THE SHIELD STRANDS ARE FLAT AND SMOOTH
- 6.1.5 CENTER A LENGTH OF INSULATION SLEEVE OVER THE FOLDED BACK SHIELD AND SHRINK IN PLACE

TABLE 2 SHIELDED WIRE TERMINATIONS INNER FERRULE SIZES

PART NO.	COLOR CODE	INNER FERRULE (NOMINAL) ID	OD
MS 21981	TIN	0.046	0.070
046	YELLOW	0.068	0.093
058	RED	0.063	0.088
063	SILVER	0.071	0.096
060	ORANGE	0.080	0.114
090	PURPLE	0.096	0.119
101	YELLOW	0.101	0.124
115	TIN	0.109	0.131
124	GREEN	0.124	0.145
134	ORANGE	0.128	0.152
158	BLUE	0.149	0.179
165	RED	0.185	0.218
175	GREEN	0.175	0.215
187	YELLOW	0.187	0.227
204	BLUE	0.184	0.225
219	ORANGE	0.219	0.248
225	YELLOW	0.225	0.266
232	RED	0.232	0.263
250	GREEN	0.250	0.281
266	TIN	0.266	0.297
275	ORANGE	0.275	0.306
281	YELLOW	0.281	0.331
287	TIN	0.287	0.327
312	PURPLE	0.312	0.335
375	BLUE	0.375	0.406

5.5 ADD 1/16 INCH TO THE OUTER DIAMETER OF THE INNER FERRULE SELECTED IN STEP 5.4 TO OBTAIN INSULATED OUTER FERRULE FROM TABLE 3 WHICH MEETS THE REQUIREMENTS OF MIL-F-21508 AND MS18121 WITH THE ABOVE DIMENSION AS THE MINIMUM INNER DIAMETER

TABLE 3 SHIELDED WIRE TERMINATIONS INSULATED OUTER FERRULE SIZES

PART NO.	COLOR CODE	INNER FERRULE (NOMINAL) ± .005
MS 18121	TIN	0.101
101	BLUE	0.148
149	PURPLE	0.156
156	YELLOW	0.177
175	BLUE	0.187
187	ORANGE	0.205
199	TIN	0.205
205	YELLOW	0.219
219	GREEN	0.219
225	PURPLE	0.225
232	PURPLE	0.232
261	YELLOW	0.261
275	TIN	0.275
281	PURPLE	0.281
287	BLUE	0.287
312	YELLOW	0.297
327	TIN	0.327
348	ORANGE	0.348
359	PURPLE	0.359
405	YELLOW	0.375
415	BLUE	0.415
460	TIN	0.460
500	GREEN	0.500

FIGURE 5A20. Connector shield termination procedures.

- 4.11.4 THE THERMOPLASTIC INSERT SHOULD COLLAPSE OVER THE SHIELD RETURN WIRE AND CONDUCTOR SHIELDING
- 4.11.5 THE FERRULE SLEEVE MUST NOT BE CUT. SPLIT OR HAVE STRANDS PROTRUDING
- 4.12 TERMINATE SHIELD RETURN WIRE WITH OTHER CONDUCTORS IN ACCORDANCE WITH THE APPLICABLE SYSTEM CONNECTION ASSEMBLY PROCEDURE
- 5 SHIELD TERMINATION TO A CONNECTOR USING THE TWO-PIECE CRIMP FERRULE METHOD
- 5.1 STRIP OUTER JACKET FROM CONDUCTORS, STRAGGLING THE DISTANCES BETWEEN EACH (SEE FIGURE 1)
- 5.2 TRIM THE SHIELDS 1/2 TO 3/4 INCH LENGTH (FIGURE 5.A)

- METALLIC SHIELDING BRAID



CONDUCTOR INSULATION 1 2 3 4" JACKET OUTER FERRULE



- ROTATE CONDUCTOR TO SPREAD SHIELDING BRAID



- INNER FERRULE PARTIALLY INSERTED



INSERT SHIELD RETURN LEAD AND SHIELD



INNER FERRULE FLUSH WITH OUTER



CONDUCTOR INSULATION - CRIMP SHIELD RETURN LEAD



FIGURE 5

TWO-PIECE GROUNDING CONNECTION FOR TERMINATING SHIELDED WIRE

- 5.3 DETERMINE THE MAXIMUM CONDUCTOR DIAMETER (SEE INDIVIDUAL LEAD STRIPPING TECHNIQUES, TABLE 1, FIGURE 5A5) AND ADD 0.005 INCH.
- 5.4 SELECT THE INNER FERRULE FROM TABLE 2 HAVING THE INNER DIAMETER NEAREST BUT LARGER THAN THE DIMENSION CALCULATED IN STEP 5.3 ENSURE THE INNER FERRULE MEETS THE REQUIREMENTS OF MIL-F-21508 AND MS21981

SH 132317328

GROSS SHIELD TERMINATION PROCEDURES
OBSERVE THE FOLLOWING BEFORE TERMINATING THE GROSS SHIELD

- 1.1 VERIFY THAT THE SHIELD BRAIDING IS NOT CUT, NICKED, OR SCRATCHED
- 1.2 INSPECT ALL SHIELD TERMINATION HARDWARE (RFI RINGS, FERRULES, ETC.) TO ENSURE THEY ARE THE CORRECT TYPE, SIZE AND ARE FREE OF TARNISH, CORROSION, OR DAMAGE
2. GROSS SHIELD TERMINATION SHALL BE IN ACCORDANCE WITH APPLICABLE SYSTEM WIRING TABLES AND DIAGRAMS UTILIZING ONE OF THE METHODS OUTLINED IN THIS APPENDIX
3. METHOD 1 — FLOATING SHIELD METHOD
- 3.1 THIS METHOD IS USED WHEN THE SYSTEM DESIGN DOES NOT REQUIRE CONTINUITY OF THE SHIELD THROUGH THE CONNECTOR OR GROUNDING OF THE SHIELD
- 3.2 CAREFULLY COMB OUT THE SHIELD USING A SPOUDGER (OR EQUIVALENT) (FIGURE 1)




FIGURE 1
COMBED OUT GROSS SHIELD

- 3.3 SEPARATE THE UNBRAIDED SHIELD WIRES INTO THREE EQUAL GROUPS
- 3.4 TWIST EACH GROUP INTO A TIGHT SELF-CONTAINED BUNDLE (PIGTAIL) (FIGURE 2)



FIGURE 2
GROSS SHIELD PIGTAILS

- 3.5 CUT THE PIGTAILS 3/4 OF AN INCH FROM THE CABLE JACKET (FIGURE 3)
- NOTE: DO NOT TIN THE PIGTAILS. LEAVE FOR POSSIBLE RFI HOOKUP AT A LATER DATE.



FIGURE 3
TRIMMED PIGTAILS

- 3.6 COVER EACH PIGTAIL WITH A 1 INCH LENGTH OF APPROPRIATELY SIZED SHRINK SLEEVING CONFORMING TO MIL-1-23053, CLASS 1 (FIGURE 4)




FIGURE 4
COVERING THE PIGTAILS

- 3.7 APPLY HEAT TO SHRINK THE SLEEVING. PINCH THE ENDS OF THE SHRINK TUBING SHUT AS HEAT IS APPLIED TO CREATE AN END SEAL (FIGURE 4)

NOTE: WHEN HEATING THE SHRINK TUBING, KEEP HEAT AWAY FROM THE CABLE AS MUCH AS POSSIBLE TO PREVENT MELTING THE CABLE JACKET AND INSULATION

- 3.8 TRIM THE UNDERLYING NYLON WRAP LEAVING 1/2 INCH TO PROTECT THE INDIVIDUAL CONDUCTOR INSULATION
- 3.9 PLACE A 3/4 INCH LENGTH OF SHRINK SLEEVING (DIAMETER TO EXCEED CABLE DIAMETER) OVER THE CABLE JACKET AND PIGTAILS
- 3.10 APPLY HEAT AND SHRINK THE SLEEVING PRIOR TO THE RFI ASSEMBLY. THE APPLICABLE CONNECTOR ASSEMBLY PROCEDURE (FIGURE 5) DO NOT SHRINK AT THIS TIME




FIGURE 5

4. METHOD 2 — GROSS SHIELD ATTACHED TO CONNECTOR CONTACT

- 4.1 PREPARE THE GROSS SHIELD IN ACCORDANCE WITH THE PROCEDURE FOR 3.6 ENSURING ONE PIGTAIL IS LEFT EXPOSED FOR CONNECTION TO THE SHIELD RETURN WIRE
- 4.2 CUT A LENGTH OF SHIELD RETURN WIRE 2 INCHES LONGER THAN THE EXPOSED CONDUCTORS
- 4.2.1 SHIELD RETURN WIRES SHALL BE FABRICATED FROM INSULATED FLEXIBLE STRANDED TYPE WIRE WITH THE SAME PHYSICAL CHARACTERISTICS AS THE SHIELDED CABLE
- 4.2.2 THE WIRE SIZE SHALL BE DICTATED BY THE CONTACT TO WHICH IT WILL BE CONNECTED (SEE APPLICABLE WIRING TABLE AND CONNECTOR ASSEMBLY PROCEDURE)
- 4.3 STRIP 3/4 OF AN INCH OF INSULATION FROM THE SHIELD RETURN WIRE IN ACCORDANCE WITH FIGURE 5A5
- 4.4 TERMINATE THE SHIELD RETURN WIRE AS FOLLOWS
- 4.4.1 BUTT THE INSULATION TO WITHIN 1/16 INCH OF THE CUT END OF THE PIGTAIL. WRAP THE WIRE STRANDS INTO THE LAY OF THE PIGTAIL WIRE STRANDS. (SEE FIGURE 7)



TWIST WIRE AROUND PIGTAIL IN A SMOOTH CONTINUOUS LAY



FIGURE 6
COMBINING SHIELD RETURN WIRE AND GROSS SHIELD PIGTAIL

NOTES:
1. THIS FIGURE SUPERSEDES SHEET 5A22 OF DWG. 803-5001027.

FIGURE 5A22. Gross shield termination procedures.

5.14 FLARE THE GROSS SHIELD OVER THE TAPERED END OF THE INNER FERRULE.

5.15 GENTLY FORCE THE CABLE TOWARD THE CONNECTOR PLUG UNTIL THE SHIELD COVERS THE TAPERED SURFACE ON THE INNER FERRULE.

5.16 INSERT THE OUTER FERRULE (RFI RING) (PC 4) INTO THE SLEEVE ASSEMBLY WHILE APPLYING FORWARD PRESSURE ON THE CABLE.

5.17 ASSEMBLE THE REMAINING BACKSHELL COMPONENTS IN ACCORDANCE WITH THE APPLICABLE CONNECTOR ASSEMBLY PROCEDURE.

5.4 REMOVE THE SLEEVE ASSEMBLY AND REPOSITION THE SHIELD TO THE POSITION WHERE IT DOES NOT INTERFERE WITH SUBSEQUENT CONNECTOR ASSEMBLY.

5.5 TRIM THE SHIELD TO THE DISTANCE MEASURED IN STEP 5.3.

5.6 COMPLETE ALL STEPS IN THE APPLICABLE CONNECTOR ASSEMBLY PROCEDURE UP TO THE BACKSHELL ASSEMBLY SECTION.

5.7 MEASURE THE DISTANCE FROM THE CONNECTOR AFT END TO THE CABLE JACKET.

5.8 MEASURE THE DISTANCE FROM THE FORWARD END OF THE SLEEVE ASSEMBLY TO A POINT MIDWAY ON THE SHIELD. THE DISTANCE FROM THE FORWARD END OF THE INNER FERRULE MUST BE BOTTOMED AGAINST THE SLEEVE SHOULDER.

5.9 DETERMINE THE DESIRED LENGTH OF THE GROSS SHIELD BY SUBTRACTING THE MEASUREMENT OF STEP 5.7 FROM THE MEASUREMENT OF STEP 5.8.

5.10 TRIM THE GROSS SHIELD TO THE DESIRED LENGTH.

5.11 ASSEMBLE SLEEVE: ASSEMBLY (PC 2) TO THE CONNECTOR PLUG (PC 1) AND TIGHTEN TORQUE TO A VALUE ESTABLISHED FOR THE CONNECTOR BEING USED. USE THE TORQUE WRENCH TO APPLY THE TORQUE. USE A WRENCH (SEE APPLICABLE CONNECTOR ASSEMBLY PROCEDURE).

5.12 SLIDE INNER FERRULE (RFI BELL) (PC 3) INTO SLEEVE ASSEMBLY AND SEAT ON INNER SHOULDER.

5.13 IF THE APPLICABLE WIRING TABLES CALL FOR INDIVIDUAL CONDUCTOR SHIELDS TO BE GROUNDED TO THE BACKSHELL, PUSH THE SHIELDS THROUGH THE GROSS SHIELD. COMBINE THE ENDS OF THE CABLE GROSS SHIELD TO FORM ONE. INDIVIDUAL SHIELD STRANDS WITH THE GROSS SHIELD.

4.4.2 SOLDER THE SHIELD RETURN WIRE TO THE SHIELD. SMOOTH AND SHINNY WITH A CONCAVE FILLET BETWEEN STRANDS. SEE SHEET 5A10 FOR ACCEPTANCE CRITERIA.

4.4.3 CLEAN THE SOLDERED CONNECTION WITH APPROVED SOLVENT.

4.4.4 COVER THE SOLDERED CONNECTION WITH APPROPRIATELY SIZED SHRINK TUBING. CONFORMING TO MIL-1-2003, CLASS 1 OF SUFFICIENT LENGTH TO COVER THE SOLDERED CONNECTION AND SOLDER CONNECTION. SHRINK THE TUBING DIRECTING HEAT AWAY FROM CONDUCTORS TO PREVENT DAMAGE.

4.5 STRAIN RELIEF

4.5.1 PLACE A 1/2 INCH LENGTH OF APPROPRIATELY SIZED SHRINK TUBING OVER THE SOLDERED CONNECTION. LOOP THE TUBING THROUGH THE STRAIN RELIEF POINTS TO PROVIDE STRAIN RELIEF FOR THE SHIELD RETURN WIRE (FIGURE 7).

4.5.2 ALTERNATE METHOD: FOLD BACK THE SHIELD RETURN WIRE TO FORMING A STRAIN RELIEF USING LACING.

NOTES:
1. THIS FIGURE SUPERSEDES SHEET 5A23 OF DWG. 803-5001027.





FIGURE 7
FORMING THE STRAIN RELIEF

4.6 PLACE A 3/4 INCH LENGTH OF SHRINK SLEEVING OVER THE SOLDERED CONNECTION. SLIDE THE SLEEVING OVER THE CABLE JACKET AND PIGTAILS.

4.7 APPLY HEAT AND SHRINK THE SLEEVING PRIOR TO BACKSHELL ASSEMBLY IN THE APPLICABLE CONNECTOR ASSEMBLY PROCEDURE.

4.8 TERMINATE THE SHIELD RETURN WIRE WITH OTHER CONDUCTORS IN ACCORDANCE WITH THE APPLICABLE CONNECTOR ASSEMBLY PROCEDURE.

5. METHOD 3 — GROSS SHIELD GROUNDED TO BACKSHELL

NOTE THE FOLLOWING ASSEMBLY PROCEDURE IS BASED ON THE NOMENCLATURE AND HARDWARE CONFIGURATION SHOWN IN THIS FIGURE. MINOR DEVIATIONS MAY OCCUR AND CAUSE MINOR DEVIATION FROM THIS PROCEDURE.

5.1 CAREFULLY COMB OUT THE GROSS SHIELD USING A SOFT INSTRUMENT (SPUDGER OR EQUIVALENT).

5.2 ASSEMBLE SLEEVE ASSEMBLY (PC 2) TO THE CONNECTOR PLUG (PC 1) AND TIGHTEN.

5.3 MEASURE THE DISTANCE FROM THE CONNECTOR END TO THE AFT END OF THE SLEEVE ASSEMBLY.

FIGURE 8
GROSS SHIELD GROUNDED TO BACKSHELL

FIGURE 8
GROSS SHIELD GROUNDED TO BACKSHELL

FIGURE 5A23. Gross shield termination procedures.

CONNECTOR LOCKWIRING TECHNIQUES

1 THE FOLLOWING PRACTICES SHALL BE OBSERVED WHEN LOCKWIRING CONNECTORS

1.1 CONNECTORS SHALL BE LOCKWIRED WITH 0.020 INCH DIAMETER WIRE CONFORMING TO MS20995-NC20

1.2 CONNECTORS SHALL BE LOCKWIRED INDIVIDUALLY

1.3 LOCKWIRE SHALL NOT BE REUSED

1.4 DAMAGED LOCKWIRE SHALL NOT BE USED

1.5 BACKSHELLS WITH HOLES IN THE COUPLING RING SHALL BE LOCKWIRED

2 CONNECTORS MUST BE LOCKWIRED WHEN USING 45° OR 90° ADAPTER ASSEMBLIES (BACKSHELLS) TO PREVENT THE LOOSENING OF THE ADAPTER COUPLING RING (SEE FIGURE 1)




FIGURE 1
LOCATION OF LOCKWIRE

3 LOCKWIRE IS NOT REQUIRED IF THE COUPLING NUT HAS SET SCREWS

4 THE FOLLOWING PROCEDURE SHALL BE USED TO LOCKWIRE CONNECTORS (SEE FIGURE 2)

4.1 THE PARTS SHALL BE LOCKWIRED USING A DOUBLE TWIST IN SUCH A MANNER THAT WHEN THE COUPLING COLOUR LOOSENS THE LOCKWIRE SHALL BE PUT IN TENSION




FIGURE 2
LOCKWIRING THE CONNECTOR

4.2 WHEN THE BACKSHELL DOES NOT HAVE A HOLE PROVIDED AND THERE IS NO OTHER PROVISION FOR LOCKWIRING THE CONNECTOR, A CRIMP HOSE CLAMP (TYPE F OR EQUIVALENT) SHOULD BE INSTALLED TO SECURE THE LOCKWIRE AS DEPICTED IN FIGURE (3)




FIGURE 3
USING A HOSE CLAMP

4.3 MEASURE THE DISTANCE FROM THE ADAPTER COUPLING RING TO THE BACKSHELL TAB (OR HOSE CLAMP) AND ADD 2 INCHES

4.4 CUT THE LOCKWIRE TWICE THE TOTAL DIMENSION MEASURED IN STEP 4.3

4.5 THREAD THE LOCKWIRE THROUGH THE SELECTED ADAPTER COUPLING RING HOLE. PULL ENDS TOGETHER TO EVEN OUT THE LEGS OF LOCKWIRE

4.6 USING WIRE TWISTER PLIERS CONFORMING TO FED SPEC 440, TWIST THE LOCKWIRE TO FORM AN ADAPTER COUPLING RING HOLE TO BACKSHELL SAFETY TAB (OR HOSE CLAMP) FORMING 6 TO 8 TURNS PER INCH

NOTES:

1. THIS FIGURE SUPERSEDES SHEET 5A24 OF DWG. 903-5001027.

4.7 THREAD ONE LOCKWIRE THROUGH THE BACKSHELL LOCKWIRE TAB (OR HOSE CLAMP) AND PULL TIGHT. EXTRA LOCKWIRE LEAVING A PIGTAIL OF 1/4 TO 1/2 INCH (3 TO 6 TWISTS) AND BEND BACK OR UNDER TO PREVENT IT FROM BECOMING A SNAG

4.8.1 ENSURE THE LOCKWIRE IS INSTALLED AND TWISTED SO THAT THE LOOP AT THE SAFETY HOLES STAY DOWN AND DOES NOT TEND TO LOCK UP THE HOLES AND LEAVE A SLACK LOOP (FIGURE 3)

4.9 WHEN OPTIONAL EXTENSIONS ARE USED, THE COUPLING NUT ON THE OPTIONAL EXTENSION MUST ALSO BE SECURED BY LOCKWIRE

4.10 IF THE CLAMP ASSEMBLY HAS A SAFETY WIRE HOLE INSTALLED, INSTALL LOCKWIRE BETWEEN IT AND THE ADAPTER ASSEMBLY (SEE FIGURE 4)

4.11 ENSURE THE HOSE CLAMP (IF PRESENT) IS SECURELY TIGHTENED




FIGURE 4
LOCKWIRING THE CLAMP ASSEMBLY

FIGURE 5A24. Connector lockwiring.

NOTES:
1. THIS FIGURE SUPERSEDES SHEET 5A/25
OF DWG. 903-5001027.




FIGURE 2

GROSS SHIELD INTERFERENCE REMOVAL

- 3.4 REMOVE THE CABLE JACKET TO THE PREDETERMINED LENGTH AS FOLLOWS
NOTE: ENSURE THE CUT DOES NOT COMPLETELY PENETRATE THE JACKET
 - 3.4.1 SCORE THE CIRCUMFERENCE OF THE JACKET WITH A MULTI-PURPOSE CUTTER (OLFA 300 OR EQUIVALENT)
 - 3.4.2 SCORE THE JACKET PIECE TO BE REMOVED ALONG ITS LENGTH WITH A MULTI-PURPOSE CUTTER
 - 3.4.3 REMOVE THE JACKET PIECE WITH NEEDLE NOSE PLIERS
 - 3.5 DO NOT DAMAGE GROSS SHIELD (IF APPLICABLE) OR CONDUCTOR INSULATION
 - 3.6 PROVIDE A LENGTH OF HEAT SHRINKABLE SLEEVING CONFORMING TO THE REQUIREMENTS OF MIL-1-23053/5 CLASS 1 OF THE PROPER DIAMETER (TABLE II) THAT WILL COVER THE CABLE CONDUCTORS, ENSURING THE FOLLOWING:
 - 3.6.1 A MINIMUM OF ONE INCH OF OVERLAP AT THE CABLE JACKET.
 - 3.6.2 SLEEVING EXTENDS PAST THE SEALING GLAND IN THE BACKSHELL WHEN THE BACKSHELL IS MATED TO THE CONNECTOR.
 - NOTE: ENSURE LONGITUDINAL SHRINKAGE IS TAKEN INTO CONSIDERATION WHEN MAKING THE ABOVE DETERMINATION
 - 3.7 CUT AND REMOVE ANY FILLER OR CORE USED TO MAKE UP THE CABLE CONSTRUCTION
NOTE: IF THE GROSS SHIELD INTERFERES WITH THIS STEP, PUSH THE BRAIDED SHIELD BACK ON THE CABLE AS DEPICTED IN FIGURE 2, WHILE REMOVING CABLE FILLERS
- CABLE TRANSFLEXING PROCEDURE
1. CABLE TRANSFLEXING SHOULD BE ACCOMPLISHED ONLY AFTER PROPER APPROVAL HAS BEEN GRANTED
 2. THE PURPOSE OF TRANSFLEXING A CABLE IS TO ALLOW THE CABLE TO EXCEED THE LENGTH OF THE ORIGINAL MECHANICAL AND ENVIRONMENTAL PROTECTION TO THE INDIVIDUAL CONDUCTORS
 3. CABLES SHALL BE TRANSFLEXED IN ACCORDANCE WITH THE FOLLOWING PROCEDURE (SEE FIGURE 1)
 - 3.1 PERFORM STEPS 1 AND 2 OF THE APPLICABLE CONNECTOR ASSEMBLY PROCEDURE. DO NOT PROCEED BEYOND STEP 5 OF CABLE PREPARATION (SHEET 5A1)
 - 3.2 DETERMINE THE LENGTH OF CABLE TO BE TRANSFLEXED. THE LENGTH SHALL NOT EXCEED THE DISTANCE AS MEASURED FROM THE CABLE END TO THE POINT WHERE THE CABLE BREAKS OUT OF ITS LAST HANGER (18 INCHES MAXIMUM).
 - 3.3 IF THE CABLE IS ARMORED REMOVE THE ARMOR
 - 3.3.1 1. 2 INCHES BEYOND THE LENGTH DETERMINED IN STEP 3.2 USING A CABLE STRIPPER MEETING THE REQUIREMENTS OF MIL-1-23053/5 CLASS 1 OF THE PROPER DIAMETER. THE ARMOR SHALL NOT INTERFERE WITH THE ENVIRONMENTAL SEAL BETWEEN THE CABLE JACKET AND TRANSFLEX SLEEVING
 - 3.3.1.1 INSTALL A 1/2 INCH PIECE OF HEAT SHRINK SLEEVING CENTERED OVER THE ARMOR-JACKET JUNCTION AND SHRINK IN PLACE
 - 3.3.1.1.1 HEAT SHRINK SLEEVING SHALL MEET THE REQUIREMENTS OF MIL-1-23053/5 CLASS 1




FIGURE 1
CABLE TRANSFLEXING

FIGURE 5A25. Cable transflexing procedure.

SH 132317332

NOTES:
1. THIS FIGURE SUPERSEDES SHEET 5A28 OF DWG. 803-5001027.

- 3.20 CONTINUE APPLYING HEAT IN THE DIRECTION OF THE CABLE JACKET REMOVING HEAT AS THE SLEEVING ASSUMES THE CONFIGURATION OF THE CABLE CONDUCTORS.
- 3.21 WHEN THE SLEEVING HAS RECOVERED SUFFICIENTLY TO SEAL WITH THE CABLE JACKET AND EXCESS ADHESIVE APPEARS AT THE END, DISCONTINUE THE HEATING PROCESS.
CAUTION: DO NOT USE SOLVENT FOR CLEANING. OFF EXCESS ADHESIVE. DOING SO COULD CAUSE MIGRATION OF THE SOLVENT INTO THE BONDING LINE AREA AND RESULT IN A POTENTIAL BOND FAILURE.
- 3.22 WIPE OFF EXCESS ADHESIVE WITH A CLEAN CLOTH.
- 3.23 ASSEMBLE THE BACKSHELL COMPONENTS TO THE CONNECTOR IN ACCORDANCE WITH THE APPLICABLE CONNECTOR ASSEMBLY PROCEDURE.




FIGURE 4
CABLE JACKET PREPARATION

3.18 REMOVE THE TEMPORARY TIES APPLIED IN STEP 3.11 AND POSITION THE HEAT SHRINKABLE TUBING OVER THE CABLE CONDUCTORS ENSURING THAT THE TUBING OVERLAPS THE CABLE JACKET BY ONE INCH AND COMPLETELY COVERS THE ENVIRONMENTAL SEAL AREA. WHILE THE TUBING SURVIVORS A HEAT GUN TO SHRINK THE TUBING SURROUNDING THE CONDUCTORS. THE SHRINKABLE TUBING UNDER THE BACKSHELL COMPONENTS DURING POSITIONING.

3.19 POSITION THE BACKSHELL COMPONENTS AWAY FROM THE CONNECTOR END. USING A HEAT GUN, SHRINK THE TUBING STARTING FROM THE CONNECTOR END WHEN CLEAR OF THE AREA THAT WILL BE OCCUPIED BY THE BACKSHELL. SLIDE THE BACKSHELL COMPONENTS TO THE CONNECTOR END.

3.12 DISASSEMBLE AND RELOCATE THE BACKSHELL AND CLAMP COMPONENTS TO THE CABLE VERIFY THAT ALL PARTS ARE INCLUDED AND THE CORRECT ORDER AND ORIENTATION ASSEMBLE THE BACKSHELL AND LOCATE IT ON THE CABLE SO THAT IT WILL NOT INTERFERE WITH CONNECTOR WIRING.

3.13 CONTINUE ASSEMBLING THE CONNECTOR IN ACCORDANCE WITH THE APPLICABLE CONNECTOR ASSEMBLY PROCEDURE COMMENCING WITH STEP 12 OF FIGURE 5A1.

NOTE: TERMINATE THE GROSS SHIELD (IF APPLICABLE) INSIDE OF THE BACKSHELL FORWARD OF AND NOT TO INTERFERE WITH THE ENVIRONMENTAL SEAL.

NOTE: DO NOT ASSEMBLE THE BACKSHELL TO THE CONNECTOR UNTIL SEQUENCED IN THIS PROCEDURE.



FIGURE 3
TERMINATION OF SPARE CONDUCTORS

- 3.14 FOLD SPARE CONDUCTORS BACK AND INSULATE EXPOSED ENDS WITH A 1/2-INCH LENGTH OF HEAT SHRINK TUBING (FIGURE 3)
- 3.14.1 POSITION GROMMET FOLLOWER IF APPLICABLE
- 3.15 IF CONNECTOR HAS INDIVIDUAL LEAD SEALING GROMMET, SLIDE DOWN OVER CONDUCTORS AND SEAL.
- 3.15.1 CLEAN THE AREA WITH AN APPROVED SOLVENT FROM TABLE 2

TABLE 2

APPROVED SOLVENT	AS APPROVED BY THE GOVERNMENT PROCURING ACTIVITY
1. 1. 1 TRICHLOROETHANE O-T-620	
TRICHLOROTRIFLUORETHANE MIL-C-81302	
ISOPROPYL ALCOHOL	
1. 1. 1 TRICHLOROETHANE O-T-236	
PERCHLOROETHYLENE MIL-T-81533 (VAPOR DEGREASING)	
REAGENT WATER (TYPE II)	ASTM D-1193
DETERGENT CLEANERS	

3.16 ABRABE BONDING SURFACE OF CABLE JACKET WITH NO. 320 EMERY CLOTH OR EQUIVALENT (FIGURE 4). WHICH WILL EFFECTIVELY SEAL THE ENCLOSED AREA AGAINST MOISTURE (GEN. EQUIVALENT). USE ADHESIVE MMM-A-189 OR EQUIVALENT.

3.17 APPLY ADHESIVE TO THE ABRATED AREA OF THE CABLE JACKET

SH 132317333

TABLE 1

MILITARY PART NO	AS SUPPLIED I.D. MIN	AFTER UNRESTRICTED SHRINKAGE I.D. MAX	WALL THICKNESS
CLASS 1			
M23063/5-101	046	023	016 ± .003
-102	093	031	017 ± .001
-104	125	046	020 ± .003
-106	193	062	020 ± .003
-107	250	093	020 ± .003
-108	375	187	025 ± .003
-109	500	250	025 ± .003
-110	750	375	030 ± .003
-111	1,000	500	035 ± .006
-112	2,000	1,000	040 ± .006
-113	3,000	1,500	050 ± .006
-114	4,000	2,000	055 ± .006
CLASS 1 OVEREXPANDED			
-115	1,000	275	045 ± .006
-116	2,000	550	045 ± .006
-117	3,000	810	045 ± .006
-118	4,000	1,050	045 ± .006
-119	2,570	452	045 ± .006
-120	3,000	840	045 ± .006
-121	3,750	930	045 ± .006
-122	4,500	1,450	045 ± .006
-123			
M23063/10-001	125	071	200 ± .006
-002	250	143	035 ± .010
-003	375	214	040 ± .010
-004	500	286	048 ± .015
-005	750	429	052 ± .015
-006	1,000	572	062 ± .015
-007	1,500	858	070 ± .020
-008	2,000	1,144	087 ± .020
-009	2,500	1,430	095 ± .020
-010	3,000	1,716	107 ± .020
-011	3,500	2,002	110 ± .020
-012	4,000	2,288	110 ± .025
-014	4,000	2,280	110 ± .025

FIGURE 5A26. Cable transflexing procedure.

DOD-STD-2003-5 (NAVY)
24 JUNE 1987

CABLE BIFURCATION PROCEDURE

1. CABLE BIFURCATION IN THIS PROCEDURE IS THE MATING OF TWO CABLES WITH A SINGLE CONNECTOR. THIS PROCEDURE SHALL ENSURE THAT AN ENVIRONMENTAL SEAL EXISTS AND THAT ADEQUATE STRAIN RELIEF IS PROVIDED (FIGURE 1)
2. THE PROCEDURE FOR MATING TWO CABLES WILL BE AS FOLLOWS:
 - 2.1 DETERMINE THE LENGTH FROM THE CONNECTOR WHERE THE MATING OF THE TWO CABLES WILL OCCUR.
 - 2.1.1 THIS DISTANCE SHALL NOT EXCEED THE DISTANCE FROM THE BREAK OFF OF THE TWO CABLES FROM THEIR LAST WIREWAY HANGER (18 INCHES MAXIMUM)
 - 2.2 PREPARE EACH CABLE IN ACCORDANCE WITH STEP 5A1 STEPS 1 THROUGH 5
 - 2.3 REMOVE THE CABLE JACKET OF EACH CABLE IN ACCORDANCE WITH FIGURE 5A1 STEP 9.5 TO THE POINT OF JUNCTURE OF THE TWO CABLES.
 - 2.3.1 IF ONE OR BOTH OF THE CABLES IS ARMORED REMOVE THE ARMOR FROM THE CABLE(S) AT A POINT 2 INCHES BEYOND THE POINT OF JUNCTURE USING A CABLE STRIPPER (FED SPEC GGG-S-665)
 - 2.3.2 SHRINK A 1 INCH PIECE OF HEAT SHRINKABLE TUBING MEETING THE REQUIREMENTS OF MIL-I-23053/5, CLASS 1, CENTERED AT THE END OF THE ARMOR TO TERMINATE THE ARMOR ON THE CABLE JACKET
 - 2.3.3 DO NOT DAMAGE GROSS SHIELD OR CONDUCTOR INSULATION
 - 2.4 CUT AND REMOVE ANY FILLER OR CORE USED TO MAKE UP THE CABLE CONSTRUCTION.

NOTE: IF THE GROSS SHIELD INTERFERES WITH THIS STEP, PUSH THE BRAIDED SHIELD BACK ON THE CABLE AS DEPICTED IN FIGURE 2 WHILE REMOVING CABLE FILLERS.




FIGURE 2
GROSS SHIELD INTERFERENCE REMOVAL

- 2.5 DETERMINE THE DIAMETERS OF THE TWO CABLES TO BE MATED AND THE RESULTANT WIRE BUNDLE AND SELECT THE APPROPRIATELY SIZED "Y" TRANSITION SLEEVE (BOOT).
 - 2.5.1 MATERIAL FOR THE BOOT SHALL BE POLYETHYLENE, UNARMED, NON-BURNING AND SHALL CONFORM TO THE REQUIREMENTS OF MIL-I-81785/1. THE BOOT SHALL HAVE AN INTERNAL COATING OF ADHESIVE.
 - 2.5.2 IF ONE BOOT WILL NOT FIT THE CABLES AT ALL LEGS, SELECT A SIZE WHICH FITS AS MANY LEGS AS POSSIBLE AND IS TOO LARGE FOR THE REMAINING LEGS. THE CABLE(S) SHOULD THEN BE BUILT UP TO THE PROPER DIAMETER BY APPLYING HEAT SHRINKABLE TUBING CONFORMING TO MIL-I-23053/5, CLASS 1.


- 2.6 SLIDE THE LEGS OF THE BOOT OVER THE CABLES AND POSITION AWAY FROM THE WORK AREA.
- 2.7 CAREFULLY COMB OUT THE GROSS SHIELD USING A SOFT INSTRUMENT (SPUDGER OR EQUIVALENT) TO THE JUNCTION OF THE TWO CABLES.
 - 2.8 MARK ALL CONDUCTORS
 - 2.9 INTERWEAVE THE LEADS FROM BOTH CABLES TO FORM A SINGLE CABLE. THE LEADS OF THE SAME LAY, CLOCKWISE OR COUNTERCLOCKWISE ROTATION AND RELATIVE POSITION AS THE ORIGINAL SINGLE CABLE CONDUCTORS
 - 2.10 PROVIDE A LENGTH OF HEAT SHRINK SLEEVING WHICH MEETS THE REQUIREMENTS OF MIL-I-23053/5, CLASS 1 OR MIL-I-23053/10 OF PROPER DIAMETER TO COVER THE COMBINED BUNDLE
 - 2.10.1 SLEEVING MUST EXTEND FROM A MINIMUM OF ONE INCH BEYOND THE BOOT TO COMPLETELY THROUGH CONNECTOR SEALING GROMMET FIGURES 1 AND 3

NOTE: ENSURE LONGITUDINAL SHRINKAGE IS TAKEN INTO CONSIDERATION WHEN MAKING THE ABOVE DETERMINATION
 - 2.10.2 SHRINK A TEST PIECE OF SLEEVING OVER CONDUCTOR BUNDLE TO CHECK CLAMPING AND ENVIRONMENTAL SEALING PER FIGURE 5A1 STEPS 6 AND 8
 - 2.10.3 BUILD UP THE CABLE DIAMETER PER SHEET 5A3 IF NECESSARY AFTER REMOVAL OF THE TEST PIECE OF SLEEVING
 - 2.11 POSITION THE TUBING OVER THE CABLES AWAY FROM THE GROSS SHIELD. ASSEMBLE THE BACK SHIELD AND CLAMP COMPONENTS ON THE CABLE SO AS NOT TO INTERFERE WITH SUBSEQUENT STEPS

- 2.12 CONTINUE ASSEMBLING THE CONNECTOR IN ACCORDANCE WITH THE APPLICABLE CONNECTOR ASSEMBLY PROCEDURE COMMENCING WITH STEP 12 OF FIGURE 5A1
- NOTE: DO NOT ASSEMBLE THE BACKSHELL UNTIL SEQUENCED IN THIS PROCEDURE
- 2.13 TERMINATE GROSS SHIELD INTERNAL TO THE BACK SHIELD AND SEAL (NO INTERFERENCE WITH ENVIRONMENTAL SEAL IN ACCORDANCE WITH APPLICABLE METHOD OF FIGURE 5A22
- 2.14 ABRASE THE BONDING SURFACE OF EACH CABLE JACKET WITH #320 EMERY CLOTH OR EQUIVALENT
- 2.15 WIPE THE ABRASED SURFACE WITH A SOLVENT FROM TABLE 1

TABLE 1

1. 1. 1-TRICHLOROETHANE	O-T-620
TRICHLOROTRIFLUOROETHANE	MIL-C-81302
ISOPROPYL ALCOHOL	TT-I-735
PERCHLOROETHYLENE	O-T-236
1. 1. 1-TRICHLOROETHANE (VAPO1 DEGREASING)	MIL-T-81533
REAGENT WATER (TYPE II)	ASTM D-1193
DETERGENT CLEANERS	AS APPROVED BY THE GOVERNMENT



CABLE BIFURCATION
FIGURE 1

FIGURE 5A27. Cable bifurcation procedure.

SH 132317334

DOD-STD-2003-5 (NAVY)
24 JUNE 1987

NOTES:
1. THIS FIGURE SUPERSEDES SHEET 5A28 OF DWG. 803-5001027.

- 2 16 ASSEMBLE THE SLEEVE ASSEMBLY AND TORQUE TO CONNECTOR SPEC
 - 2 17 USING A HEAT GUN, SHRINK THE SLEEVING BY APPLYING HEAT, STARTING AT THE CONNECTOR END AS THE TUBING SHRINKS, SLIDE THE TUBING UNDER THE CABLE AND TO THE BACKSHELL FORWARD OF THE ENVIRONMENTAL SEALING AREA
 - 2 18 CONTINUE APPLYING HEAT IN THE DIRECTION OF THE CABLE JACKET, REMOVING HEAT AS THE SLEEVING ASSUMES THE CONFIGURATION OF THE CABLE
 - 2 19 PROCEED WITH CONNECTOR/BACKSHELL ASSEMBLY IN ACCORDANCE WITH THE APPLICABLE ASSEMBLY PROCEDURE
 - 2 20 SLIDE THE BOOT OVER THE CABLE JUNCTION
 - 2 20 1 ENSURE THE BOOT CROTCH IS POSITIONED SO THAT THE BOOT WILL OVERLAP EACH CABLE JACKET ONE INCH
 - 2 21 SHRINK THE BOOT WITH A HEAT GUN BY APPLYING HEAT FROM THE CENTER TO THE ENDS TO AVOID TRAPPING AIR
 - 2 21 1 WHEN THE BOOT IS RECOVERED SUFFICIENTLY TO ASSUME THE CONFIGURATION COVERED, REMOVE THE HEAT
 - 2 21 2 WIRE OFF EXCESSIVE ADHESIVE WITH A CLEAN CLOTH
- CAUTION DO NOT USE SOLVENT FOR CLEANING OFF EXCESS ADHESIVE GOING SO CLOSE TO THE JUNCTION AREA AND RESULT IN A POTENTIAL BOND FAILURE
- 2 22 DO NOT DISTURB JUNCTION UNTIL COOL




FIGURE 5A28. Cable bifurcation procedure.

SH 132317335

GLOSSARY OF TERMS

1 A LIST OF TERMS USED IN THIS PROCEDURE WHICH ARE COMMONLY USED IN ELECTRICAL CONNECTOR ENGINEERING PRACTICE FOLLOWS

1.1 CONNECTOR RELATED TERMINOLOGY

- 1.1.1 ADAPTER, AN INTERMEDIATE DEVICE TO PROVIDE FOR ATTACHING SPECIAL ACCESSORIES OR TO PROVIDE SPECIAL MOUNTING MEANS
- 1.1.2 BACKSHELL ASSEMBLY, A DEVICE ADDED BETWEEN THE REAR OF THE CONNECTOR AND THE CABLE CLAMP THE BACKSHELL IS USED TO PROVIDE ENVIRONMENTAL SEALING AND RFI SHIELDING COMPONENTS SHELLS ARE HELD ON ANGLED BACK CONTACT STRAIN RELIEF BACKSHELLS ARE NORMALLY EITHER STRAIGHT (0°) OR ANGLED (45° OR 90°)
- 1.1.3 BAYONET COUPLING RING, A POSITIONING DEVICE FOR THE CONNECTOR AND STRAIN RELIEF KEYS ON A CONNECTOR AND STRAIN RELIEF KEYS ON THE MATING RECEPTACLE MATING AND UNMATING IS ACCOMPLISHED BY ROTATING THE COUPLING RING
- 1.1.4 BIN (BASIC IDENTIFICATION NUMBER) CODE A DISTINCTIVE NUMBER ASSIGNED TO IDENTIFY THE CONTACT THE BIN CODE IS INDICATED ON THE CONTACT BY THREE COLOR CODES OR BY THREE COLOR CODED BANDS ARE NORMALLY LOCATED ON THE WIDER BARREL END OF THE CONTACT THE WIDER BARREL END, NORMALLY NEAREST THE DUNE BARREL END, INDICATES THE FIRST DIGIT OF THE CONTACT THE SECOND DIGIT AND THE LAST BAND OF THE CONTACT IS THE BIN CODE THE COLOR CODE IS:
0 - BLACK 4 - YELLOW 7 - VIOLET
1 - BROWN 5 - GREEN 8 - GRAY
2 - RED 6 - BLUE 9 - WHITE
3 - ORANGE
- 1.1.5 BRAID, FLEXIBLE CONDUCTOR MADE OF A WOVEN OR BRAIDED ASSEMBLY OF FINE WIRES
- 1.1.6 CABLE CLAMP, THE CABLE CLAMP WHEN SCREWED ONTO THE BACKSHELL PROVIDES THE COMPRESSION FORCE TO SEAL THE CONTACTS TO THE BACKSHELL VIA THE COMPRESSION RING AND THE CLAMPING BAR PROVIDE MECHANICAL HOLDING OF THE CABLE TO THE BACKSHELL SO THE SEAL IS NOT FRACTURED BY MOVEMENT OF THE CABLE
- 1.1.7 CLOCKING, THE ORIENTATION OF CABLES HAVING ANGLED BACKSHELLS TO THE MATING KEY OF THE MATING RECEPTACLE
- 1.1.8 CONDUCTOR BARREL (WIRE BARREL), THE STRIPPED END OF THE CONTACT OR RECEPTACLE THAT ACCOMMODATES THE STRIPPED CONDUCTOR
- 1.1.9 CONNECTOR, ELECTRICAL DEVICE EITHER TERMINAL OR NONTERMINAL USED TO TERMINATE OR CONNECT THE CONTACTS IN CABLES AND WHICH PROVIDES A MEANS TO CONTINUE THE CONTACTS TO A MATING CONNECTOR OR PRINTED CIRCUIT BOARD
- 1.1.10 CONTACT, THE CONDUCTIVE ELEMENT IN A CONNECTOR WHICH MAKES CONTACT FOR THE PURPOSE OF TRANSFERRING ELECTRICAL ENERGY

- 1.1.11 CONTACT ARRANGEMENT, THE NUMBER, SPACING AND ARRANGEMENT OF CONTACTS IN A CONNECTOR
- 1.1.12 CONTACT ENGAGING AND SEPARATING FORCE, FORCE NEEDED TO EITHER ENGAGE OR SEPARATE CONTACTS TO MATING CONTACTS OR GAGE PINS
- 1.1.13 CONTACT RETAINER, A DEVICE EITHER ON THE CONTACT OR THE CONTACT HOLES TO RETAIN THE CONTACT IN AN INSERT OR BODY
- 1.1.14 CONTACT RETENTION, THE AXIAL LOAD IN EITHER DIRECTION WHICH A CONTACT CAN WITHSTAND WITHOUT BEING DISLODGED FROM ITS NORMAL POSITION WITHIN AN INSERT OR BODY
- 1.1.15 CONTACT SIZE, AN ASSIGNED NUMBER DENOTING THE SIZE OF THE CONTACT ENGAGING END
- 1.1.16 COVER, ELECTRICAL CONNECTOR, DUST CAPTAIN ITEM WHICH IS SPECIFICALLY DESIGNED TO COVER THE MATING END OF A CONNECTOR TO PROVIDE ELECTRICAL AND/OR ENVIRONMENTAL PROTECTION
- 1.1.17 DUMMY CONNECTOR RECEPTACLE, A SPECIALLY DESIGNED CONNECTOR RECEPTACLE WHICH IS USED TO COVER THE CONTACTS FOR ATTACHING CONDUCTORS TO THE CONTACTS USED FOR ASSEMBLY OF A COUNTERPART CONNECTOR PLUG
- 1.1.18 EXTRACTION TOOL, A DEVICE USED FOR REMOVING REMOVABLE CONTACTS FROM A CONNECTOR
- 1.1.19 GUIDE PIN, A SPECIFICALLY DESIGNED PIN INSERTED THROUGH A CONNECTOR TO GUIDE CONTACT CONTACTS INTO PROPER INSERT CAVITY
- 1.1.20 INSERT, ELECTRICAL CONNECTOR, AN INSULATING ELEMENT/DIELECTRIC DESIGNED TO MOUNT AND SUPPORT CONTACTS IN A CONNECTOR
- 1.1.21 INSERTION TOOL, A DEVICE USED TO INSERT CONTACTS INTO A CONNECTOR A DEVICE WHICH INSERTS TAPER PINS INTO TAPER PIN RECEPTACLES
- 1.1.22 KEYING, POLARIZATION, A MECHANICAL CONFIGURATION OF INSERTS AND SHELLS WHICH PREVENTS MISMATCHED PLUGS AND RECEPTACLES ALTERNATE KEY ARRANGEMENTS ARE AVAILABLE TO PREVENT MISMATCHING OF SIMILAR CONNECTORS
- 1.1.23 PLUG CONNECTOR, SEE ELECTRICAL CONNECTOR
- 1.1.24 PULL OUT FORCE, FORCE NECESSARY TO SEPARATE CONTACTS FROM CONTACT OR TERMINAL OR CONTACT RECEPTACLE BY EXERTING A TENSILE PULL
- 1.1.25 RFI PIECES, THE RFI PIECES ALLOW CONNECTOR SHIELDING TO BE MOVED TO THE CONTACTOR SHIELD TO PREVENT UNDESIRABLE GROSS SHIELD TO THE CONTACTOR SHIELD TO PREVENT UNDESIRABLE RADIO FREQUENCY INTERFERENCE SHIELD
- 1.1.26 SHELL, ELECTRICAL CONNECTOR, THE OUTSIDE OF THE ELECTRICAL CONNECTOR INTO WHICH THE DIELECTRIC MATERIAL AND CONTACTS ARE ASSEMBLED

- 1.1.27 SLEEVE, THE SLEEVE IS THE OUTER HOUSING OF THE BACKSHELL ASSEMBLY THE SLEEVE NORMALLY CONTAINS THE ENVIRONMENTAL SEALING AND RFI SHIELDING COMPONENTS SHELLS ARE HELD ON ANGLED BACK CONTACTS THE SLEEVE IS FORMED AT 45° OR 90° ANGLE
 - 1.1.28 SOLDER CUP, THE END OF A TERMINAL OR CONTACT IN WHICH THE CONDUCTOR IS INSERTED PRIOR TO BEING SOLDERED
 - 1.1.29 THREADED COUPLING RING, A THREADED RING FITTING OVER THE CONNECTOR SHELL THAT THREADS ONTO THE PLUG THE THREADED COUPLING RING AIDS IN MATING THE CONNECTOR TO THE PLUG AND HOLDS THE CONNECTOR AND PLUG IN A MATED CONDITION
 - 1.1.30 WIRE SEALING PLUG, WIRE SEALING PLUGS ARE USED TO SEAL THE CONTACT HOLES IN UNUSED CONNECTOR HOLES TO PROVIDE AN ENVIRONMENTAL SEAL
- 1.2 CRIMPING RELATED TERMINOLOGY
- 1.2.1 CRIMP, THE PHYSICAL COMPRESSION (DEFORMATION) OF CONTACTS TO MAKE AROUND A CONDUCTOR IN ORDER TO MAKE AN ELECTRICAL CONNECTION
 - 1.2.2 CRIMPING, A PRESSURE METHOD OF MECHANICALLY SECURING TERMINAL SPLICE OR CONTACT TO A CONDUCTOR
 - 1.2.3 CRIMPING DIE, PORTION OF THE CRIMPING TOOL THAT SHAPES THE CRIMP
 - 1.2.4 CRIMPING TOOL, MECHANISM USED FOR CRIMPING
 - 1.2.5 DEPTH OF CRIMP, THE DISTANCE THE INDENTOR PENETRATES INTO THE BARREL
 - 1.2.6 INDENTOR, THAT PART OF A CRIMPING TOOL USUALLY THE MOVING PART THAT COMPLETES INDENTATIONS IN THE CONTACT CONDUCTOR BARREL
 - 1.2.7 LOCATOR, THE PART OF THE CRIMPING DIE POSITIONER OR TURRET HEAD THAT PLACES THE TERMINAL SPLICE OR CONTACT IN THE CRIMPING AREA OF THE CRIMPING TOOL OR DIE
 - 1.2.8 POSITIONER, SEE LOCATOR
 - 1.2.9 BATCH CONTROL, A DEVICE TO ENSURE THE FULL CRIMPING CYCLE OF A CRIMPING TOOL
 - 1.2.10 TURRET HEAD, A DEVICE THAT IS ATTACHED TO A CRIMPING TOOL WHICH CONTAINS MORE THAN ONE LOCATOR AND ALLOWS THE LOCATORS TO BE ROTATED TO HOLD A CONTACT IN THE CORRECT POSITION FOR CRIMPING THE CONTACTS TO THE INTERCHANGEABLE WITH OTHER TURRET HEADS

NOTES:

- 1. THIS FIGURE SUPERSEDES SHEET 5A29 OF DWG 803-5001027.

FIGURE 5A29. Glossary of terms.

DOD-STD-2003-5 (NAVY)
24 JUNE 1987

NOTES:
1. THIS FIGURE SUPERSEDES SHEET 5A30 OF DWG. 803-5001027.

- 1.3 SOLDERING RELATED TERMINOLOGY
- 1.3.1 ALLOY REGION THE AREA WITHIN THE SOLDER CONNECTION WHICH REMAINS UNMELTED DURING THE SOLDERING PROCESS.
- 1.3.2 BRIDGING SEPARATION OF INDIVIDUAL STRANDS
- 1.3.3 COLD SOLDER CONNECTION UNSATISFACTORY CONNECTION RESULTING FROM INSUFFICIENT HEAT AND EXHIBITING A SURFACE BUILT UP OF SOLDER. (SEE ALSO DISTURBED SOLDER CONNECTION WHICH IS OFTEN REFERRED TO AS A "COLD JOINT")
- 1.3.4 DISTURBED SOLDER JOINT A DISTURBED SOLDER JOINT WHICH IS UNSATISFACTORY CONNECTION RESULTING FROM RELATIVE MOTION BETWEEN LEAD/WIRE AND THE TERMINAL AREA DURING SOLIDIFICATION OF THE SOLDER
- 1.3.5 EXCESSIVE SOLDER EXCESSIVE SOLDER IS A CONDITION RESULTING IN AN UNSATISFACTORY CONNECTION BECAUSE THE CONTOUR OF THE ELEMENTS OF THE CONNECTION IS COMPLETELY OBSURED BY THE SOLDER OR IS A SURVEY BEFORE THE CONFINES OF THE CONNECTION AREA.
- 1.3.6 FILLET SOLDER THAT FILLS THE SPACE BETWEEN CONDUCTORS IN AN ELECTRICAL CONNECTION
- 1.3.7 FLUX FLUX IS A CHEMICALLY ACTIVE COMPOUND THAT IS CAPABLE OF PROMOTING THE WETTING OF METALS WITH SOLDER
- 1.3.7.1 FLUX HAS A LOWER MELTING POINT THAN SOLDER AS HEAT IS APPLIED, FLUX DISSOLVES, REACHING THE METAL FIRST IT CLEANS THE OXIDE AS THE SOLDER MELTS. CLEANED SURFACE FLUX ALSO HELPS SOLDER FLOW AS IT SHOULD THEN RISES TO THE TOP AND IS PUSHED TO THE OUTER EDGES CARRYING WITH IT THE OXIDES WHICH HAS BEEN REMOVED. THIS PREPARED SURFACE IS CALLED "WETTED"
- 1.3.7.2 ROSIN FLUX A NONCORROSIVE, NONCONDUCTIVE, CHEMICALLY PROMOTING OF THE WETTING OF METALS WITH SOLDER BY A CHEMICAL CLEANING ACTION
- 1.3.8 OXIDATION OXYGEN MIXING WITH THE SURFACE METAL FORMING A COATING THAT IS RESISTANT TO SOLDERING
- 1.3.9 PRE-TINNED SOLDER APPLIED TO EITHER OR BOTH THE CONTACT AND CONDUCTOR PRIOR TO SOLDERING
- 1.3.10 SOLDER SOLDER IS A METALLIC ALLOY USUALLY OF LEAD AND TIN, USED TO MECHANICALLY AND ELECTRICALLY JOIN METALS BY SOLIDIFICATION FOLLOWING THE WETTING ACTION OF THE MELTED ALLOY
- 1.3.11 SOLDERED CONNECTION A SOLDERED CONNECTION IS A ELECTRICAL CONNECTION FORMED BY BONDING TWO OR MORE METALS WITH AN ALLOY (SOLDER)
- 1.3.12 SOLDERING SOLDERING IS A PROCESS IN WHICH METALLIC SURFACES IN CLOSE PHYSICAL PROXIMITY ARE JOINED BY THE WETTING AND SUBSEQUENT COALESCENCE OF LIQUID SOLDER. HEATING OF METALS TO A TEMPERATURE GENERALLY BELOW 204°C (397°F) THAN ANY OF THE METALS BEING JOINED.
- 1.3.12.1 SOLDERING IS ACCOMPLISHED BY HEATING THE TWO METAL POINTS OF CONTACT TO THE MELTING POINT OF THE SOLDER AT THIS TIME THE METAL AND THE LIQUID (MOLTEN) SOLDER MERGE AT THEIR INTERFACES AND MUTUALLY DIFFUSE INTO EACH OTHER
- 1.3.13 SOLDER HEAT BRIDGE HEAT TRANSFER IN SOLDERING CAN BE IMPROVED BY PLACING A SMALL AMOUNT OF SOLDER BETWEEN THE HEAT SOURCE AND THE CONNECTION. THIS IS CALLED A BRIDGE DOES JUST WHAT IT SAYS—IT PROVIDES A BRIDGE THROUGH WHICH HEAT CAN TRANSFER
- 1.3.14 SOLDER PROJECTION A SOLDER PROJECTION IS A UNSURFACABLE PROTRUSION FROM A SOLDERED SOLDER JOINT OR COATING
- 1.3.15 TINNING THE COATING OF A SURFACE WITH A UNIFORM LAYER OF SOLDER
- 1.3.16 WET SOLDERING IRON TIP HEATED SOLDERING IRON TIP COVERED WITH A SMALL QUANTITY OF MOLTEN SOLDER TO ACCELERATE TRANSFER OF HEAT CONNECTION
- 1.3.17 WETTING THE PROCESS OF REDUCING SURFACE RESISTANCE AND TENSION SO A LIQUID CAN SPREAD EVENLY OVER THE SURFACE
- 1.3.18 WICKING WICKING IS THE CAPILLARY ACTION OF SOLDER BETWEEN STRANDS OR FIBERS IN SOLDERING. WICKING OCCURS BETWEEN WIRES OR STRANDS OF WIRE THAT MAKE UP A CONDUCTOR WHEN HOT SOLDER COMES INTO CONTACT WITH THEM. THE STRANDED WIRE BETWEEN STRANDS OF WIRE BY CAPILLARY ACTION UNTIL IT REACHES WIRE THAT IS NOT HOT ENOUGH TO SUPPORT THE WETTING. THE WICKING EFFECT IS VERY USEFUL IN THE APPLICATIONING SOLID CAPTIVE LAMP ACTION. DISTRIBUTES SOLDER TO ALL AREAS OF THE CONDUCTORS BEING JOINED. THE HARMFUL EFFECTS OF WICKING OCCUR WHEN SOLDER IS ALLOWED TO WICK TOO FAR UP OR DOWN THE CONTACT SURFACE, CAUSING THE INSULATION

FIGURE 5A30. Glossary of terms.

SH 132317337

DOD-STD-2003-5 (NAVY)
24 JUNE 1987

- TOOLING AND MATERIALS LIST
- 1 THE FOLLOWING TOOLS ARE UTILIZED IN THE ASSEMBLY OF TYPICAL CONNECTORS
- 1.1 SOLVENT BRUSH IS USED FOR CLEANING DIRT AND GREASE FROM MATERIAL FROM CONNECTOR AND BACKSHELL PARTS
- 1.2 ARTIST'S BRUSH IS USED FOR APPLYING PETROLATUM AND OTHER APPROVED LUBRICANTS TO CONNECTOR AND BACKSHELL PARTS
- 1.3 PRECISION MECHANICAL STRIPPER IS USED TO REMOVE INSULATION FROM CONDUCTORS USING BLADES IT CONSISTS OF AN ADJUSTABLE STOP TO CONTROL THE LENGTH OF INSULATION REMOVED
- 1.4 SOLDERING IRON IS USED TO HEAT CONDUCTORS AND SOLDER TO PROVIDE A SECURE ELECTRICAL CONNECTION
- 1.5 HEAT GUM IS USED TO HEAT SHRINK SOLDER SLEEVES AND SHRINKABLE TUBING
- 1.6 DIAGONAL CUTTER IS USED TO CUT CONDUCTORS TO LENGTH, CUT OFF A REJECTED CRIMPED CONDUCTOR, AND TRIM STRIPPED CONDUCTOR WIRES TO LENGTH
- 1.7 CABLE SHEARS ARE USED TO CUT MULTICONDUCTOR CABLE SQUARELY
- 1.8 ADJUSTABLE CUTTER IS USED TO CUT CABLE JACKETS AND INSULATION BECAUSE IT IS FULLY ADJUSTABLE TO PREVENT PENETRATION TO THE UNDERLYING JACKET CONDUCTORS, BRAIDED SHIELD AND HAS A BREAK AWAY RENEWABLE BLADE
- 1.9 SOFT INSTRUMENT (SPUDGER) IS A POINTED INSTRUMENT USED TO COMB OUT THE SHIELD PRIOR TO PITTING. IT IS ALSO USED TO FIND AND ROUTE CONDUCTORS DURING CONNECTOR INSERTION
- 1.10 TAILOR SHEARS ARE USED TO CUT NYLON TAPE AND LACING TAPE
- 1.11 NEEDLE NOSE PLIERS ARE USED TO PEEL OFF THE SCORED CABLE JACKET
- 1.12 CROWS FOOT WRENCH IS USED TO TIGHTEN THE ADAPTER ONTO THE CONNECTOR
- 1.13 STRAP WRENCH IS USED TO TIGHTEN VARIOUS BACKSHELL COMPONENTS (SLEEVE TO ADAPTER AND CABLE CLAMP TO SLEEVE)
- 1.14 TWEEZERS ARE AN ALTERNATIVE TO FINGERS IN TIGHT REWORK SITUATIONS
- 1.15 TORQUE WRENCH IS USED TO TIGHTEN VARIOUS BACKSHELL COMPONENTS TO SPECIFIED TORQUE VALUES
- 1.16 CABLE STRIPPER IS USED TO REMOVE ARMOR FROM CABLES BECAUSE IT IS AN INVISIBLE STRIPPER WITH PENETRATION TO THE UNDERLYING CABLE JACKET
- 1.17 CRIMPING TOOL IS USED TO FASTEN WIRE CONDUCTORS INTO CRIMP CONTACTS
- 1.18 POSITIONER IS USED TO POSITION THE CONTACT IN THE CRIMPING TOOL INDENTORS CLOSE TO THE PROPER DEPTH
- 1.19 CRIMPING TOOL GAGE PROVIDES A GO/NO GO TEST TO MAKE SURE THE CRIMP TOOL INDENTORS CLOSE TO THE PROPER DEPTH
- 1.20 PIN CONTACT GAGE IS USED TO TEST SOCKET CONTACT RETENTION
- 1.21 PIN WIRE IS USED TO HOLD THE PIN CONTACT GAGE
- 1.22 DUMMY RECEPTACLE HOLDS AND TRANSFERS GUIDE PINS USED FOR INSERTION OF SOCKET CONTACTS AND PROVIDES A HOLDING BASE FOR THE CONNECTOR DURING INSERTION OF CONTACTS
- 1.23 GUIDE PINS PROVIDE A DEFINITE UNOBSTRUCTED PATH FOR CONTACTS TO FOLLOW, PREVENT FOREIGN MATERIAL FROM ACCUMULATING INSIDE THE SOCKET CONTACT, AND PREVENT MISALIGNMENT CAUSED BY BUNCHING OF THE CONNECTOR INSERT
- 1.24 CONNECTOR ASSEMBLY FIXTURE HOLDS THE CABLE AND CONNECTOR IN RELATION TO EACH OTHER AND PREVENTS MOVEMENT OF THE CONDUCTORS AFTER THEY HAVE BEEN INSERTED. ANY ASSEMBLY FIXTURES OR FIXTURES WITH THE ATTRIBUTES LISTED IN THE ASSEMBLY PORTIONS OF THIS PROCEDURE WILL BE ADEQUATE
- 1.25 INSERTION TOOL IS USED TO INSTALL CONTACTS INTO THE CONNECTOR CONTACT HOLES
- 1.26 EXTRACTION TOOL IS USED TO REMOVE CONTACTS FROM THE CONNECTOR
- 1.27 LOCKWIRE PLIERS ARE USED TO TWIST THE LOCKWIRE AND TO EJECT THE LOCKWIRE
- 1.28 TENSION COMPRESSION GAGE IS USED WITH TWO ADAPTERS TO TEST CONTACT CRIMPING AND CONTACT RETENTION
- 1.28.1 WIRE PULL ADAPTER IS USED TO PERFORM A PULL TEST ON CRIMPED CONTACTS (MOUNTED ON THE TENSION END OF THE GAGE)
- 1.28.2 CONTACT PUSH ADAPTER IS USED TO PERFORM A PUSH TEST OF CRIMPED CONTACTS IN THE CONNECTOR (MOUNTED ON THE COMPRESSION END OF THE GAGE)
- 1.29 TORQUE SCREWDRIVER IS USED TO TIGHTEN THE CABLE CLAMPING BAR SCREWS
- 2 THE FOLLOWING MATERIALS ARE UTILIZED IN CONNECTOR ASSEMBLY PROCEDURES
- 2.1 PETROLATUM IS THE PHARMACEUTICAL NAME FOR LUBRICANT JELLY OR VASELINE AND IS USED TO LUBRICATE CONNECTOR AND BACKSHELL COMPONENTS
- 2.2 SHRINK TUBING CONFORMS TO MIL-1-27083 AND IS USED TO INSULATE SHIELD PIGTAILS, IDENTIFICATION OF TWISTED PAIRS OR TRIADS, AND TO PROVIDE ENVIRONMENTAL PROTECTION
- 2.3 LACING TAPE IS USED TO FORM A STRAIN RELIEF FOR THE SHIELD RETURN WIRE
- 2.4 TRANSITION SLEEVE (BOOT) IS USED AT THE JUNCTION WHEN BIFURCATING TWO CABLES
- 2.5 SOLDER SLEEVE CONSISTS OF A HEAT SHRINKABLE SLEEVE CONTAINING A PREFORM OF FLUXED SEALING RING AT EACH END
- 2.6 TRANSPARENT SLEEVING IS USED TO PROVIDE ENVIRONMENTAL PROTECTION TO EXPOSED CONDUCTORS AND CONFORMS TO MIL-1-631
- 2.7 SOLVENTS ARE USED TO REMOVE GREASE, OIL, DIRT, FLUX AND OTHER RESIDUES FROM CONTACTS, TOR AND BACKSHELL COMPONENTS AND THE CABLE JACKET
- 2.8 LOCKWIRE CONFORMING TO MS20985 NC20 IS USED ON CONTACTS TO PREVENT THREADED PARTS FROM BACKING OFF

SH 132317338

FIGURE 5A31. Tooling and materials list.




FIGURE 5A32. Connector part number nomenclature.

SH 132317339







FIGURE 5A33. Connector part number nomenclature.

SH 132317340

5.1 BENDIX "PT" CONNECTORS

NOTES:
1. THIS FIGURE SUPERSEDES SHEET 5A34 OF DWG. 503-5001027.




5.1 BENDIX "PT" CONNECTORS

NOTES:
1. THIS FIGURE SUPERSEDES SHEET 5A34 OF DWG. 503-5001027.

5.1 BENDIX "PT" CONNECTORS

NOTES:
1. THIS FIGURE SUPERSEDES SHEET 5A34 OF DWG. 503-5001027.



5.1 BENDIX "PT" CONNECTORS

NOTES:
1. THIS FIGURE SUPERSEDES SHEET 5A34 OF DWG. 503-5001027.


5.1 BENDIX "PT" CONNECTORS

NOTES:
1. THIS FIGURE SUPERSEDES SHEET 5A34 OF DWG. 503-5001027.

FIGURE 5A34. Connector part number nomenclature.

SH 132317341

DOD-STD-2003-5 (NAVY)
24 JUNE 1987




NOTES
THIS FIGURE SUPERSEDES SHEET 5A35 OF DWG. 803-5001027.

FIGURE 5A35. Connector part number nomenclature.

DOD-STD-2003-5 (NAVY)
24 JUNE 1987

NOTES:
1. THIS FIGURE SUPERSEDES SHEET 5A36 OF DWG. 803-5001027.




SH 132317343

FIGURE 5A36. Connector part number nomenclature.

- 1 VISUAL INSPECTION AND VERIFICATION
- 1.1 DISASSEMBLE THE CONNECTOR BACKSHELL ASSEMBLY
 - 1.2 VERIFY THAT THE CONNECTOR IS OF THE CORRECT TYPE AND CONFIGURATION. THE CONTACTS SHOULD BE TERMINATED IN ACCORDANCE WITH THE SYSTEM CABLING DIAGRAM
 - 1.3 VERIFY THAT THE BACKSHELL CONFIGURATION IS OF THE CORRECT TYPE AS SPECIFIED ON THE SYSTEM CABLING DIAGRAM
 - 1.4 VERIFY THAT ALL COMPONENT PARTS OF THE CONTACT BACKSHELL HARDWARE ARE PRESENT AND IDENTIFIED BY SPERRY CORP. PART NUMBER. THE CONTACT BACKSHELL CONFIGURATION REFERENCE MIL SPECS MIL C 81511 FOR CONNECTOR MIL C 85049 FOR BACKSHELL OR VENDOR DATA FOR SPECIFIC CONFIGURATIONS
 - 1.5 VISUALLY INSPECT THE COMPONENTS FOR DAMAGE SUCH AS DEFORMED PARTS, GOUGES, DAMAGED THREADS, CUT O-RINGS, BURRS, OR SURFACE DAMAGE
 - 1.6 VERIFY THAT THE CONTACTS MEET THE REQUIREMENTS OF MIL C 39029/47 FOR SERIES 1 AND 2 PIN MIL C 39029/33 FOR SERIES 1 SOCKET OR MIL C 39029/46 FOR SERIES 2 SOCKET CONTACTS AND ARE OF THE CORRECT TYPE AND TYPE FOR THE CONTACTOR BEING ASSEMBLED
 - 1.7 IF THE CONDUCTORS ARE RETWISTED DURING LEAD PREPARATION, ENSURE THEY ARE TWISTED AS SPECIFIED IN THE MANUFACTURING INSTRUCTIONS. THE LAY OF THE CONDUCTOR IS MAINTAINED AND THE CONTACTORS WILL FIT INSIDE THE CONTACT BARREL

NOTES:

1. THIS FIGURE SUPERSEDES SHEET 5B1 OF DWG. 803-5001027.



- NOTE: EQUIVALENT TOOLING FROM ALTERNATE SOURCES IS ACCEPTABLE, HOWEVER THE USE OF OTHER TOOLS MAY AFFECT THE PROCEDURAL STEPS OUTLINED BELOW
- 3.1 SECURE THE ASSEMBLY FIXTURE TO A VISE OR SIMILAR HOLDING DEVICE IN ORDER TO PROVIDE A STABLE WORK AREA
 - 3.2 CHECK THE DUMMY RECEPTACLE (FIGURE 3B) (DUMMY RECEPTACLE NAVSEA DWG. NO. 53711-5499688) USED IN THIS PROCEDURE
 - 3.2.1 O-RING IN PLACE AND LIGHTLY LUBRICATED WITH PETROLIUM (V-P-236) OR EQUIVALENT (FIGURE 3 A)
 - 3.2.2 RETAINER BARREL THREADS LIGHTLY LUBRICATED WITH PETROLIUM OR EQUIVALENT (FOR USE WITH SOCKET CONTACTS ONLY)
 - 3.2.3 ALL GUIDE PINS PRESENT AND STRAIGHT (FOR USE WITH SOCKET CONTACTS ONLY)
 - 3.2.4 GUIDE PINS PRESSED BACK INTO THE DUMMY RECEPTACLE SO THAT NO MORE THAN 1/8 INCH PROJECTS (FOR USE WITH SOCKET CONTACTS ONLY)
 - 3.3 MATE THE CONNECTOR TO THE DUMMY RECEPTACLE. RETAINER BARREL (IF REQUIRED) ASSEMBLY AND LOCK THE COUPLING RING (FIGURE 3 B)
 - 3.4 TURN THE CONTACT RETENTION RING CLOCKWISE TO THE LOCKED POSITION (FIGURE 3 C)
 - 3.5 PERFORM THIS STEP FOR SOCKET CONTACTS ONLY USING A WOODEN DOWEL. SLOWLY PRESS THE DOWEL THROUGH THE CONTACTS IN A SERIES OF SHORT STROKES TO RELEASE THEM IN A SERIES OF SHORT STROKES TO ALLOW THE GUIDE PINS TO REALIGN THEMSELVES AND RELIEVE STRESS WITHIN THE INSERT. CONTINUE UNTIL THE GUIDE PINS PROTRUDE ABOUT 1/8 INCH FROM THE REAR OF THE CONNECTOR (FIGURE 3 D)





FIGURE 5B1. MIL-C-81511 series 1 and 2 gang contact release connector assembly procedure.

8 SEATING CHECKS TO BE CONDUCTED AFTER INSERTION OF ALL CONTACTS

8.1 RELEASE THE FIXTURE CLAMP AND GRASP THE CABLE JACKET. PUSH THE ENTIRE WIRE BUNDLE INTO THE CONNECTOR WHILE CONTINUING TO EXERT PRESSURE ON THE CONTACT RETENTION RING TO ITS LOCKED POSITION.

CAUTION DO NOT FORCE THE RETENTION RING FAILURE OF THE RETENTION RING TO CLOSE INDICATES ONE OR MORE CONTACTS ARE BEING FORCED INTO THE RETENTION DISC.

THE RETENTION RING IS FULLY LOCKED WHEN NO COLOR SHOWS BELOW THE EDGE. WHEN THE RETENTION RING WILL NOT LOCK IF ONE OR MORE CONTACTS ARE NOT FULLY SEATED. FIGURE 6 ILLUSTRATES THE EFFECT OF AN UNSEATED CONTACT ON THE RETENTION DISC.

8.2 IDENTIFY UNSEATED CONTACTS BY A VISUAL INSPECTION OF THE CONNECTOR FACE OR BY EXAMINATION OF THE GUIDE PINS TO DETECT ANY THAT ARE NOT FULLY PUSHED OUT BY THE CORRESPONDING SOCKET CONTACT.

8.3 IF REQUIRED REMOVE UNSEATED CONTACTS FROM THE CONNECTOR. REMOVE THE DUMMY RECEP-TACLE AND UNLOCK THE RETENTION RING. INSERT THE UNSEATED CONTACTS INTO THE CONNECTOR FACE AND PUSH THE UNSEATED CONTACTS INTO THE SOCKET UNTIL THE TOOL BOTTOMS OUT. NO FURTHER EXTRACTION IS NECESSARY.

8.4 REINSERT ALL EXTRACTED CONTACTS AND REPEAT THE SEATING CHECKS.

8.5 IF THE RETENTION RING CANNOT BE LOCKED AFTER THREE INSERTION ATTEMPTS REPLACE THE OFFEND-ING CONTACTS. IF THE SAME CONTACT LOCATION CONTINUES TO GIVE THE SAME CONTACT LOCATION DISC IS PROBABLY DAMAGED OR FAULTY AND THE ENTIRE CONNECTOR MUST BE REPLACED.

8.6 REMOVE THE CONNECTOR FROM THE DUMMY RECEP-TACLE UPON COMPLETION OF FINAL SEATING CHECKS.

9 CONTACT PUSH TEST

9.1 USING THE COMBINATION TENSION/COMPRESSION GAGE (CHATILLON DPP 50 OR EQUIVALENT) PUSH TEST ALL CONTACTS TO EVALUATE CONTACT RETEN-TION (FIGURE 8).

9.1.1 ENSURE THE PROPER CONTACT RETENTION PROBE IS UTILIZED (FIGURE 9) SO THE RETEN-TION FINGERS WON'T BE DAMAGED.

9.1.2 SEE TABLE 4 FOR PUSH TEST VALUES.

9.1.3 THE FORCE SHALL BE APPLIED TO THE MAT-ING END OF THE CONTACT IN A FIRM, SLOW MANNER DO NOT INSTANTANEOUSLY APPLY THE FORCES LISTED IN TABLE 4.

TABLE 4

CONTACT SIZE	PUSH TEST VALUE (LBS)
12-12	25
16-16	45
20-20	75
23-22	10
23-28	10

NOTES:
1. THIS FIGURE SUPERSEDES SHEET 5B3 OF DWG 803-5001027.





FIGURE 8
PUSH TEST ADAPTER, TENSION/COMPRESSION GAGE

SOCKET CONTACT RETENTION PROBE



125 ± .005 ± .120° INCLUDED ANGLE CHAMFER



PIN CONTACT RETENTION PROBE

CONTACT SIZE	A	B	C	D
23	± .010	± .001	± .001	± .005
20	300	028	029	125
16	410	038	043	125
12	410	051	057	125
				156

FIGURE 9
CONTACT RETENTION PROBES




FIGURE 7
PROPERLY SEATED CONTACTS

FIGURE 6
UNSEATED CONTACTS

SH 132317346

FIGURE 5B3. MIL-C-81511 series 1 and 2 gang contact release connector assembly procedure.

NOTES:
1. THIS FIGURE SUPERSEDES SHEET 5B4 OF DWG. 803-5001027.

- 10 7 IF THE GROSS SHIELD IS TO BE FLOATED OR TERMINATED TO A CONNECTOR CONTACT SLIDE THE GROSS SHIELD TO THE BACKSHELL RFI HARDWARE PROCEED AS FOLLOWS
- 10 7 1 SLIDE THE RFI BELL (PC 3) AGAINST THE BACKSHELL ADAPTOR
- 10 7 2 FLARE THE GROSS SHIELD UNIFORMLY OVER THE TAPERED END OF THE RFI BELL. SHIELD SHALL NOT EXTEND BEYOND THE TAPERED END
- 10 7 3 GENTLY FORCE THE CABLE TOWARD THE CONNECTOR PLUG UNTIL THE SHIELD COVERS THE TAPERED SURFACE ON THE RFI BELL WHILE APPLYING FORWARD PRESSURE ON THE CABLE
- 10 7 5 COMPRESS THE SHIELD BETWEEN THE RFI BELL AND RFI RING WITH A FORWARD MOTION ON THE RFI RING (SEE FIGURE 12)




FIGURE 12
RFI COMPONENTS

- 10 8 IF THE GROSS SHIELD IS FLOATED OR TERMINATED TO A CONNECTOR CONTACT SLIDE THE GROSS SHIELD TO THE BACKSHELL RFI HARDWARE PROCEED AS FOLLOWS
- 10 9 SLICE THE BACKSHELL SLEEVE (PC 5) OVER THE RFI ASSEMBLY AND SCREW THE SLEEVE ONTO THE ADAPTER
- 10 10 TORQUE THE SLEEVE TO THE VALUE PROVIDED IN TABLE 5 FOR THE APPROPRIATE SHELL SIZE

10 BACKSHELL ASSEMBLY

NOTE THE FOLLOWING ASSEMBLY PROCEDURE IS BASED ON THE ASSUMPTION THAT THE CONTACTS ARE IN THE POSITION SPECIFIED IN FIGURE 1. VARIATIONS MAY OCCUR AND CAUSE MINOR DEVIATIONS FROM THIS PROCEDURE IF THIS SITUATION OCCURS THE MANUFACTURER'S ASSEMBLY INSTRUCTIONS SHOULD BE FOLLOWED

- 10 1 FOLD SPARE WIRES BACK ONE-HALF THE DISTANCE BETWEEN THE CONNECTOR AND THE JACKET END
- 10 2 SLIDE A 1 INCH LONG PIECE OF 1/4 INCH SHRINK TUBING OVER EACH FOLDED PAIR AND SHRINK IN PLACE
- 10 3 LIGHTLY COAT THE THREADS OF EACH BACKSHELL PART WITH PETROLIUM (V-V-P-236) JUST PRIOR TO USING
- 10 4 POSITION AND LUBRICATE ALL O-RINGS
- 10 5 REMOVE THE WIRE HOOP AND LOOSEN THE FIXTURE CLAMP FROM THE ASSEMBLY FIXTURE
- 10 6 SLIDE THE BACKSHELL ADAPTER DOWN THE CABLE AND SCREW IT ONTO THE CONNECTOR (FIGURE 11) AND TIGHTEN THE ADAPTER TO THE TORQUE VALUE PROVIDED IN TABLE 5 FOR THE APPROPRIATE SHELL SIZE





FIGURE 11

SHELL SIZE	TORQUE VALUE IN /LBS
8	45
9	45
10	45
11	45
12	45
14	50
15	50
16	60
17	60
18	60
19	60
20	70
21	70
22	70
23	70
24	70
25	70

NOTE DURING THE PERFORMANCE OF THIS TEST A SMALL AMOUNT OF CONTACT "PUSH BACK" OCCURS WHICH AFFECTS THE FINAL SEATING OF THE CONTACT RETENTION DISC FIGURE 10 ILLUSTRATES THIS EFFECT AND THE NECESSITY FOR A FINAL TIGHTENING OF THE CONTACT RETENTION RING FOLLOWING THE "PUSH TEST"

- 9 2 REPLACE THE CONNECTOR IN THE DUMMY RECEPTACLE AND RETIGHTEN THE RETENTION RING WHILE GENTLY PUSHING THE WIRE BUNDLE TOWARD THE CONNECTOR. IF ALL THE CONTACTS HAVE BEEN PROPERLY JUSTIFIED, THE RETENTION RING WILL TURN AN ADDITIONAL 1/8 TO 1/4 TURN



PUSH BACK ALLOWS FINGERS TO REST AGAINST SURFACE OF CONTACT

CONTACT "PUSH BACK"
FIGURE 10

SH 132317347

FIGURE 5B4. MIL-C-81511 series 1 and 2 gang contact release connector assembly procedure.

NOTES:
1. THIS FIGURE SUPERSEDES SHEET 5B5
OF DWG. 803-5001027.

10.11 MARK A LINE ON THE CABLE 1/4-1/2 INCH ABOVE THE BACKSHELL SLEEVE (SEE FIGURE 13). CAREFULLY PUSH THE CABLE INTO THE BACKSHELL 1/4 INCH. STRAIN RELIEF SHOULD BE POSITIONED ON THE CONDUCTOR AND MARKED ON THE BACKSHELL. BE SURE TO HOLD AT THIS POSITION FOR THE NEXT FOUR STEPS (LINE MARKED ON JACKET IS PARALLEL WITH SLEEVE END).





FIGURE 13
MARKING THE CABLE

- 10.12 SLIDE THE SEALING HARDWARE WASHER (PC 6), GROMMET (PC 7), AND GROMMET FOLLOWER (PC 8) IN 'O' POSITION BEHIND THE SLEEVE.
- 10.13 VERIFY THE CABLE JACKET IS POSITIONED COMPLETELY THROUGH THE GROMMET.
- 10.14 SCREW THE CABLE CLAMP (PC 9) ONTO THE SLEEVE AND TORQUE TO THE VALUE SPECIFIED IN TABLE 5.
- 10.15 ALTERNATELY TIGHTEN THE CLAMPING BAR SCREWS UNTIL REACHING THE TORQUE VALUE SPECIFIED IN TABLE 6 USING A TORQUE SCREWDRIVER (TORQUE CONTROL OR EQUIVALENT) (FIGURE 14).
- NOTE IF REQUIRED, INSTALL PERSONNEL SAFETY GROUND UNDER CLAMPING BAR SCREW.
- 10.16 REMOVE THE CONNECTOR FROM THE ASSEMBLY FIXTURE AND REMOVE THE DUMMY RECEPTACLE.
- 11 FINAL TEST AND DOCUMENTATION
- 11.1 USING ESTABLISHED SHIPYARD PROCEDURES PERFORM ELECTRICAL/ELECTRONIC CHECKS ON THE ASSEMBLED CONNECTOR.
- 11.2 INSTALL A PROTECTIVE DUST CAP ON THE CONNECTOR.
- 11.3 COMPLETE THE ASSEMBLY INSPECTION AND DOCUMENTATION AS REQUIRED BY LOCAL PROCEDURES.
- 12 IF NECESSARY LOCKWIRE THE CONNECTOR IN ACCORDANCE WITH FIGURE 5A24.

TABLE 6
CLAMP SCREWS

CABLE DIAMETER	TORQUE VALUE
0.0 TO 0.5 IN	25-2 IN /OZ
0.5 TO 1.0 IN	40-2 IN /OZ
1.0 TO 2.0 IN	50-2 IN /OZ

NOTE THESE TORQUE VALUES MUST BE MAINTAINED SO THAT A MINIMUM GAP OF NOT LESS THAN 1/16 IN EXISTS BETWEEN THE CLAMP SUPPORT AND CLAMP SADDLES.

SH 132317348

FIGURE 5B5. MIL-C-81511 series 1 and 2 gang contact release connector assembly procedure.

APPLICABLE CONNECTORS	
MIL C 81511/45	
MIL C 81511/46	
MIL C 81511/55	
MIL C 81511/56	

- VISUAL INSPECTION AND VERIFICATION
 - DISASSEMBLE THE CONNECTOR/BACKSHELL ASSEMBLY
 - VERIFY THAT THE CONNECTOR IS OF THE CORRECT TYPE AND CONFIGURATION FOR THE CABLE BEING TERMINATED IN ACCORDANCE WITH THE SYSTEM CABLING DIAGRAM
 - VERIFY THAT THE BACKSHELL CONFIGURATION IS OF THE CORRECT TYPE AS SPECIFIED ON THE SYSTEM CABLING DIAGRAM
 - VERIFY THAT ALL COMPONENT PARTS OF THE CONDUCTOR AND BACKSHELL HAVE BEEN IDENTIFIED FOR BACKSHELL CONFIGURATION. REFERENCE MIL SPECS MIL C 81511 FOR CONNECTOR MIL C 85049 FOR BACKSHELL OR VENDOR DATA FOR SPECIFIC CONFIGURATION
 - VISUALLY INSPECT THE COMPONENTS FOR DAMAGE SUCH AS DEFORMED PARTS, GOUGES, DAMAGED THREADS, CUT O-RINGS, BURRS, OR SURFACE DAMAGE
 - VERIFY THAT THE CONTACTS MEET THE REQUIREMENTS OF MIL C 39029/18 FOR SERIES 3 AND 4 AND MIL C 39029/15 FOR SERIES 3 AND 4 CLASS L SOCKET CONTACTS AND ARE THE CORRECT SIZE AND TYPE FOR THE CONTACT BEING ASSEMBLED
 - IF THE CONDUCTORS ARE RETWISTED DURING LEAD PREPARATION, ENSURE THEY ARE TWISTED AS TIGHT AS ORIGINALLY CONSTRUCTED. THE NATURAL LAY OF THE CONDUCTOR IS MAINTAINED AND THE CONDUCTORS WILL FIT INSIDE THE CONTACT BARREL
- PREPARE THE CABLE IN ACCORDANCE WITH FIGURE 5A1
- INSERTION SETUP. DUE TO THE MANY POSSIBLE VARIATIONS IN THE CABLE, THE FOLLOWING PROCEDURES AND TOOLS NO SPECIFICATION IS MADE AS TO A PARTICULAR TYPE. THE CRITERIA WHICH ARE DESIRABLE FOR AN ACCEPTABLE ASSEMBLY FIXTURE ARE AS FOLLOWS
 - DUMMY RECEPTACLE WITHOUT CONNECTOR INSERTED TO HOLD THE CONNECTOR BEING WORKED ON SECURELY
 - CABLE CLAMPING FIXTURE TO HOLD THE CABLE IN PLACE PERMITTING ACCESS TO THE REAR FACE OF THE CONNECTOR FOR THE CONTACT INSERTION TOOL
 - A DEVICE FOR HOLDING THE WIRE BUNDLE OUT OF THE WORK AREA

THE ASSEMBLY FIXTURE REFERRED TO IN THIS PROCEDURE IS THE ASSEMBLY FIXTURE DEVELOPED BY SPERRY CORP. AND IDENTIFIED BY NAVY SEA DWG NO 53711 5499888 (FIGURE 2)




FIGURE 2
ASSEMBLY FIXTURE
SH 132317349

- SECURE THE ASSEMBLY FIXTURE TO A VISE OR SIMILAR HOLDING DEVICE IN ORDER TO PROVIDE A STABLE WORK AREA
- CHECK THE DUMMY RECEPTACLE (FIGURE 3) (DUMMY RECEPTACLE NAVSEA DWG NO 53711-5499889 USED IN THIS PROCEDURE WITHOUT RETAINER BARREL)
 - O-RING IN PLACE AND LIGHTLY LUBRICATED WITH PETROLATUM (VY P-236) OR EQUIVALENT (FIGURE 3 A)
- MATE THE CONNECTOR TO THE DUMMY RECEPTACLE AND LOCK THE COUPLING RING (FIGURE 3 B)
 - TURN CONNECTOR COUPLING CLOCKWISE




FIGURE 3

- EQUIVALENT TOOLING FROM ALTERNATE SOURCES IS ACCEPTABLE. HOWEVER, THE USE OF OTHER TOOLS MAY AFFECT THE PROCEDURAL STEPS OUTLINED BELOW
- SECURE THE DUMMY FIXTURE TO A VISE OR SIMILAR HOLDING DEVICE IN ORDER TO PROVIDE A STABLE WORK AREA
- CHECK THE DUMMY RECEPTACLE (FIGURE 3) (DUMMY RECEPTACLE NAVSEA DWG NO 53711-5499889 USED IN THIS PROCEDURE WITHOUT RETAINER BARREL)
 - O-RING IN PLACE AND LIGHTLY LUBRICATED WITH PETROLATUM (VY P-236) OR EQUIVALENT (FIGURE 3 A)
- MATE THE CONNECTOR TO THE DUMMY RECEPTACLE AND LOCK THE COUPLING RING (FIGURE 3 B)
 - TURN CONNECTOR COUPLING CLOCKWISE




FIGURE 4
DETERMINING CONDUCTOR LENGTH

- POSITION THE CONNECTOR SO THAT THE CONDUCTOR TO CABLE JACKET DISTANCE IS THAT MEASURED IN STEP 9.2 OF FIGURE 5A1. ROTATE THE CONNECTOR TO ALIGN THE KEYWAY POSITION IN PROPER RELATIONSHIP TO THE BACKSHELL (FIGURE 4B)
- ROUTE THE INDIVIDUAL CONDUCTORS PER THE APPLICABLE WIRING TABLE. ENSURE THAT THE LONGEST ROUTED CONDUCTOR HAS SUFFICIENT LENGTH AT THE REQUIRED POSITION TERMINATION PRIOR TO CUTTING ANY CONDUCTOR (FIGURE 4C)
- CUT THE CONDUCTORS AS REQUIRED TO PROVIDE EVEN CONDUCTOR LENGTHS AT THE CONNECTOR INSERT
- LEAVE THE SPARES FULL LENGTH

NOTE: LEAVE THE SPARES FULL LENGTH

NOTES:
1. THIS FIGURE SUPERSEDES SHEET 5B6 OF DWG. 803-5001027.




FIGURE 1
MB1511 CONNECTOR WITH COMPATIBLE BACKSHELL CONFIGURATION

FIGURE 5B6. MIL-C-81511 series 3 and 4 individual contact release connector assembly procedure.

4 STRIP THE INDIVIDUAL CONDUCTORS IN ACCORDANCE WITH SHEET 5A5 (FOR CONTACT WIRE BARREL DEPTHS SEE TABLE 1)

TABLE 1
WIRE BARREL DEPTH (IN)

CONTACT SIZE	SERIES 3		SERIES 4	
	PIN	SOCKET	PIN	SOCKET
12-12	216	232	216	232
16-16	185	195	185	195
20-20	145	155	145	155
23-22	145	155	145	155
23-28	145	155	145	155
CONTACT SIZE	MIN SEPARATION FORCE (OZ)			
12-12	2.5			
16-16	0.6			
20-20	0.4			
23-22	0.4			
23-28	0.4			

NOTE FOR CLASS L SOCKET CONTACTS THE BARREL DEPTH IS 160, 170 INCHES

5 PRIOR TO CRIMPING A CONTACT SIZING TEST SHOULD BE ACCOMPLISHED FOR ALL SOCKET CONTACTS (PIN CONTACTS PREVIOUSLY VERIFIED IN STEP 1 & 6 DO NOT NEED FURTHER TESTING)

5.1 SOCKET CONTACTS SHOULD BE INSPECTED FOR PROPER SIZE USING A PIN CONTACT GAGE CONFORMING TO MS3197 WHEN TESTED THE MINIMUM SEPARATION FORCE MEASURED WITH A TENSION COMPRESSION GAGE (CHATILLON DPP 16 OR EQUIVALENT) SHOULD BE AS SPECIFIED IN TABLE 1




FIGURE 5
SOCKET CONTACT SIZING TEST

6 TERMINATE INDIVIDUAL CONDUCTORS WITH CRIMP CONTACTS IN ACCORDANCE WITH FIGURE 5A10. SEE TABLE 2 FOR PROPER CRIMPING TOOL. IF CONTACT REWORK SHORTENS A CONDUCTOR'S INITIAL LENGTH BY GREATER THAN 1/4 INCH THE JACKET MUST BE CUT BACK AGAIN AND ALL CONDUCTORS RETRIMMED TO PRECLUDE STRESS

TABLE 2 - CRIMP TOOLING INFORMATION

CONTACT SIZE	SERIES 3 & 4 CLASS L SOCKET	
	CRIMPING TOOL	POSITIONER
16-16	M22520/2-01	M22520/2-21
20-20	M22520/2-01	M22520/2-20
22-22	M22520/2-01	M22520/2-19
22-28	M22520/2-01	M22520/2-19

SH 132317350

CONTACT SIZE	SERIES 3 & 4 PIN & SERIES 4 SOCKET		SERIES 3 SOCKET	
	CRIMPING TOOL	POSITIONER	CRIMPING TOOL	POSITIONER
12-12	M22520/1-01	M22520/1-09	M22520/1-01	M22520/1-10
16-16	M22520/2-01	M22520/2-03	M22520/2-01	M22520/2-18
20-20	M22520/2-01	M22520/2-15	M22520/2-01	M22520/2-03
23-22	M22520/2-01	M22520/2-02	M22520/2-01	M22520/2-17
23-28	M22520/2-01	M22520/2-13	M22520/2-01	M22520/2-16

6.1 SECURE THE WIRE BUNDLE IN THE WIRE HOOP SO THAT THE WORK AREA AT THE CONNECTOR FACE IS CLEAR

7 INSERTING CONTACTS

7.1 USING THE PROPER WIRING TABLE PROPER INSERTING TOOL BASED ON CONTACT TYPE (SEE TABLE 3) AND WORKING FROM THE REAR TO THE FRONT OF THE INSERTER FIXTURE, INSERT THE CONTACTS INTO THE DESIGNATED LOCATIONS IN THE CONNECTOR AS FOLLOWS

TABLE 3

CONTACT SIZE	SERIES 3 & 4 PIN & SOCKET	
	INSTALLING TOOL	REMOVAL TOOL
12-12	M81969/16-03	M81969/16-03
16-16	M81969/16-02	M81969/30-04
20-20	M81969/16-01	M81969/30-02
23-22	M81969/16-04	M81969/16-01
23-28	M81969/16-04	M81969/30-01

CONTACT SIZE	SERIES 3 & 4 CLASS L SOCKET CONTACT	
	INSTALLING TOOL	REMOVAL TOOL
16-16	M81969/16-02	M81969/16-02
20-20	M81969/16-01	M81969/30-03
22-22	M81969/16-04	M81969/30-02
22-28	M81969/16-04	M81969/30-01

7.1.1 HOLD THE INSERTION TOOL BETWEEN THE THUMB AND FOREFINGER AND LAY THE WIRE AGAINST THE SLOT OF THE TOOL

7.1.2 SNAP THE WIRE INTO THE SLOT

7.1.3 SEAT THE RETENTION SHOULDER OF THE CONTACT AGAINST THE TIP OF THE TOOL

7.1.4 SLOWLY PUSH THE WIRED CONTACT STRAIGHT INTO THE OPENING AT THE REAR OF THE INSERT

7.1.5 APPLY STRAIGHT STEADY FORWARD PRESSURE ON THE TOOL UNTIL THE CONTACT BOTTOMS

7.1.6 REMOVE THE TOOL BY SLIDING IT STRAIGHT BACK ALONG THE WIRE

7.1.7 UNSNAP THE TOOL FROM THE WIRE WHEN IT IS CLEAR OF THE INSERT

7.1.7.1 LIGHTLY PULL ON INSERTED LEAD TO ENSURE CONTACT HAS LOCKED IN CONNECTOR

7.1.8 ADJUST THE FIXTURE CLAMP AS REQUIRED DURING THE CRIMPING PROCESS TO EASE STRESS ON THE CONDUCTORS

NOTES:
1. THIS FIGURE SUPERSEDES SHEET 1. 5B7 OF DWG. 803-5001027.

7.1.9 ENSURE THAT THE SHIELD GROUND WIRE IF TERMINATED TO A CONTACT IS INSERTED IN ITS PROPER LOCATION

7.1.10 UPON INSERTION OF EACH TWO ROWS OF CONTACTS, VISUALLY INSPECT THE CONTACTS TO FACE TO ENSURE THAT THE CONTACTS ARE PROPERLY INSERTED AND DO NOT APPEAR ANGLED. CONTACTS WHICH APPEAR IMPROPERLY INSERTED CONTACTS WILL APPEAR ANGLED WHEN COMPARED TO THE PROPERLY INSERTED CONTACTS

7.2 INSERT UNWIRED CONTACTS BACKED UP BY SEALING PLUGS IN ALL UNUSED CONTACT LOCATIONS (SEALING PLUGS CONFORMING TO MS2748B)

7.3 CONDUCT A VISUAL CHECK OF THE CONNECTOR AND VERIFY WIRE LOCATION AGAINST THE WIRING TABLE. ENSURE NO DEBRIS IS INSIDE SOCKET CONTACTS

8 CONTACT REMOVAL PROCEDURE (AS REQUIRED)

8.1 REMOVE THE CONNECTOR FROM THE DUMMY RECEPTACLE

8.2 USING THE EXTRACTION TOOL REMOVE ANY UNSEATED CONTACTS AS FOLLOWS

8.2.1 LAY THE WIRE OF THE CONTACT TO BE REMOVED ALONG THE SLOT OF THE TOOL LEAVING 1/2 INCH FROM THE END OF THE TOOL TO THE REAR OF THE CONNECTOR

8.2.2 SQUEEZE THE WIRE FIRMLY INTO THE TOOL BETWEEN THE THUMB AND FOREFINGER ABOUT 1/2 INCH FROM THE TIP

8.2.3 SLIDE THE TOOL DOWN ALONG THE WIRE AND INTO THE REAR CAVITY AND SLOWLY AROUND THE CONTACT UNTIL A POSITIVE RESISTANCE IS FELT CONTINUE UNTIL THE CONTACT IS FULLY LOCKED INTO THE CONNECTOR CONTACT RETENTION FINGERS

8.2.4 PULL BOTH THE TOOL AND CONTACT WIRE ASSEMBLY OUT OF THE CONNECTOR SIMULTANEOUSLY

NOTE DO NOT ROTATE THE TOOL AS THIS MAY DAMAGE THE INSERT

8.3 REINSERT ALL EXTRACTED CONTACTS

9 CONTACT PUSH TEST

9.1 USING THE COMBINATION TENSION/COMPRESSION GAGE (CHATILLON DPP 50 OR EQUIVALENT) PUSH TEST ALL CONTACTS TO EVALUATE CONTACT RETENTION (FIGURE 6)

9.1.1 ENSURE THE PROPER CONTACT RETENTION PROBE IS UTILIZED (FIGURE 7) SO THE RETENTION FINGERS WON'T BE DAMAGED

9.1.2 SEE TABLE 4 FOR PUSH TEST VALUES

9.1.3 THE FORCE SHALL BE APPLIED TO THE MATING END OF THE CONTACT IN A FIRM, SLOW MANNER AS INSTANTANEOUSLY APPLY THE FORCES LISTED IN TABLE 4

FIGURE 5B7. MIL-C-81511 series 3 and 4 individual contact release connector assembly procedure.

NOTES:
1. THIS FIGURE SUPERSEDES SHEET 5B3 OF DWG. 803-5001027.

- 10.7.2 FLARE THE GROSS SHIELD OVER THE TAPERED END OF THE RFI BELL. SHIELD SHALL NOT EXTEND BEYOND THE TAPERED END.
- 10.7.3 GENTLY FORCE THE CABLE TOWARD THE CONNECTOR PLUG UNTIL THE SHIELD COVERS THE TAPERED SURFACE ON THE RFI BELL.
- 10.7.4 SLIDE THE RFI RING (PC 4) ONTO THE RFI BELL WHILE APPLYING FORWARD PRESSURE ON THE CABLE.
- 10.7.5 COMPRESS THE SHIELD BETWEEN THE RFI BELL AND RING WITH A BACK SHEET (FIGURE 9) RING (SEE FIGURE 9).




FIGURE 9
RFI COMPONENTS

- 10.8 IF THE GROSS SHIELD IS FLOATED OR TERMINATED TO THE TAPERED END OF THE RFI BELL, THE RFI BELL SHALL BE REMOVED AND THE RFI BELL COMPONENTS (PC 3, 4) OVER THE PIGTAILS LOOPED GROUND WIRE AND SPARE CONDUCTORS.
- 10.9 SLIDE THE BACKSHELL SLEEVE (PC 5) OVER THE RFI ASSEMBLY AND SCREW THE SLEEVE ONTO THE ADAPTER.
- 10.10 TORQUE THE SLEEVE TO THE VALUE PROVIDED IN TABLE 5 FOR THE APPROPRIATE SHELL SIZE.
- 10.11 MARK A LINE ON THE CABLE 1/4-1/2 INCH ABOVE THE BACKSHELL SLEEVE (SEE FIGURE 10). CAREFULLY PUSH THE CABLE INTO THE BACKSHELL 1/4-1/2 INCH TO PROVIDE STRAIN RELIEF FOR THE CONDUCTORS AND MAINTAIN TENSION FOR THE NEXT FOUR STEPS. THIS LINE MARKED ON JACKET IS PARALLEL WITH SLEEVE END.
- 10.12 VERIFY THE CABLE JACKET IS POSITIONED COMPLETELY THROUGH THE GROMMET.
- 10.13 SLIDE THE SEALING HARDWARE WASHER (PC 6), GROMMET (PC 7), AND GROMMET FOLLOWER (PC 8) INTO POSITION BEHIND THE SLEEVE.
- 10.14 SCREW THE CABLE CLAMP (PC 9) ONTO THE SLEEVE AND TORQUE TO THE VALUE SPECIFIED IN TABLE 5.
- 10.15 ALTERNATELY TIGHTEN THE CLAMPING BAR SCREWS UNTIL REACHING THE TORQUE VALUE SPECIFIED IN TABLE 5. USE THE SAME TORQUE SPECIFICATION CONTROL OR EQUIVALENT (FIGURE 11).

NOTE: IF REQUIRED, INSTALL PERSONNEL SAFETY GROUND UNDER CLAMPING BAR SCREW.

10.16 REMOVE THE CONNECTOR FROM THE ASSEMBLY FIXTURE AND REMOVE THE DUMMY RECEPTACLE.

- 10.1 FOLD SPARE WIRES BACK ONE HALF THE DISTANCE BETWEEN THE CONNECTOR AND THE JACKET END.
- 10.2 SLIDE A 1 INCH LONG PIECE OF 1/4 INCH SHRINK TUBING OVER EACH FOLDED PAIR AND SHRINK IN PLACE.
- 10.3 LIGHTLY COAT THE THREADS OF EACH BACKSHELL PART WITH PETROLATUM (V.P. 236) JUST PRIOR TO USING.
- 10.4 POSITION AND LUBRICATE ALL O RINGS.
- 10.5 REMOVE THE WIRE HOOP AND LOOSEN THE FIXTURE CLAMP FROM THE ASSEMBLY FIXTURE.
- 10.6 SLIDE THE BACKSHELL ADAPTER DOWN THE CABLE STRAIN RELIEF AND CONNECTOR (FIGURE 8). TIGHTEN THE ADAPTER TO THE TORQUE VALUE PROVIDED IN TABLE 5 FOR THE APPROPRIATE SHELL SIZE.




FIGURE 8

TABLE 5

SHELL SIZE	CONNECTOR BACKSHELL & CABLE CLAMP TORQUE VALUE IN IN. / LBS (1.5 IN. / LBS)
8	45
9	45
10	45
11	45
12	45
13	50
14	50
15	50
16	50
17	60
18	60
19	60
20	70
21	70
22	70
23	70
24	70
25	70

- 10.7 IF THE GROSS SHIELD IS TO BE FLOATED OR TERMINATED TO A CONNECTOR CONTACT, PROCEED TO STEP 10.8. IF THE SHIELD IS TO BE TERMINATED TO THE BACKSHELL, RFI HARDWARE PROCEED AS FOLLOWS.
- 10.7.1 SLIDE THE RFI BELL (PC 3) AGAINST THE BACKSHELL ADAPTOR.




FIGURE 6
PUSH TEST ADAPTER TENSION/COMPRESSION GAGE

TABLE 4

CONTACT SIZE	PUSH TEST (POUNDS)
12	12
16	15
18	12
20	12
22	12
23	12
24	12
25	12




FIGURE 7
CONTACT RETENTION PROBES

CONTACT SIZE	A	B	C	D
23	±.010	±.001	±.001	±.005
16	±.006	±.006	±.006	±.006
18	±.006	±.006	±.006	±.006
12	±.006	±.006	±.006	±.006

- 9.2 REPLACE THE CONNECTOR IN THE DUMMY RECEPTACLE.

10. BACKSHELL ASSEMBLY

NOTE: THE FOLLOWING ASSEMBLY PROCEDURE IS BASED ON THE STANDARD HARDWARE CONFIGURATION DEPICTED IN FIGURE 1. VARIATIONS MAY OCCUR AND CAUSE MINOR DEVIATIONS FROM THIS PROCEDURE IF THIS SITUATION OCCURS THE MANUFACTURER'S ASSEMBLY INSTRUCTIONS SHOULD BE FOLLOWED.

SH 132317351

FIGURE 5B8. MIL-C-81511 series 3 and 4 individual contact release connector assembly procedure.

DOD-STD-2003-5 (NAVY)
24 JUNE 1987

NOTES:
1. THIS FIGURE SUPERSEDES SHEET 5B9 OF DWG 803-5001027.




FIGURE 10
MARKING THE CABLE

TABLE 6
CLAMP SCREWS

CABLE DIAMETER	TORQUE VALUE
0.0 TO 0.5 IN	25 ± IN / OZ
0.5 TO 1.0 IN	40 ± IN / OZ
1.0 TO 2.0 IN	50 ± IN / OZ

NOTE THESE TORQUE VALUES MUST BE MAINTAINED SO THAT A MINIMUM GAP OF NOT LESS THAN .005 IN EXISTS BETWEEN THE CLAMP SUPPORT AND CLAMP SADDLES




FIGURE 11

11. FINAL TEST AND DOCUMENTATION
- 11.1 USING ESTABLISHED SHIPYARD PROCEDURES PERFORM ELECTRICAL/ELECTRONIC CHECKS ON THE ASSEMBLED CONNECTOR
 - 11.2 INSTALL A PROTECTIVE DUST CAP ON THE CONNECTOR
 - 11.3 COMPLETE THE ASSEMBLY INSPECTION AND DOCUMENTATION AS REQUIRED BY LOCAL PROCEDURES
 - 12. IF NECESSARY LOCKWIRE THE CONNECTOR IN ACCORDANCE WITH FIGURE 5A24.

SH 132317352

FIGURE 5B9. MIL-C-81511 series 3 and 4 individual contact release connector assembly procedure.




FIGURE 5C1. MIL-C-5015 solder connector assembly procedure.

SH 132317354

NOTES:
1. THIS FIGURE SUPERSEDES SHEET 5C2 OF DWG. 803-5001027.

TABLE 2
CONNECTOR REAR THREAD AND CABLE CLAMP TORQUE IN IN./LBS (1.5 IN./LBS)

SHELL SIZE	TORQUE IN IN./LBS (1.5 IN./LBS)
8	45
8S	45
10	45
10S	45
10SL	45
12S	50
14	50
14S	50
16	60
16S	60
20	70
22	70
24	80
28	100
32	100
36	120
40	140
44	140
48	140

12.7 ALTERNATELY TIGHTEN THE CLAMPING BAR SCREWS UNTIL REACHING THE TORQUE VALUE SPECIFIED IN TABLE 2 USING A TORQUE SCREWDRIVER (TORQUE CONTROL OR EQUIVALENT). (FIGURE 6).

NOTE: IF REQUIRED, INSTALL PERSONNEL SAFETY GROUND UNDER CLAMPING BAR SCREW.

TABLE 3
CLAMP SCREWS

CABLE DIAMETER	TORQUE VALUE
0.0 TO 0.5 IN	25 ± 2 IN./OZ
0.5 TO 1.0 IN	40 ± 2 IN./OZ
1.0 TO 2.0 IN	50 ± 2 IN./OZ

NOTE: THESE TORQUE VALUES MUST BE MAINTAINED SO THAT A MINIMUM GAP OF NOT LESS THAN 1/16 IN. EXISTS BETWEEN THE CLAMP SUPPORT AND CLAMP SADDLES.




FIGURE 6

13 FINAL TEST AND DOCUMENTATION

13.1 USING ESTABLISHED SHIPYARD PROCEDURES PERFORM VISUAL AND ELECTRONIC CHECKS ON THE ASSEMBLED CONNECTOR.

13.2 INSTALL A PROTECTIVE DUST CAP ON THE CONNECTOR.

13.3 COMPLETE THE ASSEMBLY INSPECTION AND DOCUMENTATION AS REQUIRED BY LOCAL PROCEDURES.

14 IF NECESSARY LOCKWIRE THE CONNECTOR IN ACCORDANCE WITH FIGURE 5A24.




FIGURE 5
PROTECTING SOLDERED CONTACTS

9 A PIECE OF STIFF FIRE RETARDANT PAPER SHOULD BE INSERTED BETWEEN THE ROWS AS THEY ARE COMPLETED TO AVOID FINGERING OR WORK ALREADY ACCOMPLISHED (SEE FIGURE 5 FOR EXAMPLE).

10 REMOVE THE CABLE AND CONNECTOR FROM THE ASSEMBLY FIXTURE AND DUMMY RECEPTACLE.

11 CONDUCT A FINAL VISUAL CHECK OF THE CONNECTOR AND VERIFY WIRE LOCATION AGAINST THE WIRING TABLE. ENSURE NO DEBRIS IS INSIDE SOCKET CONTACTS.

12 BACKSHELL ASSEMBLY

NOTE: THE FOLLOWING ASSEMBLY PROCEDURE IS BASED ON THE NOMENCLATURE AND HARDWARE CONFIGURATION DEPICTED IN FIGURE 1. VARIATIONS MAY OCCUR IN THE HARDWARE CONFIGURATION. THIS PROCEDURE IF THIS SITUATION OCCURS THE MANUFACTURER'S ASSEMBLY INSTRUCTIONS SHOULD BE FOLLOWED.

12.1 SLIDE THE GROMMET (PC 2) OVER THE CONTACTS SO THAT IT IS FLUSH WITH THE CONNECTOR INSERT.

12.2 FILL ALL EMPTY GROMMET HOLES OF CLASS E, F, AND R CONNECTORS WITH SEALING PLUGS CORRESPONDING TO MS3187 OR MS27488.

12.3 FOLD SPARE WIRES BACK ONE-HALF THE DISTANCE BETWEEN THE CONNECTOR AND THE JACKET END.

12.4 SLIDE A 1 INCH LONG PIECE OF 1/4 INCH SHRINK SLEEVE OVER EACH FOLDED PAIR AND SHRINK IN PLACE.

12.5 LIGHTLY COAT THE THREADS OF THE ENDBELL (PC 4) WITH PENTOLATUM (VV-P-236) JUST PRIOR TO ASSEMBLY.

12.6 PLACE THE FERRULE (PC 3) AND ENDBELL (PC 4) OVER THE GROMMET. TIGHTEN USING A STRAP WRENCH AND TORQUE WRENCH TO THE VALUE SPECIFIED IN TABLE 2.

NOTE: CONNECTORS MANUFACTURED BY THE BENDIS CORPORATION DO NOT REQUIRE THE BACKSHELL TO BE TORQUED. THE ENDBELL COMPRESSES THE WIRE SEALING GROMMET BY ENSURING A METAL TO METAL CONTACT BETWEEN THE ENDBELL AND THE CONNECTOR BODY.




FIGURE 4
DETERMINING CONDUCTOR LENGTH

4.5 ROUTE THE INDIVIDUAL CONDUCTORS PER THE APPLICABLE WIRING TABLE. ENSURE THAT THE LONGEST ROUTED CONDUCTOR HAS SUFFICIENT LENGTH AT THE REQUIRED POSITION TERMINATION PRIOR TO CUTTING ANY CONDUCTOR (FIGURE 4C).

4.6 CUT THE CONDUCTORS AS REQUIRED TO PROVIDE EVEN CONDUCTOR LENGTHS AT THE CONNECTOR INSERT.

NOTE: LEAVE THE SPARES FULL LENGTH.

5 INSERT CONDUCTORS INTO PROPER HOLES OF GROMMET (PC 2). POSITION THE GROMMET NEXT TO THE CABLE JACKET.

TABLE 1

CONTACT SIZE	WIRE BARREL DEPTH	+0.063	-0.000
0	0.625		
4	0.625		
8	0.675		
12	0.375		
16	0.250		

6 STRIP THE INDIVIDUAL CONDUCTORS IN ACCORDANCE WITH SHEET 5A5 (FOR CONTACT WIRE BARREL DEPTHS SEE TABLE 1).

7 TIN THE CONDUCTORS IN ACCORDANCE WITH FIGURE 5A13 PRIOR TO TINNING.

7.2 IF REMARK SHORTENS A CONDUCTOR'S INITIAL LENGTH BEHIND THE JACKET, THE CONDUCTOR MUST BE CUT BACK AGAIN AND ALL LEADS RETRIMMED AND TINNED TO PRECLUDE STRESS.

8 SOLDER THE CONDUCTORS TO THE CONTACTS IN ACCORDANCE WITH FIGURE 5A14. THE OPERATOR SHOULD WITH THE CONTACT ROWS FURTHER AWAY FROM THE OPERATOR.

WARNING: DO NOT MOVE THE CONDUCTOR AFTER THE SOLDER JOINT HAS BEEN REMOVED OR A COLD SOLDER JOINT COULD RESULT.

SH 132317355

FIGURE 5C2. MIL-C-5015 solder connector assembly procedure.

DOD-STD-2003-5 (NAVY)
24 JUNE 1987

NOTES:


1. THIS FIGURE SUPERSEDES SHEET 5C3 OF DWG. 803-5001027.

- 1.8 VERIFY THAT THE CONTACTS FOR MIL-C-5015 MODIFIED CONNECTORS ARE 10-113239 SERIES FOR SHELL SIZE BS-40 AND 10-313672 (10-313673 SERIES FOR SOCKETS) SERIES. THE CURRENT BENDY CORPORATION PART NUMBERS.

2. PREPARE THE CABLE IN ACCORDANCE WITH FIGURE 5A1.
NOTE THE BACKSHELL CONFIGURATIONS DEPICTED IN FIGURES 1A, 1B, AND 1C ARE INTERCHANGEABLE BETWEEN CONNECTOR TYPES (SERIES).

- NOTE THIS PROCEDURE COVERS THE MS3400 SERIES (CONNECTOR/ARMOR TACT), MS3450 SERIES (CONNECTOR/REAR RELEASE CRIMP CONTACT), AND THE MIL-C-5015 (MODIFIED) CONNECTORS (BENDY 10-214 SERIES FRONT RELEASE CONTACTS)

1. VISUAL INSPECTION AND VERIFICATION
 - 1.1 DISASSEMBLE THE CONNECTOR/BACKSHELL ASSEMBLY
 - 1.2 VERIFY THAT THE CONNECTOR IS OF THE CORRECT TYPE AND CONFIGURATION FOR THE CABLE BEING TERMINATED IN ACCORDANCE WITH THE SYSTEM CABLING DIAGRAM
 - 1.3 VERIFY THAT THE BACKSHELL CONFIGURATION IS OF THE CORRECT TYPE AS SPECIFIED ON THE SYSTEM CABLING DIAGRAM
 - 1.4 VERIFY THAT ALL COMPONENTS PARTS OF THE CONNECTOR AND BACKSHELL HARDWARE ARE IDENTIFIED BY PART NUMBER AND CONFIGURATION (SEE FIGURE 1 FOR BACKSHELL CONFIGURATION). REFERENCE MIL-C-5015 FOR CONNECTOR MIL-C-85049 FOR BACKSHELL OR VENDOR DATA FOR SPECIFIC CONFIGURATIONS
 - 1.5 VISUALLY INSPECT THE COMPONENTS FOR DAMAGE SUCH AS DEFORMED PARTS, GOUGES, DAMAGES THREADS, CUT O-RINGS, BURRS, OR SURFACE DAMAGE
 - 1.6 VERIFY THAT FRONT RELEASE CONTACTS MEET THE REQUIREMENTS OF MIL-C-39029/44 FOR PIN AND MIL-C-39029/45 FOR SOCKET CONTACTS
 - 1.7 VERIFY THAT REAR RELEASE CONTACTS MEET THE REQUIREMENTS OF MIL-C-39029/46 FOR PIN AND MIL-C-39029/30 FOR SOCKET CONTACTS



TYPICAL REAR RELEASE CONNECTOR/GROSS SHELL TERMINATION BACKSHELL CONFIGURATION (MS3450 SERIES)
FIGURE 1B

TYPICAL FRONT RELEASE CONNECTOR/ARMOR TERMINATION BACKSHELL CONFIGURATION (MS3400 SERIES)
FIGURE 1A

SH 132317356

FIGURE 5C3. MIL-C-5015 (crimp) connector assembly procedure.

5 PRIOR TO CRIMPING, A CONTACT SIZING TEST SHOULD BE ACCOMPLISHED FOR ALL SOCKET CONTACTS (PIN CONTACTS PREVIOUSLY VERIFIED IN STEPS 1, 6, 17, AND 18 DO NOT NEED FURTHER TESTING)

NOTES:
1. THIS FIGURE SUPERSEDES SHEET 5C4 OF DWG. 803-5001027.

5.1 SOCKET CONTACTS SHOULD BE INSPECTED FOR PROPER SIZE USING A PIN CONTACT GAGE. CONFORMING TO MS2137 WHEN TESTED WITH THE TENSION-MANUAL CONTACT GAGE (CATALOG DPP-16 OR EQUIVALENT) SHOULD BE AS SPECIFIED IN TABLE 1




FIGURE 5
SOCKET CONTACT SIZING TEST

5.2 TERMINATE INDIVIDUAL CONDUCTORS WITH CRIMP CONFORMING TO MS2137 WHEN TESTED WITH THE TENSION-MANUAL CONTACT GAGE (CATALOG DPP-16 OR EQUIVALENT) SHOULD BE AS SPECIFIED IN TABLE 2

5.3 FOR PROPER CRIMPING, TOOL THE CONTACT REWORK SHORTENS A CONDUCTOR'S INITIAL LENGTH BY GREATER THAN 1/4 INCH THE JACKET MUST BE CUT BACK AGAIN AND ALL CONDUCTORS RETRIMMED TO PRECLUDE STRESS

3.1 INSERTION SETUP, Owing to the many possible variations of acceptable designs, only as particular type of acceptable assembly fixture are as follows:

A. A DIMMY RECEPTACLE WITHOUT CONNECTOR ASSEMBLY, OR THE CONNECTOR BEING WORKED ON SECURELY OR A CLAMPING DEVICE THAT WILL NOT DAMAGE THE CONNECTOR

B. A CABLE CLAMPING FIXTURE TO HOLD THE CABLE IN A SECURE FIXED RELATIONSHIP TO THE CONNECTOR AND TO MAINTAIN THE CONTACT INSERTION TOOL

THE ASSEMBLY FIXTURE REFERRED TO IN THIS PROCEDURE IS THAT DEVELOPED BY CHARLESTON NAVAL SHIPYARD (FIGURE 2).

ANGLE ADJUSTED TO BACKSHELL CONFIGURATION (I.E. STRAIGHT, 45°, 90°)




FIGURE 2
ASSEMBLY FIXTURE

3.2 USE OF THIS ASSEMBLY FIXTURE NEGATES THE NEED FOR A DIMMY RECEPTACLE (FIGURE 3 ILLUSTRATES HOW THE CONNECTOR IS FIRMLY SEATED IN THE CONNECTOR CLAMP)

3.3 SEAT THE CONNECTOR IN THE CONNECTOR CLAMP PLACE AND ADJUST THE WING NUTS TO SECURE IT IN PLACE

3.4 PLACE THE PREPARED CABLE IN THE FIXTURE CLAMP SO THAT THE FIRST CONTACTS TO BE INSERTED WILL BE IN CONTACT WITH THE CONTACTS OF THE CONNECTOR CLAMP

3.5 POSITION THE CABLE AT THE ANGLE SIMILAR TO THE BACKSHELL DESIGN (I.E. 45°, 90° OR STRAIGHT). SECURE THE CABLE IN THE FIXTURE CLAMP (FIGURE 4A) SH 132317357

3.6 POSITION THE CONNECTOR SO THAT THE CONTACT JACKET DISTANCES THAT MEASURED IN STEP 3.5 ARE IN THE CORRECT POSITION TO RELATE TO THE KEYWAY POSITION IN PROPER RELATIONSHIP TO THE BACKSHELL (FIGURE 4B)

3.7 ROUTE THE INDIVIDUAL CONDUCTORS PER THE POSITION DISTANCE AND ALIGN KEYWAY (FIGURE 4C). THE LONGEST ROUTED CONDUCTOR HAS SUFFICIENT LENGTH AT THE REQUIRED POSITION TERMINATION PRIOR TO CUTTING ANY CONDUCTOR (FIGURE 4C)




FIGURE 3
CONNECTOR SEATED IN ASSEMBLY FIXTURE

3.8 CUT THE CONDUCTORS AS REQUIRED TO PROVIDE THE CORRECT CONDUCTOR LENGTHS AT THE CONNECTOR INSERT.

NOTE: LEAVE THE SPIRES FULL LENGTH.

4. STRIP THE INDIVIDUAL CONDUCTORS IN ACCORDANCE WITH FIGURE 5A5 (FOR CONTACT WIRE BARREL DEPTHS - SEE TABLE 1).




FIGURE 4
DETERMINING CONDUCTOR LENGTH

NOTE: LEAVE THE SPIRES FULL LENGTH.

4. STRIP THE INDIVIDUAL CONDUCTORS IN ACCORDANCE WITH FIGURE 5A5 (FOR CONTACT WIRE BARREL DEPTHS - SEE TABLE 1).

TABLE 1*

CONTACT BARREL SIZE	WIRE BARREL DEPTH (IN)		MINIMUM SEPARATION FORCE (OZ)
	FRONT RELEASE	REAR RELEASE	
0	0.636-0.690	0.610-0.630	12
4	0.484-0.534	0.485-0.516	8
6	0.350-0.384	0.350-0.366	2.5
16	0.250-0.281	0.250-0.268	1.5
20	0.250-0.270	N/A	0.6

*SEE TABLE 4 FOR MIL-C-5015 MODIFIED CONNECTORS




FIGURE 5C4. MIL-C-5015 (crimp) connector assembly procedure.

TABLE 2*
FRONT RELEASE

CONTACT SIZE	BASIC CRIMPING TOOL	POSITIONER	DIE SET	LOCATOR
0-0	M22520/23-01	—	M22520/23-06	M22520/23-13
4-4	M22520/23-01	—	M22520/23-04	M22520/23-11
8-8	M22520/23-01	—	M22520/23-02	M22520/23-09
12-12	M22520/1-01	M22520/1-02 YELLOW	—	—
12-16	M22520/1-01	M22520/1-02 YELLOW	—	—
16-16	M22520/1-01	M22520/1-02 BLUE	—	—
16-20	M22520/1-01	M22520/1-02 BLUE	—	—

REAR RELEASE

CONTACT SIZE	BASIC CRIMPING TOOL	POSITIONER	DIE SET	LOCATOR
0-0	M22520/23-01	—	M22520/23-06	M22520/23-13
4-4	M22520/23-01	—	M22520/23-04	M22520/23-11
8-8	M22520/23-01	—	M22520/23-02	M22520/23-09
12-12	M22520/1-01	M22520/1-02 YELLOW	—	—
12-16	—	—	—	—
16-16	M22520/7-01 M22520/1-01	M22520/17-03 M22520/1-02 BLUE	—	—
16-22	—	—	—	—

*SEE TABLE 4 FOR MIL-C-5015 MODIFIED CONNECTOR

7. INSERTING CONTACTS

7.1 USING THE PROPER WIRING TABLE, PROPER INSERTING TOOL BASED ON CONTACT TYPE (SEE TABLE 3), AND WORKING FROM THE REAR TO THE FRONT OF THE CONNECTOR, INSERT CONTACTS INTO THE DESIGNATED LOCATIONS IN THE CONNECTOR AS FOLLOWS

TABLE 3*

CONTACT SIZE	FRONT RELEASE		REAR RELEASE	
	INSERTION TOOL	REMOVAL TOOL	INSERTION TOOL	REMOVAL TOOL
0-0	M81969/17-06	M81969/19-05	—	M81969/23-04
4-4	M81969/17-07	M81969/19-04	—	M81969/23-03
8-8	31969/17-06	M81969/19-03	—	M81969/23-02
12-12	31969/17-02	M81969/19-02	M81969/14-04	M81969/14-04
12-16	M81969/17-01	M81969/19-01	—	—
16-16	M81969/17-01	M81969/19-01	M81969/14-03	M81969/14-03
16-22	M81969/17-01	M81969/19-01	—	—

*SEE TABLE 4 FOR MIL-C-5015 MODIFIED CONNECTORS

SH 132317358

NOTE FOR MIL-C-5015 MODIFIED CONNECTORS WITH SOCKET CONTACTS: INSERT SOCKET CONTACTS INTO PILOT PINS IN THE CONNECTOR (TABLE 4) PROCEED TO STEP 7.1.4 FOR CONTACT INSERTION PROCEDURE

7.1.1 INSERT A WIRED CONTACT INTO THE REAR OF THE INSERT

7.1.2 SEAT THE CONTACT BY POSITIONING THE INSERTION TOOL AROUND THE REAR OF THE CONTACT SHOULDER WITH A SLIGHT ANGLE TOWARD THE CONTACT TO ASSURE A FIRM GRIP (FIGURE 6)




FIGURE 6
CONTACT INSERTION

7.1.2.1 PUSH THE CONTACT STRAIGHT INTO THE CONNECTOR WITH A FIRM, STEADY PRESSURE UNTIL THE CONTACT BOTTOMS

7.1.2.2 THE CONTACT SHOULDER PROVIDES A POSITIVE STOP

7.1.3 MOVE THE INSERTION TOOL BACK AWAY FROM THE CONTACT BEFORE SLIDING IT STRAIGHT UP ALONG THE WIRE INSULATION UNTIL IT CLEARS THE INSERT

7.1.3.1 LIGHTLY PULL ON INSERTED CONDUCTOR TO ENSURE CONTACT HAS LOCKED IN CONNECTOR

7.1.4 INSERT CONTACTS INTO THE MIL-C-5015 MODIFIED CONNECTOR AS FOLLOWS

WARNING: CONTACTS (SIZE 16) ARE FRAGILE COMPARED TO THE CONTACT INSERTION FORCE CARE MUST BE EXERCISED TO AVOID BENDING THE CONTACTS. BENT CONTACTS MUST BE REPLACED

7.1.4.1 GRIP THE CONTACT WITH THE INSERTION TOOL LOCATED CLOSE TO THE CONTACT ENGAGING END (FIGURE 7)

7.1.4.2 USING STRAIGHT FORWARD MOTION PUSH THE WIRED CONTACT INTO THE APPROPRIATE CAVITY OF THE INSERT UNTIL THE TOOL TIP IS IN CONTACT WITH THE INSERT

NOTES:
1. THIS FIGURE SUPERSEDES SHEET 5C5 OF DWG. 803-5001027.




FIGURE 7
CONTACT INSERTION

7.1.4.3 REPOSITION THE INSERTION TOOL BEHIND THE REAR SHOULDER OF THE CONTACT (FIGURE 8)

7.1.4.4 PUSH THE CONTACT INTO THE INSERT UNTIL SEATED




FIGURE 8
CONTACT INSERTION

7.1.4.5 REMOVE THE INSERTION TOOL BY MOVING IT BACK AWAY FROM THE CONTACT BEFORE SLIDING IT STRAIGHT UP ALONG THE WIRE INSULATION UNTIL IT CLEARS THE INSERT

7.1.4.6 LIGHTLY PULL ON INSERTED LEAD TO ENSURE CONTACT HAS LOCKED IN CONNECTOR

7.1.5 ADJUST THE FIXTURE CLAMP AS REQUIRED DURING THE INSERTION PROCESS TO EASE STRESS ON THE CONDUCTORS

7.1.6 ENSURE THAT THE SHIELD GROUND WIRE (IF TERMINATED TO A CONTACT) IS INSERTED IN ITS PROPER LOCATION

7.1.7 UPON INSERTION OF EACH TWO ROWS OF CONTACTS, CHECK THE CONTACTS TOP FACE TO ENSURE THAT THE CONTACTS ARE PROPERLY INSERTED

7.1.8 INSERT UNWIRED CONTACTS INTO ALL EMPLOYABLES IN THE CONNECTOR INSERT UTILIZING STEP 7


7.1.9 INSERT SEALING PLUGS MEETING THE REQUIREMENTS OF MILITARY STANDARD MS2187 OR MS27488 INTO ALL UNWIRED CONTACT HOLES

7.2 CONDUCT A VISUAL CHECK OF THE CONNECTOR AND VERIFY WIRE LOCATION AGAINST THE WIRING TABLE. ENSURE NO DEBRIS IS INSIDE SOCKET CONTACTS

FIGURE 5C5. MIL-C-5015 (crimp) connector assembly procedure.

NOTES:
1. THIS FIGURE SUPERSEDES SHEET 5C6 OF DRAWING NO. 903-5001027.

FIGURE 10
CONTACT REMOVAL (REAR RELEASE)




- 8.4 IF A CONTACT FAILS TO RESET AFTER THREE INSERTION ATTEMPTS REPLACE THE OFFENDING CONTACT IF THE SAME CONTACT LOCATION CONTINUES TO GIVE DIFFICULTY, THE CONNECTOR IS PROBABLY DAMAGED OR FAULTY AND MUST BE REPLACED.
- 8.5 REMOVE THE CONNECTOR FROM THE CONNECTOR CLAMP IF NOT PREVIOUSLY ACCOMPLISHED
- 9 CONTACT PUSH TEST
- 9.1 USING THE COMBINATION TENSION/COMPRESSION GAGE (CHAILLON DPP 160 OR EQUIVALENT) PUSH TEST ALL CONTACTS TO EVALUATE CONTACT RETENTION (FIGURE 11)

TABLE 4 (BENDIX P/N 9)

CONTACT SIZE	CRIMPING TOOL	POSITIONER TOOL	INSERTION TOOL	EXTRACTION* TOOL TIP		SOCKET CONTACT/PILOT PIN	WIRE STRIP LENGTH (IN)
				PIN	SOCKET		
16	11-7295	11-7771	11-7345	11-3697	11-3698	10-242758-16	5/16
12	11-7295	11-7771	11-7082	11-3676	11-3698	10-242758-12	5/16
8	11-7838-1	11-7740-5 (LOCATOR)	11-8220	11-8252	11-8251	10-242758-8	9/16

*EXTRACTION TOOL TIPS ARE USED IN CONJUNCTION WITH THE 11-8911 HANDLE ASSEMBLY

- 8 CONTACT REMOVAL PROCEDURE (AS REQUIRED)
- 8.1 CONDUCT A VISUAL INSPECTION OF THE CONNECTOR FACE TO IDENTIFY ANY UNSEATED CONTACTS
- 8.2 REMOVE THE CONNECTOR FROM THE CONNECTOR CLAMP AND USING THE EXTRACTION TOOL REMOVE ANY UNSEATED CONTACTS AS FOLLOWS
- 8.2.1 FRONT RELEASE (MS3400 SERIES)
 - 8.2.1.1 SELECT THE CORRECT REMOVAL TOOL FROM TABLE 3
 - 8.2.1.2 ENCLOSE THE FRONT OF THE CONTACT WITH THE EXTRACTION TOOL (FIGURE 9 A)



9 B REMOVING THE CONTACT

FIGURE 9
CONTACT REMOVAL (FRONT RELEASE)

SH 132317359

- 8.2.1.3 PUSH WITH THE REAR OF THE TOOL AND FULLY BOTTOMED THE TOOL TO THE REAR OF THE TOOL IN A CLOCKWISE DIRECTION.
- 8.2.1.4 WITH THE TOOL TIP BOTTOMED, SLIDE THE TOOL TIP SLEEVE FORWARD MOVING THE CONTACT BACK THROUGH THE SEALING BARRIERS (FIGURE 9 B)
- NOTE FOR SIZE 6 WIRE AND LARGER ASSIST THE TOOL BY PUSHING BACK ON THE WIRE WHILE USING THE THRUST SLEEVE
- 8.2.2 REAR RELEASE (MS3450 SERIES)
 - 8.2.2.1 SELECT THE CORRECT REMOVAL TOOL FROM TABLE 3
 - 8.2.2.2 LAY THE WIRE OF THE CONTACT TO BE REMOVED ALONG THE SLOT FROM THE END OF THE TOOL TO THE REAR OF THE CONNECTOR (FIGURE 10 A)
 - 8.2.2.3 SQUEEZE THE WIRE FIRMLY INTO THE REAR OF THE CONTACT WITH THE FOREFINGER ABOUT 1/2 INCH FROM THE TIP (FIGURE 10 A)
 - 8.2.2.4 SLIDE THE TOOL DOWN ALONG THE WIRE AND INTO THE REAR CAVITY AND SLOWLY AROUND THE CONTACT UNTIL THE CONTACT FEELER (FIGURE 10 B) IS FELT (FIGURE 10 B) CONTINUE UNTIL THE TOOL IS BOTTOMED. UNLOCKING CONNECTOR CONTACT RETENTION FINGERS
- NOTE DO NOT ROTATE THE TOOL AS THIS MAY DAMAGE THE INSERT
- 8.2.2.5 PULL BOTH THE TOOL AND CONTACT WIRE ASSEMBLY OUT OF THE CONNECTOR
- 8.2.3 MIL-C-5015 MODIFIED (10-214 SERIES)
 - 8.2.3.1 SELECT THE CORRECT REMOVAL TOOL FROM TABLE 4
 - 8.2.3.2 POSITION THE TOOL TIP IN (SOCKET OR PIN) OVER THE MATING FRONT END OF THE CONTACT TO BE REMOVED
 - 8.2.3.3 PUSH THE CONTACT THROUGH THE INSERT
 - 8.2.3.4 REMOVE THE REMOVAL TOOL AND INSPECT THE CONNECTOR INSERT FOR DAMAGE
- 8.3 REINSERT ALL EXTRACTED CONTACTS

NOTES:
1. THIS FIGURE SUPERSEDES SHEET 5C7 OF DRAWING NO. 803-5001027.

- 10.7.1 SLIDE THE SLEEVE ASSEMBLY (PC 2) DOWN THE CABLE AND SCREW IT ON THE CONNECTOR PLUG (PC 1).
- 10.7.2 TORQUE THE SLEEVE ASSEMBLY TO THE VALUE PROVIDED IN TABLE 6 FOR THE APPROPRIATE SHELL SIZE.
- 10.7.3 IF THE GROSS SHIELD IS TO BE FLARED OR TERMINATED TO A CONNECTOR CONTACT, PROCEED TO STEP 10.7.4. IF THE SHIELD IS TO BE FLARED, THE BACKSHELL RFI HARDWARE PROCEED AS FOLLOWS:
10.7.3.1 SLIDE THE RFI BELL (PC 3) AGAINST THE SLEEVE ASSEMBLY.
10.7.3.2 FLARE THE GROSS SHIELD OVER THE TAPERED END OF THE RFI BELL.
10.7.3.3 GENTLY FORCE THE CABLE TOWARD THE CONNECTOR PLUG UNTIL THE PIGTAIL COVERS THE TAPERED SURFACE ON THE RFI BELL.
10.7.3.4 SLIDE THE RFI RING (PC 4) ONTO THE RFI BELL WHILE APPLYING FORWARD PRESSURE ON THE CABLE.
10.7.3.5 COMPRESS THE SHIELD BETWEEN THE RFI BELL AND RFI RING WITH A FORWARD MOTION ON THE RFI RING.
- 10.7.4 SLIDE THE RFI BACKSHELL COMPONENTS (PC 3, 4) OVER THE PIGTAILS, LOOPED GROUND WIRE AND SPARE CONDUCTORS.
- 10.7.5 SLIDE THE REAR ADAPTER (PC 5) OVER THE SLEEVE ASSEMBLY AND SCREW IT ONTO THE SLEEVE ASSEMBLY.
- 10.7.6 TORQUE THE REAR ADAPTER TO THE VALUE PROVIDED IN TABLE 6 FOR THE APPROPRIATE SHELL SIZE.
- 10.7.7 MARK A LINE ON THE CABLE 1/4 ± 1/2" ABOVE THE BACKSHELL REAR ADAPTER (SEE FIGURE 12). CAREFULLY PUSH THE CABLE INTO THE BACKSHELL 1/4 ± 1/2" INCH AND MARK THE POSITION FOR THE MARKING TO HOLD AT THIS POSITION FOR THE NEXT TWO STEPS. (LINE MARKED ON JACKET IS PARALLEL WITH END OF REAR ADAPTER)




FIGURE 12
MARKING THE CABLE

FIGURE 5C7. MIL-C-5015 (crimp) connector assembly procedure.

- 10.6 ARMOR TERMINATION BACKSHELL CONFIGURATION (FIGURE 1 A)
NOTE: IF THE CABLE IS UNARMORED, EXCHANGE THE GROMMET AND GROMMET FOLLOWER TO FOLLOW RULES OF FIGURE 1(A) WITH THE INNER AND OUTER SHEATHING SEQUENCE.
10.6.1 SLIDE THE SLEEVE ASSEMBLY (PC 2) DOWN THE CABLE AND SCREW ON THE CONNECTOR PLUG (PC 1). TIGHTEN THE SLEEVE ASSEMBLY TO THE TORQUE VALUE PROVIDED IN TABLE 6 FOR THE APPROPRIATE SHELL SIZE.
10.6.2 SLIDE THE GROMMET (PC 3) AND GROMMET FOLLOWER (PC 4) INTO THE SLEEVE ASSEMBLY.
10.6.2.1 THE CABLE JACKET MUST EXTEND BEYOND THE GROMMET TO ASSURE PROPER SEAL TO GROMMET SEAL.
10.6.3 ENGAGE THE REAR ADAPTER (PC 5) WITH THE SLEEVE ASSEMBLY AND TIGHTEN TO A TORQUE VALUE PROVIDED IN TABLE 6 FOR THE APPROPRIATE SHELL SIZE.
10.6.4 SLIDE THE INNER FERRULE (PC 6) INTO THE REAR ADAPTER (PC 5) AND SEAT ON THE INNER SHOULDER.
10.6.5 FLARE THE ARMOR OVER THE INNER SHOULDER.
10.6.6 GENTLY FORCE THE ARMOR TOWARD THE CONNECTOR UNTIL THE ARMOR COVERS THE TAPERED SURFACE OF THE INNER FERRULE.
10.6.7 INSERT THE OUTER FERRULE (PC 7) INTO THE REAR ADAPTER AND SCREW IT ONTO THE REAR ADAPTER WITH A TWISTING MOTION.
10.6.8 SCREW THE CABLE CLAMP ASSEMBLY (PC 8) OVER THE REAR ADAPTER AND HAND TIGHTEN.
10.6.9 USING A STRAP WRENCH AND TORQUE WRENCH TIGHTEN THE CABLE CLAMP TO THE VALUE PROVIDED IN TABLE 6 FOR THE APPROPRIATE SHELL SIZE.

TABLE 6

SHELL SIZE	CONNECTOR REAR THREAD TORQUE IN IN. / LBS (IN. / LBS)
8	45
8S	45
10S	45
10SL	45
12	50
12S	50
14	50
14S	50
16	60
16S	60
18	70
20	70
22	70
28	80
32	100
36	120
40	140
44	140
48	140

10.6.10 PROCEED TO STEP 10.7.11.

10.7 GROSS SHIELD TERMINATION BACKSHELL CONFIGURATION (FIGURE 1 B).




FIGURE 11
PUSH TEST ADAPTER, TENSION/COMPRESSION GAGE

- 9.1.1 SEE TABLE 5 FOR PUSH TEST VALUES.
- 9.1.2 THE FORCE SHALL BE APPLIED TO THE MATING END OF THE CONTACT IN A FIRM SLOW MANNER DO NOT INSTANTANEOUSLY APPLY THE FORCES LISTED IN TABLE 5.
- 9.1.3 ENSURE THE CORRECT PUSH TEST ADAPTER / PROBE IS UTILIZED FOR THE CONTACT SIZE BEING TESTED.

TABLE 5

CONTACT SIZE	PUSH TEST VALUE (LBS)	CLASS D
0-0	75	100
4-8	50	100
12-12	30	50
12-16	30	50
16-16	25	50
16-22	25	50

*EXCEPT CLASS D

10 BACKSHELL ASSEMBLY

- NOTE: THE FOLLOWING ASSEMBLY PROCEDURE IS BASED ON THE NOMENCLATURE AND HARDWARE CONFIGURATION DEPICTED IN FIGURE 1. VARIATIONS MAY OCCUR AND CAUSE MINOR DEVIATIONS FROM THIS PROCEDURE. IF SUCH DEVIATIONS OCCUR, THE MANUFACTURER'S ASSEMBLY INSTRUCTIONS SHOULD BE FOLLOWED.
- 10.1 FOLD SPARE WIRES BACK ONE-HALF THE DISTANCE BETWEEN THE CONNECTOR AND THE JACKET END.
- 10.2 SLIDE A 1 INCH LONG PIECE OF APPROPRIATELY SIZED SHRINK TUBING OVER EACH FOLDED PAIR AND SHRINK IN PLACE.
- 10.3 LIGHTLY COAT THE THREAD OF EACH BACKSHELL PART WITH PETROLATUM (V-P-238) JUST PRIOR TO USING.
- 10.4 POSITION AND LUBRICATE ALL O-RINGS.
- 10.5 LOOSEN THE FIXTURE CLAMP ON THE ASSEMBLY FIXTURE.

SH 132317360

NOTES:
1. THIS FIGURE SUPERSEDES SHEET 5C8 OF DWG. 803-5001027.

- 10 8 5 SLIDE THE GROMMET (PC 3) AND GROMMET FOLLOWER (PC 4) INTO POSITION BEHIND THE REAR ADAPTER
- 10 8 6 SCREW THE CABLE CLAMP (PC 5) ONTO THE REAR ADAPTER AND TORQUE TO THE VALUE SPECIFIED IN TABLE 6
- 10 8 7 ALTERNATELY TIGHTEN THE CLAMPING BAR SCREWS UNTIL REACHING THE TORQUE VALUE SPECIFIED IN TABLE 6. UNDER TORQUE, THE TORQUE SCREWDRIVER (TORQUE CONTROL OR EQUIVALENT) (FIGURE 13). ENSURE A MINIMUM GAP OF 1/16 INCH EXISTS BETWEEN THE CLAMP SUPPORT AND CLAMP SADDLES
- NOTE: IF REQUIRED, INSTALL PERSONNEL SAFETY GROUND UNDER CLAMPING BAR SCREW
- 10 8 8 REMOVE THE CONNECTOR FROM THE ASSEMBLY FIXTURE
- 11 FINAL TEST AND DOCUMENTATION
- 11 1 USING ESTABLISHED SHIPYARD PROCEDURES PERFORM ELECTRICAL/ELECTRONIC CHECKS ON THE ASSEMBLED CONNECTOR
- 11 2 INSTALL A PROTECTIVE DUST CAP ON THE CONNECTOR
- 11 3 COMPLETE THE ASSEMBLY INSPECTION AND DOCUMENTATION AS REQUIRED BY LOCAL PROCEDURES
- 12 IF NECESSARY, LOCKWIRE THE CONNECTOR IN ACCORDANCE WITH FIGURE 5A21

- 10 7 8 VERIFY THE CABLE JACKET IS POSITIONED COMPLETELY THROUGH THE GROMMET
- 10 7 9 SLIDE THE GROMMET (PC 6) AND GROMMET FOLLOWER (PC 7) INTO POSITION BEHIND THE REAR ADAPTER
- 10 7 10 SCREW THE CABLE CLAMP (PC 8) ONTO THE REAR ADAPTER AND TORQUE TO THE VALUE SPECIFIED IN TABLE 6
- 10 7 11 ALTERNATELY TIGHTEN THE CLAMPING BAR SCREWS UNTIL REACHING THE TORQUE VALUE SPECIFIED IN TABLE 7, USING A TORQUE SCREWDRIVER (TORQUE CONTROL OR EQUIVALENT) (FIGURE 13)
- NOTE: IF REQUIRED, INSTALL PERSONNEL SAFETY GROUND UNDER CLAMPING BAR SCREW
- 10 7 12 REMOVE THE CONNECTOR FROM THE ASSEMBLY FIXTURE

TABLE 7
CLAMP SCREWS

CABLE DIAMETER	TORQUE VALUE
0.0 TO 0.5 IN	25 ± 2 IN./OZ
0.5 TO 1.0 IN	40 ± 2 IN./OZ
1.0 TO 2.0 IN	50 ± 2 IN./OZ

NOTE: THESE TORQUE VALUES MUST BE MAINTAINED SO THAT A MINIMUM GAP OF NOT LESS THAN 1/16 INCH EXISTS BETWEEN THE CLAMP SUPPORT AND CLAMP SADDLES




FIGURE 13


- 10 7 13 PROCEED TO STEP 11
- 10 8 MIL-C-5015 MODIFIED CONNECTOR (10-214 SERIES) (FIGURE 1 C)
- 10 8 1 SLIDE THE REAR ADAPTER (PC 2) DOWN THE CABLE AND SCREW IT ON THE CONNECTOR PLUG (PC 1)
- 10 8 2 TORQUE THE REAR ADAPTER TO THE VALUE SPECIFIED IN TABLE 6 FOR THE APPROPRIATE SHELL SIZE
- 10 8 3 MARK A LINE ON THE CABLE 1/4 INCH ABOVE THE REAR ADAPTER (TO THE REAR ADAPTER 1/4 INCH AND MAINTAIN CONTINUOUS PRESSURE TO HOLD AT THIS POSITION FOR THE NEXT FOUR STEPS. (LINE MARKED ON JACKET IS PARALLEL WITH END OF REAR ADAPTER)
- 10 8 4 VERIFY THE CABLE JACKET IS POSITIONED COMPLETELY THROUGH THE GROMMET

FIGURE 5C8. MIL-C-5015 (crimp) connector assembly procedure.

- NOTE THIS PROCEDURE COVERS SERIES 1 CONNECTORS WHICH HAVE SOLDER OR FRONT RELEASE CRIMP CONTACTS, AND SERIES 2 CONNECTORS WHICH HAVE REAR RELEASE CRIMP CONTACTS
1. VISUAL INSPECTION AND VERIFICATION
 - 1.1 DISASSEMBLE THE CONNECTOR/BACKSHELL ASSEMBLY.
 - 1.2 VERIFY THAT THE CONNECTOR IS OF THE CORRECT TYPE AND CONFIGURATION FOR THE CABLE BEING TERMINATED IN ACCORDANCE WITH THE SYSTEM CABLING DIAGRAM.
 - 1.3 VERIFY THAT THE BACKSHELL CONFIGURATION IS OF THE CORRECT TYPE AS SPECIFIED ON THE SYSTEM CABLING DIAGRAM.
 - 1.4 VERIFY THAT ALL COMPONENTS PARTS OF THE CONNECTOR AND BACKSHELL HARDWARE ARE PRESENT (SEE FIGURE 1 FOR A TYPICAL CONNECTOR/BACKSHELL CONFIGURATION). REFERENCE MIL SPEC MIL-C-26482 FOR CONNECTOR AND BACKSHELL CONFIGURATIONS.
 - 1.5 VISUALLY INSPECT THE COMPONENTS FOR DAMAGE SUCH AS DEFORMED PARTS, GOUGES, DAMAGED THREADS, CUT O-RINGS, BURRS, OR SURFACE DAMAGE.
 - 1.6 VERIFY THAT THE SERIES 1 CRIMP PIN CONTACTS CONFORM TO MIL-C-39029/31, SERIES 1 CRIMP SOCKET CONTACTS CONFORM TO MIL-C-39029/32, SERIES 2 CRIMP PIN CONTACTS CONFORM TO MIL-C-39029/31, AND SERIES 2 CRIMP SOCKET CONTACTS CONFORM TO MIL-C-39029/32. VERIFY THAT THE CONTACTS CONFORM TO THE CORRECT SIZE AND TYPE FOR THE CONNECTOR BEING ASSEMBLED.
 - 1.7 IF THE CONDUCTORS ARE RETWISTED DURING LEAD PREPARATION, THE CONTACTS MUST BE AS TIGHT AS ORIGINALLY CONSTRUCTED. THE NATURAL LAY OF THE CONDUCTOR IS MAINTAINED, AND THE CONDUCTORS WILL FIT INSIDE THE CONTACT BARREL.
 2. PREPARE THE CABLE IN ACCORDANCE WITH FIGURE 5A
 - 2.1 THE GROMMET (PC 2) IS DESIGNED TO FIT AROUND INDIVIDUAL CONDUCTORS ON CLASSES E AND F AND THEREFORE CANNOT BE PLACED ON THE CABLE UNTIL THE INDIVIDUAL CONDUCTORS HAVE BEEN EXPOSED IN THE CABLE.
 3. INSERTION SETUP OWING TO THE MANY POSSIBLE VARIATIONS FOR ACCEPTABLE TOOLING FOR CONTACT INSERTION AND SOLDERING, NO SPECIFICATION IS MADE AS TO WHICH TOOLING IS TO BE USED. THE FOLLOWING ARE THE FOLLOWING FOR AN ACCEPTABLE ASSEMBLY FIXTURE ARE AS FOLLOWS
 - A. A DUMMY RECEPTACLE, WITHOUT CONNECTOR CONTACTS, WHICH THE CLAMPING DEVICE WILL LOCK ON SECURELY OR CLAMPING DEVICE THAT WILL NOT DAMAGE THE CONNECTOR.

- B. A CABLE CLAMPING FIXTURE TO HOLD THE CABLE IN A SECURE FIXED RELATIONSHIP TO THE CONNECTOR WHILE PERMITTING ACCESS TO THE REAR FACE OF THE CONNECTOR FOR THE CONTACT INSERTION TOOL OR SOLDERING IRON.
 - C. A DEVICE FOR HOLDING THE WIRE BUNDLE OUT OF THE WORK AREA.
- THE ASSEMBLY FIXTURE REFERRED TO IN THIS PROCEDURE IS THAT DEVELOPED BY CHARLESTON NAVAL SHIPYARD (FIGURE 2).
- NOTE EQUIVALENT TOOLING FROM ALTERNATE SOURCES IS PERMISSIBLE, HOWEVER THE USE OF OTHER TOOLS MAY AFFECT THE PROCEDURAL STEPS OUTLINED BELOW.
- 3.1 SECURE THE ASSEMBLY FIXTURE TO A VISE OR SIMILAR HOLDING DEVICE IN ORDER TO PROVIDE A STABLE WORK AREA.
 - 3.2 USE OF THIS ASSEMBLY FIXTURE NEGATES THE NEED FOR A DUMMY RECEPTACLE, FIGURE 3 ILLUSTRATES HOW THE CONNECTOR IS FIRMLY SEATED IN THE CONNECTOR CLAMP.
 - 3.3 SEAT THE CONNECTOR IN THE CONNECTOR CLAMP AND ADJUST THE WING NUTS TO SECURE IT IN PLACE.

NOTES:
1. THIS FIGURE SUPERSEDES SHEET 5D1 OF DWG. 803-5001027.




SH 132317362

FIGURE 5D1. MIL-C-26482 connector assembly procedure.

NOTES:
1. THIS FIGURE SUPERSEDES SHEET 5D2 OF DWG. 803-5001027.

TABLE 2

CONTACT SIZE	PIN CONTACT		SOCKET CONTACT	
	BASIC CRIMPING TOOL	POSITIONER	BASIC CRIMPING TOOL	POSITIONER
20	M22520/7-01	M22520/7-03	M22520/7-01	M22520/7-02
	M22520/1-01	M22520/1-02	M22520/1-01	M22520/1-02
16	M22520/2-01	M22520/2-02	M22520/2-01	M22520/2-02
	M22520/1-01	M22520/1-02	M22520/1-01	M22520/1-02
12	M22520/7-01	M22520/7-03	M22520/7-01	M22520/7-03
	M22520/1-01	M22520/1-02	M22520/1-01	M22520/1-02



5.4 PRIOR TO CRIMPING A CONTACT SIZING TEST SHOULD BE ACCOMPLISHED FOR ALL SOCKET CONTACTS (PIN CONTACTS PREVIOUSLY VERIFIED IN STEP 1.6 DO NOT NEED FURTHER TESTING).

5.4.1 SOCKET CONTACTS SHOULD BE INSPECTED FOR PROPER SIZE USING A PIN CONTACT GAGE CONFORMING TO MS3197. WHEN TESTED, THE MINIMUM SEPARATION FORCE MEASURED WITH A MINIMUM SEPARATION SPEED SHALL BE AS SPECIFIED IN TABLE 1.

5.4.2 TERMINATE INDIVIDUAL CONDUCTORS WITH CRIMP CONTACTS IN THE WORK SHORTS SECTION. INITIAL LENGTH BY GREATER THAN 1/4 INCH THE JACKET MUST BE CUT BACK AGAIN AND ALL CONDUCTORS RETRIMMED TO PRECLUDE STRESS.

TABLE 3

CONTACT SIZE	PIN CONTACT		SOCKET CONTACT	
	BASIC CRIMPING TOOL	POSITIONER	BASIC CRIMPING TOOL	POSITIONER
20	M22520/1-01	M22520/1-02	M22520/2-01	M22520/2-02
	M22520/2-01	M22520/2-02	M22520/1-01	M22520/1-02
16	M22520/1-01	M22520/1-02	M22520/1-01	M22520/1-02
	M22520/7-01	M22520/7-03	M22520/7-01	M22520/7-03
12	M22520/1-01	M22520/1-02	M22520/1-01	M22520/1-02




FIGURE 2
ASSEMBLY FIXTURE




FIGURE 3
CONNECTOR SEATED IN ASSEMBLY FIXTURE

3.4 PLACE THE PREPARED CABLE IN THE FIXTURE CLAMP SO THAT THE FIRST CONTACTS TO BE INSERTED/SOLDERED WILL BE AT THE BACK OF THE CONNECTOR AS IT IS HELD IN THE CONNECTOR CLAMP.

3.5 POSITION THE CABLE AT THE ANGLE SIMILAR TO THE BACKSHELL DESIGN (I.E. 45° OR STRAIGHT). SECURE THE CABLE IN THE FIXTURE CLAMP (FIGURE 4A).

3.6 POSITION THE CONNECTOR SO THAT THE CONNECTION TO CABLE JACKET DISTANCE IS THAT MEASURED IN STEP 9.2 OF FIGURE 5A). ROTATE THE CONNECTOR TO ALIGN THE KEYWAY POSITION WITH PROPER RELATIONSHIP TO THE BACKSHELL (FIGURE 4B).

3.7 ROUTE THE INDIVIDUAL CONDUCTORS PER THE APPLICABLE WIRING DIAGRAM. THAT THE APPLICABLE WIRING DIAGRAM HAS SUFFICIENT LENGTH AT THE REQUIRED POSITION TERMINATION PRIOR TO CUTTING ANY CONDUCTOR (FIGURE 4C).

3.8 CUT THE CONDUCTORS AS REQUIRED TO PROVIDE EVEN CONDUCTOR LENGTHS AT THE CONNECTOR INSERT.

4. STRIP THE INDIVIDUAL CONDUCTORS IN ACCORDANCE WITH TABLE 1.4S (FOR CONTACT WIRE BARREL DEPTHS SEE TABLE 1).

TABLE 1
WIRE BARREL DEPTH

CONTACT SIZE	SERIES 1 (IN.)		SERIES 2 (IN.)		MINIMUM SEPARATION FORCE (LBS.)
	SOLDER CRIMP	SOCKET CRIMP	PIN	SOCKET	
20	125	250	157	186	0.6
	270	270	186	186	
16	188	238	250	250	1.5
	281	281	284	284	
12	188	238	250	250	2.5
	281	281	284	284	

5. TERMINATE THE CONDUCTORS FOR SERIES 1 CONNECTORS AS FOLLOWS:

5.1 INSERT CONDUCTORS INTO THE PROPER HOLES OF THE WIRE SEALING GROMMET (PC 2). POSITION THE GROMMET NEXT TO THE CABLE JACKET.

5.2 COMPLETE THE FOLLOWING STEPS FOR SOLDER CONTACTS:

5.2.1 TIN THE CONDUCTORS IN ACCORDANCE WITH FIGURE 5A13.

5.2.1.1 ENSURE CONDUCTOR STRANDS ARE TWISTED TIGHT.

5.3 COMPLETE THE FOLLOWING STEPS FOR CRIMP CONTACTS:

5.3.1 SELECT THE CORRECT CRIMPING TOOL FROM TABLE 2 FOR SERIES 1 CONNECTORS AND TABLE 3 FOR SERIES 2 CONNECTORS.

6 1 2 4 1 SLIGHTLY PULL ON INSERT. ENOUGH TO ENSURE CONTACT HAS LOCKED IN CONTACTOR.

6 2 ACCOMPLISH THE FOLLOWING STEPS FOR SERIES 2 CONNECTORS

NOTE ADJUST THE ASSEMBLY FIXTURE AS REQUIRED DURING THE INSERTION PROCESS TO EASE STRESS ON THE CONDUCTORS

NOTES:
1. THIS FIGURE SUPERSEDES SHEET 503 OF DWG. 803-5001027.

6 1 2 3 SEAT THE CONTACT SHOULDER AGAINST THE TIP OF THE TOOL

6 2 2 LAY THE WIRE WITH CONTACT ATTACHED AGAINST THE SLOT OF THE CORRECT INSERTION TOOL AND SNAP INTO THE TOOL (SEE FIGURE 8)

6 2 3 SEAT THE CONTACT SHOULDER AGAINST THE TIP OF THE TOOL

6 2 4 PUSH THE CONTACT INTO THE PROPER OPENING AT THE REAR OF THE INSERT BY APPLYING LIGHT TO STEADY FORWARD PRESSURE UNTIL THE CONTACT BOTTOMS

NOTE DO NOT TWIST THE TOOL

6 2 5 REMOVE THE TOOL BY SLIDING IT STRAIGHT BACK ALONG THE WIRE UNSNAP THE TOOL FROM THE WIRE WHEN CLEAR OF THE INSERT

6 1 2 1 SELECT THE PROPER INSERTION TOOL FROM TABLE 5

6 2 2 LAY THE WIRE WITH CONTACT ATTACHED AGAINST THE SLOT OF THE CORRECT INSERTION TOOL AND SNAP INTO THE TOOL (SEE FIGURE 8)

6 2 3 SEAT THE CONTACT SHOULDER AGAINST THE TIP OF THE TOOL

6 2 4 PUSH THE CONTACT INTO THE PROPER OPENING AT THE REAR OF THE INSERT BY APPLYING LIGHT TO STEADY FORWARD PRESSURE UNTIL THE CONTACT BOTTOMS

NOTE DO NOT TWIST THE TOOL

6 2 5 REMOVE THE TOOL BY SLIDING IT STRAIGHT BACK ALONG THE WIRE UNSNAP THE TOOL FROM THE WIRE WHEN CLEAR OF THE INSERT

TABLE 5

SOCKET CONTACT		REMOVAL TOOL	
CONTACT SIZE	INSERTION TOOL	WIRED CONTACT	UNWIRED CONTACT
20	M81969/8-05 M81969/14-02	M81969/8-05 M81969/14-02	M81969/30-05
16	M81969/8-07 M81969/14-03	M81969/8-08 M81969/14-03	M81969/30-06
12	M81969/8-09 M81969/14-04	M81969/8-10 M81969/14-04	M81969/30-07

PIN CONTACT

SOCKET CONTACT		REMOVAL TOOL	
CONTACT SIZE	INSERTION TOOL	WIRED CONTACT	UNWIRED CONTACT
20	M81969/14-02	M81969/14-02	M81969/30-05
16	M81969/14-03	M81969/14-03	M81969/30-06
12	M81969/14-04	M81969/14-04	M81969/30-07

6 2 1 SELECT THE PROPER INSERTION TOOL FROM TABLE 5

6 2 2 LAY THE WIRE WITH CONTACT ATTACHED AGAINST THE SLOT OF THE CORRECT INSERTION TOOL AND SNAP INTO THE TOOL (SEE FIGURE 8)

6 2 3 SEAT THE CONTACT SHOULDER AGAINST THE TIP OF THE TOOL

6 2 4 PUSH THE CONTACT INTO THE PROPER OPENING AT THE REAR OF THE INSERT BY APPLYING LIGHT TO STEADY FORWARD PRESSURE UNTIL THE CONTACT BOTTOMS

NOTE DO NOT TWIST THE TOOL

6 2 5 REMOVE THE TOOL BY SLIDING IT STRAIGHT BACK ALONG THE WIRE UNSNAP THE TOOL FROM THE WIRE WHEN CLEAR OF THE INSERT

6 1 2 1 SELECT THE PROPER INSERTION TOOL FROM TABLE 5


6 2 2 LAY THE WIRE WITH CONTACT ATTACHED AGAINST THE SLOT OF THE CORRECT INSERTION TOOL AND SNAP INTO THE TOOL (SEE FIGURE 8)

6 2 3 SEAT THE CONTACT SHOULDER AGAINST THE TIP OF THE TOOL

6 2 4 PUSH THE CONTACT INTO THE PROPER OPENING AT THE REAR OF THE INSERT BY APPLYING LIGHT TO STEADY FORWARD PRESSURE UNTIL THE CONTACT BOTTOMS

NOTE DO NOT TWIST THE TOOL

6 2 5 REMOVE THE TOOL BY SLIDING IT STRAIGHT BACK ALONG THE WIRE UNSNAP THE TOOL FROM THE WIRE WHEN CLEAR OF THE INSERT



6 1 2 1 SELECT THE PROPER INSERTION TOOL FROM TABLE 4

6 1 2 2 INSERT A WIRED CONTACT INTO THE REAR OF THE INSERT

6 1 2 3 SEAT THE CONTACT BY POSITIONING THE INSERTION TOOL AROUND THE REAR OF THE CONTACT SHOULDER AND APPLYING LIGHT TO STEADY FORWARD PRESSURE TO ASSURE A FIRM GRIP (SEE FIGURE 7)

6 1 2 3 1 PUSH THE CONTACT STRAIGHT INTO THE CONTACT SHOULDERS WITH STEADY PRESSURE UNTIL THE CONTACT BOTTOMS

6 1 2 3 2 THE CONTACT SHOULDER PROVIDES A POSITIVE STOP

6 1 2 4 MOVE THE INSERTION TOOL BACK AWAY FROM THE CONTACT BEFORE SLIDING IT STRAIGHT UP ALONG THE WIRE UNTIL IT CLEANS THE INSERT

6 1 2 1 SELECT THE PROPER INSERTION TOOL FROM TABLE 4

6 1 2 2 INSERT A WIRED CONTACT INTO THE REAR OF THE INSERT

6 1 2 3 SEAT THE CONTACT BY POSITIONING THE INSERTION TOOL AROUND THE REAR OF THE CONTACT SHOULDER AND APPLYING LIGHT TO STEADY FORWARD PRESSURE TO ASSURE A FIRM GRIP (SEE FIGURE 7)

6 1 2 3 1 PUSH THE CONTACT STRAIGHT INTO THE CONTACT SHOULDERS WITH STEADY PRESSURE UNTIL THE CONTACT BOTTOMS

6 1 2 3 2 THE CONTACT SHOULDER PROVIDES A POSITIVE STOP

6 1 2 4 MOVE THE INSERTION TOOL BACK AWAY FROM THE CONTACT BEFORE SLIDING IT STRAIGHT UP ALONG THE WIRE UNTIL IT CLEANS THE INSERT

TABLE 4

PIN CONTACT		SOCKET CONTACT	
CONTACT SIZE	INSERTION TOOL	REMOVAL TOOL	REMOVAL TOOL
20	M81969/17-03 M81969/14-02	M81969/19-07 M81969/14-02	M81969/17-03 M81969/19-07
16	M81969/17-04 M81969/14-03	M81969/19-08 M81969/14-03	M81969/19-08 M81969/17-04
12	M81969/17-05 M81969/14-04	M81969/19-09 M81969/17-06	M81969/19-09 M81969/17-05

6 1 2 2 INSERT A WIRED CONTACT INTO THE REAR OF THE INSERT

6 1 2 3 SEAT THE CONTACT BY POSITIONING THE INSERTION TOOL AROUND THE REAR OF THE CONTACT SHOULDER AND APPLYING LIGHT TO STEADY FORWARD PRESSURE TO ASSURE A FIRM GRIP (SEE FIGURE 7)

6 1 2 3 1 PUSH THE CONTACT STRAIGHT INTO THE CONTACT SHOULDERS WITH STEADY PRESSURE UNTIL THE CONTACT BOTTOMS

6 1 2 3 2 THE CONTACT SHOULDER PROVIDES A POSITIVE STOP

6 1 2 4 MOVE THE INSERTION TOOL BACK AWAY FROM THE CONTACT BEFORE SLIDING IT STRAIGHT UP ALONG THE WIRE UNTIL IT CLEANS THE INSERT




FIGURE 7
CONTACT INSERTION (SERIES 1)

6 1 2 3 1 PUSH THE CONTACT STRAIGHT INTO THE CONTACT SHOULDERS WITH STEADY PRESSURE UNTIL THE CONTACT BOTTOMS

6 1 2 3 2 THE CONTACT SHOULDER PROVIDES A POSITIVE STOP

6 1 2 4 MOVE THE INSERTION TOOL BACK AWAY FROM THE CONTACT BEFORE SLIDING IT STRAIGHT UP ALONG THE WIRE UNTIL IT CLEANS THE INSERT

6 1 2 3 1 PUSH THE CONTACT STRAIGHT INTO THE CONTACT SHOULDERS WITH STEADY PRESSURE UNTIL THE CONTACT BOTTOMS

6 1 2 3 2 THE CONTACT SHOULDER PROVIDES A POSITIVE STOP

6 1 2 4 MOVE THE INSERTION TOOL BACK AWAY FROM THE CONTACT BEFORE SLIDING IT STRAIGHT UP ALONG THE WIRE UNTIL IT CLEANS THE INSERT

6 1 2 3 1 PUSH THE CONTACT STRAIGHT INTO THE CONTACT SHOULDERS WITH STEADY PRESSURE UNTIL THE CONTACT BOTTOMS

6 1 2 3 2 THE CONTACT SHOULDER PROVIDES A POSITIVE STOP

6 1 2 4 MOVE THE INSERTION TOOL BACK AWAY FROM THE CONTACT BEFORE SLIDING IT STRAIGHT UP ALONG THE WIRE UNTIL IT CLEANS THE INSERT




FIGURE 5
SOCKET CONTACT SIZING TEST

6 CONDUCTOR CONTACT INSERTION INTO CONNECTOR

NOTE UPON INSERTION OF EACH TWO ROWS OF PIN CONTACTS VISUALLY INSPECT THE CONNECTOR FACE TO ENSURE THAT THE CONTACTS ARE PROPERLY INSERTED

6 1 INSERT SERIES 1 CONNECTORS AS FOLLOWS

6 1 1 ACCOMPLISH THE FOLLOWING STEPS FOR SOLDER CONTACTS

6 1 1 1 SOLDER THE CONDUCTORS TO THE CONTACTS IN ACCORDANCE WITH FIGURE 6A. SOLDERING SHOULD BE COMPLETED FOR EACH ROW'S FURTHEST AWAY FROM THE OPERATOR. A PIECE OF STIFF FIRE RETARDANT PAPER SHOULD BE INSERTED BETWEEN THE ROWS AS THE ROWS ARE COMPLETED TO AID IN PROTECTING COMPLETED WORK (FIGURE 6)

WARNING DO NOT MOVE THE CONDUCTOR AFTER THE SOLDERING HAS BEEN COMPLETED OR A COLD SOLDERED JOINT COULD RESULT

6 1 1 1 SOLDER THE CONDUCTORS TO THE CONTACTS IN ACCORDANCE WITH FIGURE 6A. SOLDERING SHOULD BE COMPLETED FOR EACH ROW'S FURTHEST AWAY FROM THE OPERATOR. A PIECE OF STIFF FIRE RETARDANT PAPER SHOULD BE INSERTED BETWEEN THE ROWS AS THE ROWS ARE COMPLETED TO AID IN PROTECTING COMPLETED WORK (FIGURE 6)

WARNING DO NOT MOVE THE CONDUCTOR AFTER THE SOLDERING HAS BEEN COMPLETED OR A COLD SOLDERED JOINT COULD RESULT

6 1 1 1 SOLDER THE CONDUCTORS TO THE CONTACTS IN ACCORDANCE WITH FIGURE 6A. SOLDERING SHOULD BE COMPLETED FOR EACH ROW'S FURTHEST AWAY FROM THE OPERATOR. A PIECE OF STIFF FIRE RETARDANT PAPER SHOULD BE INSERTED BETWEEN THE ROWS AS THE ROWS ARE COMPLETED TO AID IN PROTECTING COMPLETED WORK (FIGURE 6)

WARNING DO NOT MOVE THE CONDUCTOR AFTER THE SOLDERING HAS BEEN COMPLETED OR A COLD SOLDERED JOINT COULD RESULT




FIGURE 6
PROTECTING SOLDERED CONTACTS

SH 132317364

FIGURE 5D3. MIL-C-26482 connector assembly procedure.

1. THIS FIGURE SUPERSEDES SHEET S04 OF DWG. 803-5001027.

TABLE 6

CONTACT SIZE	PUSH TEST VALUE (LBS)	
	SERIES 1	SERIES 2
20	15	20
18	25	25
12	25	30

8 2 REPLACE THE CONNECTOR IN THE CONNECTOR CLAMP.

9 BACKSHELL ASSEMBLY

NOTE THE FOLLOWING ASSEMBLY PROCEDURE IS BASED ON THE ASSUMPTION THAT THE WIRE CONFIGURATION IDENTIFIED IN FIGURE 1 VARIATIONS MAY OCCUR AND CAUSE MINOR DEVIATIONS FROM THIS PROCEDURE. IF THIS SITUATION OCCURS THE MANUFACTURER'S ASSEMBLY INSTRUCTIONS SHOULD BE FOLLOWED.

9 1 FOLD THE SPARE WIRES BACK ONE HALF THE DISTANCE BETWEEN THE CONNECTOR AND THE JACKET END.

9 2 SLIDE A 1 INCH LONG PIECE OF 1/4 INCH SHRINK TUBING OVER EACH FOLDED PAIR AND SHRINK IN PLACE.

9 3 LIGHTLY COAT THE THREADS OF EACH BACKSHELL PART WITH PETROLIUM (V.P. 236) JUST PRIOR TO USING.

9 4 LOOSEN THE FIXTURE CLAMP FROM THE ASSEMBLY FIXTURE.

9 5 FOR CLASS "A" CONNECTORS

9 5 1 SLIDE THE BACKSHELL OVER THE CONDUCTORS AND TIGHTEN USING A STRAP WRENCH AND A TORQUE WRENCH ACCORDING TO THE VALUE PROVIDED IN TABLE 7.

9 6 FOR CLASS "E" AND "F" CONNECTORS

9 6 1 SLIDE THE GROMMET (PC 2) OVER THE WIRE BUNDLE.

9 6 2 SLIDE THE TAPERED SLEEVE (PC 3) AND GROMMET NUT (PC 4) OVER THE GROMMET AND TIGHTEN THE GROMMET NUT.

9 6 2 1 ENSURE THE TAPERED SLEEVE IS NOT COCKED IN THE NUT.

9 7 IF A CABLE CLAMP IS ATTACHED (CLASS "B" OR "E") ADJUST TO THE CONNECTOR ASSEMBLY AND TORQUE TO THE VALUE SPECIFIED IN TABLE 7.

TABLE 7

SHELL SIZE	CONNECTOR BACKSHELL & CABLE CLAMP TORQUE VALUE	
	IN IN. / LBS	FT. LB
8	45	
10	45	
11	45	
13	50	
14	50	
15	50	
16	60	
17	60	
18	60	
19	60	
20	70	
22	70	
23	70	
24	70	
25	70	

7 2 2 REMOVE UNSEATED SERIES 2 CONTACTS AS FOLLOWS

7 2 2 1 SELECT THE CORRECT REMOVAL TOOL FROM TABLE 5

7 2 2 2 LAY THE SLOT OF THE TOOL AGAINST THE WIRE OF THE CONTACT TO BE REMOVED LEAVING 1/2 INCH FROM THE TOOL END TO THE REAR OF THE CONNECTOR.

7 2 2 3 SQUEEZE THE WIRE FIRMLY INTO THE TOOL BETWEEN THE THUMB AND FOREFINGER ABOUT 1/2 INCH FROM THE TOOL TIP.

7 2 2 4 SLIDE THE TOOL DOWN ALONG THE WIRE AND SLOWLY INTO THE INSERT UNTIL POSITIVE RESISTANCE IS FELT.

WARNING DO NOT TWIST OR TURN THE TOOL.

7 2 2 5 PULL BOTH THE TOOL AND WIRED CONTACT OUT OF THE CONNECTOR.

7 3 REINSERT ALL EXTRACTED CONTACTS

7 4 IF A CONTACT FAILS TO RESEAT AFTER THREE INSERTION ATTEMPTS REPLACE THE OFFENDING CONTACT IF THE SAME CONTACT LOCATION CONTINUES TO GIVE DIFFICULTY. THE CONNECTOR IS DAMAGED ON FAULTY AND MUST BE REPLACED.

8 CONTACT PUSH TEST

8 1 USING THE COMBINATION TENSION/COMPRESSION GAGE (CHATILLON DPP 50 OR EQUIVALENT) PUSH TEST ALL CRIMP CONTACTS TO EVALUATE CONTACT RETENTION (FIGURE 9).




FIGURE 9

PUSH TEST ADAPTER, TENSION/COMPRESSION GAGE

8 1 1 SEE TABLE 8 FOR PUSH TEST VALUES.

8 1 2 THE FORCE SHALL BE APPLIED TO THE WAT. CONTACT IN A FIRM SLOW MANNER NOT TO EXCEED 1 LB/SEC. DO NOT INSTANTANEOUSLY APPLY THE FORCES LISTED IN TABLE 8.

8 1 3 ENSURE THE CORRECT PUSH TEST ADAPTER/SPARE IS UTILIZED FOR THE CONTACT SIZE BEING TESTED.




FIGURE 8

CONTACT INSERTION (SERIES 2)

6 2 5 1 SLIGHTLY PULL ON INSERTED CONDUCTOR TO ENSURE CONTACT HAS LOCKED IN CONNECTOR.

6 3 ENSURE THAT THE SHIELD GROUND WIRE (IF TERMINATED TO A CONTACT) IS INSERTED IN ITS PROPER LOCATION.

6 4 INSERT UNWIRED CONTACTS INTO ALL EMPTY HOLES IN THE CONNECTOR INSERT.

6 5 INSERT SEALING PLUGS MEETING THE REQUIREMENTS OF MILITARY STANDARD SPECIFICATIONS AND CLASSIFIED AS SERIES 1, 2, 3, 4, 5, 6, 7, 8, 9, AND A CONNECTORS.

6 6 REMOVE THE CONNECTOR FROM THE CONNECTOR CLAMP.

6 7 CONDUCT A VISUAL CHECK OF THE CONNECTOR AND VERIFY WIRE LOCATION AGAINST THE WIRING TABLE. ENSURE NO DEBRIS IS INSIDE SOCKET CONTACTS.

7 CONTACT REMOVAL PROCEDURES (AS REQUIRED)

7 1 CONDUCT A VISUAL INSPECTION OF THE CONTACTS FOR FACE TO IDENTIFY ANY UNSEATED CONTACTS.

7 2 IF REQUIRED TO REMOVE UNSEATED CONTACTS PROCEED AS FOLLOWS

7 2 1 REMOVE UNSEATED SERIES 1 CRIMP CONTACTS AS FOLLOWS

7 2 1 1 SELECT THE PROPER REMOVAL TOOL FROM TABLE 4.

7 2 1 2 INSERT THE REMOVAL TOOL INTO THE CONTACT FACE PLACING THE SLEEVE OF THE TOOL OVER THE CONTACT TO BE REMOVED.

7 2 1 3 USING STRAIGHT FORWARD MOTION PUSH AND SLIGHTLY ROTATE THE TOOL UNTIL THE SLEEVE BOTTOMS IN THE INSERT.

7 2 1 4 PUSH THE REMOVAL TOOL THRUST COLLAR FORWARD WHICH MOVES THE CONTACT BACK THROUGH THE INSERT. EXPOSING IT FOR EASY HAND REMOVAL.

7 2 1 5 REMOVE THE REMOVAL TOOL FROM THE CONNECTOR.

FIGURE 5D4. MIL-C-26482 connector assembly procedure.

DOD-STD-2003-5 (NAVY)
24 JUNE 1987

NOTES:
1. THIS SHEET SUPERSEDES SHEET 5D5 OF DWG. 803-5001027.

9.8 ALTERNATELY TIGHTEN THE CLAMPING BAR SCREWS UNTIL REACHING THE TORQUE VALUE SPECIFIED IN TABLE 8 USING A TORQUE SCREWDRIVER. DO NOT OVER-TIGHTEN. CHECK FOR MINIMUM GAP OF 1/16 INCH BETWEEN THE CLAMP SUPPORT AND CLAMP SADDLES.

NOTE: IF REQUIRED, INSTALL PERSONNEL SAFETY GROUND UNDER CLAMPING BAR SCREW.

TABLE 8
CLAMP SCREWS

CABLE DIAMETER	TORQUE VALUE
0.0 TO 0.5 IN	25 ± 2 IN./OZ
0.5 TO 1.0 IN	40 ± 2 IN./OZ
1.0 TO 2.0 IN	50 ± 2 IN./OZ




FIGURE 10

9.9 REMOVE THE CONNECTOR FROM THE ASSEMBLY FIXTURE.

10.1 USING ESTABLISHED SHIPYARD PROCEDURES PERFORM ELECTRICAL/ELECTRONIC CHECKS ON THE ASSEMBLED CONNECTOR.

10.2 INSTALL A PROTECTIVE DUST CAP ON THE CONNECTOR.

10.3 COMPLETE THE ASSEMBLY INSPECTION AND DOCUMENTATION AS REQUIRED BY LOCAL PROCEDURES.

11 IF NECESSARY, LOCKWIRE THE CONNECTOR IN ACCORDANCE WITH FIGURE 5A24.

SH 132317366

FIGURE 5D5. MIL-C-26482 connector assembly procedure.

DOD-STD-2003-5 (NAVY)
24 JUNE 1987

NOTES:
1. THIS FIGURE SUPERSEDES SHEET 5E1 OF DWG. 803-5001027

3.1 SECURE THE ASSEMBLY FIXTURE TO A VISE OR SIMILAR SERVICE IN ORDER TO PROVIDE A STABLE WORK AREA.
3.2 USE OF THIS ASSEMBLY FIXTURE NEGATES THE NEED FOR A DUMMY RECEPTACLE. HOWEVER, THE USE OF THE DUMMY RECEPTACLE WITH THE CONNECTOR CLAMP

ANGLE ADJUSTED TO BACKSHELL CONFIGURATION (IE STRAIGHT, 45°, 90°)






FIGURE 3
CONNECTOR SEATED IN ASSEMBLY FIXTURE

FIGURE 2
ASSEMBLY FIXTURE



TYPICAL CONNECTOR/BACKSHELL CONFIGURATION
FIGURE 1

1. VISUAL INSPECTION AND VERIFICATION
 - 1.1 DISASSEMBLE THE CONNECTOR/BACKSHELL ASSEMBLY
 - 1.2 VERIFY THAT THE CONNECTOR IS OF THE CORRECT TYPE AND CONFIGURATION FOR THE CABLE BEING TERMINATED IN ACCORDANCE WITH THE SYSTEM CABLING DIAGRAM
 - 1.3 VERIFY THAT THE BACKSHELL CONFIGURATION IS OF THE CORRECT TYPE AS SPECIFIED ON THE SYSTEM CABLING DIAGRAM
 - 1.4 VERIFY THAT ALL COMPONENTS PARTS OF THE CONNECTOR AND BACKSHELL ARE PREPARED AS SPECIFIED FOR A TYPICAL CONNECTOR/BACKSHELL CONFIGURATION. REFERENCE MIL SPEC MIL-C-28840 FOR SPECIFIC CONFIGURATIONS
 - 1.5 VISUALLY INSPECT THE COMPONENTS FOR DAMAGE TO FORMED PARTS, GOUGES, DAMAGED THREADS, CUT O-RINGS, BURRS, OR SURFACE DAMAGE
 - 1.6 VERIFY THAT THE CONTACTS MEET THE REQUIREMENTS OF MIL SPEC MIL-C-28840 FOR PIN AND MIL-C-39029/84 FOR SOCKET CONTACTS
 - 1.7 IF THE CONDUCTORS ARE RETWISTED DURING LEAD PREPARATION, ENSURE THEY ARE TWISTED AS TIGHT AS POSSIBLE. THE CONTACTS IN THE BACKSHELL CONDUCTOR IS MAINTAINED AND THE CONDUCTORS WILL FIT INSIDE THE CONTACT BARREL
2. PREPARE THE CABLE IN ACCORDANCE WITH PDRIFE 5A1
3. INSERTION SETUP, OWING TO THE MANY POSSIBLE VARIATIONS FOR ACCEPTABLE DESIGNS FOR AN ASSEMBLY FIXTURE, NO SPECIFICATION IS MADE AS TO A PARTICULAR TYPE. THE CRITERIA WHICH ARE APPLICABLE FOR AN ACCEPTABLE ASSEMBLY FIXTURE ARE AS FOLLOWS:
 - A. DUMMY RECEPTACLE, WITHOUT CONNECTOR, INSERT TO HOLD THE CONNECTOR BEING WORKED ON SECURELY OR A CLAMPING DEVICE THAT WILL NOT DAMAGE THE CONNECTOR
 - B. A CABLE CLAMPING FIXTURE TO HOLD THE CABLE IN A SECURE, FIXED RELATIONSHIP TO THE CONNECTOR WHILE PERMITTING ACCESS TO THE REAR FACE OF THE CONNECTOR FOR THE CONTACT INSERTION TOOL
 - C. A DEVICE FOR HOLDING THE WIRE BUNDLE OUT OF THE WORK AREA

NOTE: EQUIVALENT TOOLING FROM ALTERNATE SOURCES IS ACCEPTABLE PROVIDED IT DOES NOT AFFECT THE PROCEDURAL STEPS OUTLINED BELOW.

SH 132317367

FIGURE 5E1. MIL-C-28840 connector assembly procedure.

NOTES
1. THIS FIGURE SUPERSEDES SHEET 5E2 OF DWG. 803-5001027.

- 7.3 PUSH THE CONTACT FORWARD UNTIL THE SHOULDER OF THE CONTACT IS SLIGHTLY EXPOSED BEHIND THE INSERT.
- 7.4 SEAT THE CONTACT BY POSITIONING THE INSERTION TOOL AROUND THE REAR OF THE CONTACT. THE SHOULDER WITH A SLIGHT ANGLE TOWARD THE CONTACT TO ASSURE A FIRM GRIP.
- 7.4.1 PUSH THE CONTACT STRAIGHT INTO THE CONNECTOR CONTACT BOTTOMS UPWARDS. PRES-SURE UNTIL THE CONTACT BOTTOMS PROVIDES A POS-ITIVE STOP.

NOTE
UPON INSERTION OF EACH TWO ROWS OF CON-DUCTORS, THE CONTACT CONNECTORFACE TO INSURE THAT THE CONTACT IS PROPERLY INSERTED AND DO NOT "CROSS OVER" INTO ADJAC-ENT HOLES. ANY "IMPROPERLY" INSERTED CON-TACTS WILL APPEAR ANGLED WHEN COMPARED TO THE PROPERLY INSERTED CONTACTS.

- 7.4.3 MOVE THE INSERTION TOOL BACK AWAY FROM THE CONTACT BEFORE SLIDING IT STRAIGHT UP ALONG THE WIRE INSULATION UNTIL IT CLEARS THE INSERT.
- 7.5 ENSURE THAT THE SHIELD GROUND WIRE (IF TERMI-NATED TO A CONTACT) IS INSERTED IN ITS PROPER LOCKED IN THE CONNECTOR.

- 8. INSERT UNWIRED CONTACTS INTO ALL EMPTY HOLES IN THE CONNECTOR INSERT.
- 9. INSERT SEALING PLUGS WHICH MEET THE REQUIREMENTS OF MS27488 INTO ALL UNWIRED CONTACT HOLES.
- 10. CONDUCT A FINAL VISUAL CHECK OF THE CONNECTOR AND WIRE LOCATION AGAINST THE WIRING TABLE BY THE USE OF A CONTACTIVITY TEST. ENSURE NO DEBRIS IS INSIDE SOCKET CONTACTS.

- 11. CONTACT REMOVAL PROCEDURE (AS REQUIRED)

- 11.1 CONDUCT A VISUAL INSPECTION OF THE CONNEC-TOR FACE TO IDENTIFY ANY UNSEATED CONTACTS.
- 11.2 IF REQUIRED REMOVE THE CONNECTOR FROM THE CONNECTOR CLAMP AND USING THE PROPER TOOL (MS899-34-01) REMOVE THE UNSEATED CONTACT AS FOLLOWS (FIGURE 7)




FIGURE 7
REMOVING A CONTACT




FIGURE 5
SOCKET CONTACT SIZING TEST

- 6. TERMINATE INDIVIDUAL CONDUCTORS WITH CRIMP CON-TACTS IN ACCORDANCE WITH SHEET 5A11. ENSURE THE CRIMPING TOOL CONFORMS TO M22520/34-01 WITH POSITIONER M22520/34-02).

- 6.1 IF CONTACT NETWORK SHORTENS A CONDUCTORS INITIAL LENGTH BY GREATER THAN 1/4 INCH THE JACKET MUST BE CUT BACK AGAIN.
- 7. USING THE PROPER WIRING TABLE AND WORKING FROM THE REAR OF THE CONTACTS INTO THE ASSEMBLY FIXTURE INSERT THE CONTACTS INTO THEIR DESIGNATED LOC-A-TIONS AS FOLLOWS (FIGURE 6)




FIGURE 6
CONTACT INSERTION

NOTE ADJUST THE FIXTURE CLAMP AS REQUIRED DURING THE INSERTION PROCESS TO EASE STRESS ON THE CONDUCTORS

- 7.1 ENSURE THE INSERTION TOOL CONFORMS TO MIL-SPEC #81989/33-01.
- 7.2 INSERT A WIRED CONTACT INTO THE REAR OF THE INSERT

- 3.3 SEAT THE CONNECTOR IN THE CONNECTOR CLAMP AND ADJUST THE WING NUTS TO SECURE IT IN PLACE.
- 3.4 PLACE THE PREPARED CABLE IN THE FIXTURE CLAMP AND CRIMP CONTACTS TO BE INSERTED WILL BE AT THE REAR OF THE CONNECTOR AS IT IS HELD IN THE CONNECTOR CLAMP.

- 3.5 POSITION THE CABLE AT THE ANGLE SIMILAR TO THE BACKSHELL DESIGN (IE, 45°, 90°, OR STRAIGHT). SECURE THE CABLE IN THE FIXTURE CLAMP (FIGURE 4A).

- 3.6 POSITION THE CONNECTOR SO THAT THE CONNEC-TOR TO CABLE JACKET DISTANCE IS THAT MEASURED IN STEP 9.2 OF FIGURE 5A1. ROTATE THE CONNECTOR TO OBTAIN THE CORRECT POSITION IN PROPER RELATIONSHIP TO THE BACKSHELL (FIGURE 4B).

- 3.7 ROUTE THE INDIVIDUAL CONDUCTORS PER THE APPROPRIATE WIRING TABLE. ENSURE THAT THE LONGEST ROUTED CONDUCTOR IS THE CORRECT LENGTH AT THE REQUIRED POSITION TERMINATION PRIOR TO CUTTING ANY CONDUCTOR (FIGURE 4C).

SECURE CABLE AND ALIGN FOR INSERTION




FIGURE 4B

FIGURE 4C

FIGURE 4
DETERMINING CONDUCTOR LENGTH

- 3.8 CUT THE CONDUCTORS AS REQUIRED TO PROVIDE EVEN CONDUCTION LENGTHS AT THE CONNECTOR INSERT.

NOTE LEAVE THE SPARES FULL LENGTH

- 4. STRIP THE INDIVIDUAL CONDUCTORS IN ACCORDANCE WITH FIGURE 5A5 (CONTACT WIRE BARREL DEPTH IS 160-208 INCHES)

- 5. PRIOR TO CRIMPING, A CONTACT SIZING TEST SHOULD BE CONDUCTED FOR ALL SOCKET CONTACTS (PIN CON-TACTS PREVIOUSLY VERIFIED IN STEP 1.6 DO NOT NEED FURTHER TESTING).

- 5.1 SOCKET CONTACTS SHOULD BE INSPECTED FOR PROPER SIZE USING A PIN CONTACT GAGE CON-FORMING TO MIL-STD-883C. WHEN TESTED THE MINIMUM SEPARATION FOR ALL CONTACTS USING A TENSION/COMPRESSION GAGE (CITIZILLOD DPP 16 OR EQUI-VALENT) SHOULD BE 0.02

SH 132317368

FIGURE 5E2. MIL-C-28840 connector assembly procedure.

NOTES:
1. THIS FIGURE SUPERSEDES SHEET 5E3 OF DRAWING NO. 803-5001027.

13.11 MARK A LINE ON THE CABLE 1/4-1/2 INCH ABOVE THE BACKSHELL. PUSH THE CABLE INTO THE BACKSHELL 1/4-1/2 INCH AND MAINTAIN CONTINUOUS PRESSURE TO HOLD AT THIS POSITION FOR THE NEXT FOUR STEPS (LINE MARKED ON JACKET IS PARALLEL WITH END OF BACKSHELL SLEEVE)




FIGURE 9
MARKING THE CABLE

13.12 VERIFY THE CABLE JACKET IS POSITIONED COMPLETELY THROUGH THE GROMMET
13.13 SLIDE THE SEALING HARDWARE WASHER (PC 6), GROMMET (PC 7), AND GROMMET FOLLOWER (PC 8) INTO POSITION BEHIND THE SLEEVE
13.14 SCREW THE CABLE CLAMP (PC 9) ONTO THE SLEEVE AND TORQUE TO THE VALUE SPECIFIED IN TABLE 1

13.1 FOLD SPARE WIRES BACK ONE-HALF THE DISTANCE BETWEEN THE CONNECTOR AND THE JACKET END.
13.2 SLIDE A 1 INCH LONG PIECE OF APPROPRIATELY SIZED SHRINK TUBING OVER EACH FOLDED PAIR AND SHRINK IN PLACE.
13.3 LIGHTLY COAT THE THREAD OF EACH BACKSHELL PART WITH PETROLATUM (VV P-238) JUST PRIOR TO USING.
13.4 POSITION AND LUBRICATE ALL O-RINGS.
13.5 LOOSEN THE CABLE CLAMP ON THE ASSEMBLY FIXTURE.
13.6 SLIDE THE BACKSHELL ADAPTER (PC 2) DOWN THE SLEEVE TO THE POSITION OF THE GROMMET FOLLOWER. TORQUE WRENCH TO THE VALUE PROVIDED IN TABLE 1 FOR THE APPROPRIATE SHELL SIZE.

TABLE 1

SHELL SIZE	CONNECTOR REAR THREAD AND CABLE CLAMP TORQUE IN IN./LBS (± 5 IN /LBS)
8	45
8S	45
10	45
10S	45
12	50
12S	50
14	50
14S	50
16	60
16S	60
20	70
22	70
24	80
28	100
32	100
36	120

13.7 IF THE GROSS SHIELD IS TO BE FLOATED OR TERMINATED TO A CONNECTOR CONTACT, PROCEED TO STEP 13.8. IF THE SHIELD IS TO BE TERMINATED TO THE BACKSHELL RFI HARDWARE, PROCEED AS FOLLOWS:
13.7.1 SLIDE THE RFI BELL (PC 3) AGAINST THE BACKSHELL ADAPTOR.
13.7.2 FLARE THE GROSS SHIELD OVER THE TAPERED END OF THE RFI BELL.
13.7.3 GENTLY FORCE THE CABLE TOWARD THE CONNECTOR PLUG UNTIL THE SHIELD CONTACTS THE TAPERED SURFACE ON THE RFI BELL.
13.7.4 SLIDE THE RFI RING (PC 4) ONTO THE RFI BELL WHILE APPLYING FORWARD PRESSURE ON THE CABLE.
13.7.5 COMPRESS THE SHIELD BETWEEN THE RFI BELL AND RFI RING WITH A CABLE DRESSER, TWISTING FORWARD MOTION ON THE RFI RING.
13.8 SLIDE THE RFI BACKSHELL COMPONENTS (PC 3, 4) OVER THE RFI BELL, LOOPED GROUND WIRE AND SPARE CONDUCTORS.
13.9 SLIDE THE BACKSHELL SLEEVE (PC 5) OVER THE RFI ASSEMBLY AND SCREW THE SLEEVE ONTO THE ADAPTER.
13.10 TORQUE THE SLEEVE TO THE VALUE PROVIDED IN TABLE 1 FOR THE APPROPRIATE SHELL SIZE.

11.2.1 INSERT THE EXTRACTION TOOL INTO THE CONNECTOR FACE AND ENGAGE THE FRONT OF THE CONTACT WITH THE TOOL.
11.2.2 PUSHING WITH THE REAR OF THE TOOL TO APPLY PRESSURE ON THE TOOL TIP, ROTATE THE TOOL REAR SLIGHTLY IN THE CLOCKWISE DIRECTION.
11.2.3 PUSH THE TOOL THRUST SLEEVE FORWARD MOVING THE CONTACT BACK THROUGH THE INSERT.
11.2.4 REMOVE THE CONTACT FROM THE REAR OF THE CONNECTOR AND SLOWLY REMOVE THE EXTRACTION TOOL FROM THE FACE OF THE CONTACT.
11.3 REINSERT ALL EXTRACTED CONTACTS IN ACCORDANCE WITH STEP 7 AND REINSPECT THE CONNECTOR FACE.
11.4 IF A CONTACT FAILS TO RESEAT AFTER THREE INSERTION ATTEMPTS, REPLACE THE OFFENDING CONTACT IF THE SAME CONTACT LOCATION CONTINUES TO GIVE DIFFICULTY. THE CONNECTOR IS PROBABLY DAMAGED OR FAULTY AND MUST BE REPLACED.
11.5 REMOVE THE CONNECTOR FROM THE CONNECTOR CLAMP IF NOT PREVIOUSLY ACCOMPLISHED.
12 CONTACT PUSH TEST.
12.1 USING THE COMBINATION TENSION/COMPRESSION GAGE (CHATILLON DPP 25 OR EQUIVALENT), PUSH TEST ALL CONTACTS TO EVALUATE CONTACT RETENTION (FIGURE 8).
12.1.1 ENSURE THE CORRECT PUSH TEST ADAPTER/PROBE IS UTILIZED FOR THE CONTACT SIZE BEING TESTED.




FIGURE 8

12.2 THE FORCE SHALL BE APPLIED TO THE MATING END CONTACT SLOWLY UNTIL CONTACT PRESSURE OF 30 STRAIGHT TENSILE CONTACT PRESSURE OF 20 POUNDS DO NOT INSTANTANEOUSLY APPLY THE PRESSURE.
12.3 REPLACE THE CONNECTOR IN THE CONNECTOR CLAMP.
13 BACKSHELL ASSEMBLY

NOTE THE FOLLOWING ASSEMBLY PROCEDURE IS BASED ON THE ASSUMPTION THAT THE CONTACT RATION DEFICIT IN FIGURE 11 VARIATIONS MAY OCCUR AND CAUSE MINOR DEVIATIONS FROM THIS PROCEDURE IF THIS SITUATION OCCURS THE MANUFACTURER'S ASSEMBLY INSTRUCTIONS SHOULD BE FOLLOWED.
SH 132317389

FIGURE 5E3. MIL-C-28840 connector assembly procedure.

DOD-STD-2003-5 (NAVY)
24 JUNE 1987

NOTES:
1. THIS PROCEDURE SUPERSEDES SHEET 5E4 OF DRAWING NO. 803-5031027.

13.15 ALTERNATELY TIGHTEN THE CLAMPING BAR SCREWS UNTIL REACHING THE TORQUE VALUE SPECIFIED IN THE TORQUE CONTROL OR EQUIVALENT (FIGURE 10).

NOTE: IF REQUIRED, INSTALL PERSONNEL SAFETY GROUND UNDER CLAMPING BAR SCREW.

13.16 REMOVE THE CONNECTOR FROM THE ASSEMBLY FIXTURE.

TABLE 2
CLAMP SCREWS

CABLE DIAMETER	TORQUE VALUE
0.0 TO 0.5 IN	25 ± 2 IN / OZ
0.0 TO 1.0 IN	40 ± 2 IN / OZ
1.0 TO 2.0 IN	50 ± 2 IN / OZ

NOTE: THESE TORQUE VALUES MUST BE MAINTAINED SO THAT A MINIMUM GAP OF NOT LESS THAN 1/16 IN EXISTS BETWEEN THE CLAMP SUPPORT AND CLAMP SADDLES.




FIGURE 10

14. FINAL TEST AND DOCUMENTATION

14.1 USING ESTABLISHED SHIPYARD PROCEDURES PERFORM ELECTRICAL/ELECTRONIC CHECKS ON THE ASSEMBLED CONNECTOR.

14.2 INSTALL A PROTECTIVE DUST CAP ON THE CONNECTOR.

14.3 COMPLETE THE ASSEMBLY INSPECTION AND DOCUMENTATION AS REQUIRED BY LOCAL PROCEDURES.

15. IF NECESSARY, LOCKWIRE THE CONNECTOR IN ACCORDANCE WITH FIGURE 5A24.

SH 132317370

FIGURE 5E4. MIL-C-28840 connector assembly procedure.

DOD-STD-2003-5 (NAVY)
24 JUNE 1987

- 1 VISUAL INSPECTION AND VERIFICATION
 - 1.1 DISASSEMBLE THE CONNECTOR/BACKSHELL ASSEMBLY
 - 1.2 VERIFY THAT THE CONNECTOR IS OF THE CORRECT TYPE AND CONDITION FOR THE CABLE BEING TERMINATED IN ACCORDANCE WITH THE SYSTEM CABLING DIAGRAM
 - 1.3 VERIFY THAT THE BACKSHELL CONFIGURATION IS OF THE TYPE AS SPECIFIED ON THE SYSTEM CABLING DIAGRAM
 - 1.4 VERIFY THAT ALL COMPONENT PARTS OF THE CONNECTOR AND BACKSHELL HARDWARE ARE PRESENT (SEE FIGURE 1 FOR A TYPICAL CONNECTOR/BACKSHELL ASSEMBLY). REFER TO THE MIL SPECS MIL-C-27599 FOR CONTACT AND CONTACTS FOR BACKSHELL OR VENDOR DATA FOR SPECIFIC CONFIGURATIONS
 - 1.5 VISUALLY INSPECT THE COMPONENTS FOR DAMAGE SUCH AS DEFORMED PARTS, BUCKLED LEAD THREADS, CUT O-RINGS, BURRS, OR SURFACE DAMAGE
 - 1.6 VERIFY THAT THE CONTACTS MEET THE REQUIREMENTS OF MIL-C-27599 AND MATE PROPERLY WITH THEIR COUNTERPART CONTACTS
 - 1.7 IF THE CONDUCTORS ARE RETWISTED DURING LEAD SEPARATION, ENSURE THEY ARE TWISTED AS CLOSE TO THE ORIGINAL LAY OF THE CONDUCTORS AS MAINTAINED IN THE BARREL
- 2 PREPARE THE CABLE IN ACCORDANCE WITH FIGURE 5A1
- 3 WHILE SOLDERING THE CONDUCTORS TO THE CONTACT AN ASSEMBLY FIXTURE SHOULD BE UTILIZED IN ORDER TO IMMOBILIZE THE CABLE, CONDUCTORS, AND CONNECTOR. THE FOLLOWING ARE THE REQUIREMENTS FOR AN ACCEPTABLE ASSEMBLY FIXTURE ARE AS FOLLOWS:
 - A A DUMMY RECEPTACLE, WITHOUT CONNECTOR INSERT, TO HOLD THE CONNECTOR BEING WORKED TO PREVENT DAMAGE TO THE CONTACTS OR TO DAMAGE THE CONNECTOR
 - B A CABLE CLAMPING FIXTURE TO HOLD THE CABLE IN A SECURE, FIXED RELATIONSHIP TO THE CONNECTOR WHILE PERMITTING ACCESS TO THE REAR FACE OF THE CONNECTOR FOR THE SOLDERING IRON

ANGLE ADJUSTED TO BACKSHELL CONFIGURATION (± STRAIGHT, 45°, 90°)




FIGURE 2
ASSEMBLY FIXTURE
SH 132317371

C A DEVICE FOR HOLDING THE WIRE BUNDLE OUT OF THE WORK AREA
THE ASSEMBLY FIXTURE REFERRED TO IN THIS PROCEDURE IS THAT DEVELOPED BY CHARLESTON NAVAL SHIPYARD (FIGURE 2).
NOTE EQUIVALENT TOOLING FROM ALTERNATE SOURCES IS ACCEPTABLE PROVIDED THE USE OF OTHER TOOLS MAY AFFECT THE PROCEDURAL STEPS OUTLINED BELOW





FIGURE 3
CONNECTOR SEATED IN ASSEMBLY FIXTURE

- 3.1 SECURE THE ASSEMBLY FIXTURE TO A VISE OR SIMILAR HOLDING DEVICE IN ORDER TO PROVIDE A STABLE WORK AREA
- 3.2 USE OF THIS ASSEMBLY FIXTURE NEGATES THE NEED FOR A DUMMY RECEPTACLE (FIGURE 3 ILLUSTRATES HOW THE CONNECTOR IS FIRMLY SEATED IN THE CONNECTOR CLAMP)
- 3.3 SEAT THE CONNECTOR IN THE CONNECTOR CLAMP AND ADJUST THE WING NUTS TO SECURE IT IN PLACE
- 3.4 PLACE THE PREPARED CABLE IN THE FIXTURE CLAMP SO THAT THE FIRST CONTACTS OF THE CABLE WILL BE AT THE BACK OF THE CONNECTOR AS IT IS HELD IN THE CONNECTOR CLAMP

NOTES:
1. THIS FIGURE SUPERSEDES SHEET 5F1 OF DWG 803-5001027.



MIL-C-27599 CONNECTOR WITH
COMPATIBLE BACKSHELL CONFIGURATION

FIGURE 1

FIGURE 5F1. MIL-C-27599 connector assembly procedure.

NOTES:
1. THIS FIGURE SUPERSEDES SHEET 5F2 OF DWG. 803-5001027

9. BACKSHELL ASSEMBLY

NOTE: THIS CONNECTOR SPECIFICATION DOES NOT PROVIDE FOR UNIQUE CONNECTOR ACCESSORIES. THE FOLLOWING ASSEMBLY PROCEDURE IS BASED ON THE NOMENCLATURE AND HARDWARE CONFIGURATION DEPICTED IN FIGURE 1. VARIATIONS IN HARDWARE DESIGN BASED ON MANUFACTURER MAY OCCUR AND CAUSE MINOR PROBLEMS. THE BACKSHELL MANUFACTURERS SHOULD BE UTILIZED WHEN CONFLICTS EXIST.

9.1 FOLD SPARE WIRES BACK ONE-HALF THE DISTANCE BETWEEN THE CONNECTOR AND THE JACKET END

9.2 SLIDE A 1 INCH LONG PIECE OF APPROPRIATELY SIZED SHRINK TUBING OVER EACH FOLDED PAIR AND SHRINK IN PLACE

9.3 LIGHTLY COAT THE THREADS OF EACH BACKSHELL PART WITH PETROLATUM (VV-P-236) JUST PRIOR TO ASSEMBLY

9.4 POSITION AND LUBRICATE (PETROLATUM VV-P-236) ALL O-RINGS

9.5 SLIDE THE BACKSHELL ADAPTER (PC 2) DOWN THE CABLE AND SCREW IT ONTO THE CONNECTOR. TIGHTEN THE ADAPTER TO THE TORQUE VALUE PROVIDED IN TABLE 2 FOR THE APPROPRIATE SHELL SIZE USING A TORQUE WRENCH AND STRAP WRENCH

9.6 SLIDE THE 90° ELBOW (PC 3) DOWN AND SCREW IT ONTO THE ADAPTER. TIGHTEN THE ELBOW TO THE TORQUE VALUE PROVIDED IN TABLE 2 FOR THE APPROPRIATE SHELL SIZE

TABLE 2

SHELL SIZE	CONNECTOR BACKSHELL & CABLE CLAMP TORQUE VALUE IN INCH LBS. (1.5 IN. LBS.)
8	45
9	45
10	45
11	45
13	50
14	50
15	50
16	60
17	60
18	60
19	60
20	70
21	70
22	70
23	70
24	70
25	70

9.7 IF THE GROSS SHIELD IS TO BE FLOATED OR TERMINATED TO A CONNECTOR CONTACT, PROCEED TO STEP 9.8 IF THE SHIELD IS TO BE TERMINATED TO THE BACKSHELL RFI HARDWARE PROCEED AS FOLLOWS

9.7.1 SLIDE THE RFI BELL (PC 4) AGAINST THE ELBOW

9.7.2 FLARE THE GROSS SHIELD OVER THE TAPERED END OF THE RFI BELL

9.7.3 GENTLY FORCE THE CABLE TOWARD THE CONNECTOR PLUG UNTIL THE SHIELD COVERS THE TAPERED SURFACE ON THE RFI BELL

9.7.4 SLIDE THE RING (PC 5) ONTO THE RFI BELL AND APPLY FORWARD PRESSURE ON THE CABLE

9.7.5 COMPRESS THE SHIELD BETWEEN THE RFI BELL AND RING WITH A BACK AND FORHWARD TWISTING FORWARD MOTION ON THE RFI RING

3.8 CUT THE CONDUCTORS AS REQUIRED TO PROVIDE EVEN CONDUCTION LENGTHS AT THE CONNECTOR INSERT

NOTE: LEAVE THE SPARES FULL LENGTH

4. STRIP THE INDIVIDUAL CONDUCTORS IN ACCORDANCE WITH FIGURE 5A5 FOR CONTACT WIRE BARREL DEPTHS (SEE TABLE 1)

4.1 IF REWORK SHORTENS A CONDUCTOR'S INITIAL LENGTH BY GREATER THAN 1/4 INCH THE JACKET MUST BE CUT BACK AGAIN AND ALL CONDUCTORS RETRIMMED TO PREVENT STRESS

TABLE 1

CONTACT SIZE	WIRE BARREL DEPTH
22	084, 125
20	125, 156
16	141, 172

5. TIN INDIVIDUAL CONDUCTORS IN ACCORDANCE WITH SHEET 5A13

5.1 ENSURE CONDUCTOR STRANDS ARE TWISTED TIGHT PRIOR TO TINNING

6. SOLDER THE CONDUCTORS TO THE CONTACTS IN ACCORDANCE WITH FIGURE 5A13. SOLDER THE STRANDS AWAY FROM THE OPERATOR. A PIECE OF STIFF FIRE-RETARDANT PAPER SHOULD BE INSERTED BETWEEN THE ROWS AS THEY ARE COMPLETED TO AID IN PROTECTING THE WORK ALREADY COMPLETED (SEE FIGURE 5 FOR EXAMPLE)

WARNING: DO NOT MOVE THE CONDUCTOR AFTER THE SOLDERING. IF THE SOLDER HAS BEEN REMOVED OR A COLD SOLDERED JOINT COULD RESULT




FIGURE 5

7. REMOVE THE CABLE AND CONNECTOR FROM THE ASSEMBLY FIXTURE

8. CONDUCT A VISUAL CHECK OF THE CONNECTOR AND VERIFY WIRE LOCATION AGAINST THE WIRING TABLE. ENSURE NO DEBRIS IS INSIDE SOCKET CONTACTS

3.3 POSITION THE CABLE AT THE ANGLE SIMILAR TO THE BACKSHELL DESIGN (I.E. 45° 90° OR STRAIGHT) SECURE THE CABLE IN THE FIXTURE CLAMP (FIGURE 4A)

3.6 POSITION THE CONNECTOR SO THAT THE CONNECTOR TO CABLE JACKET DISTANCE IS THAT MEASURED IN STEP 3.2 OF SHEET 5A1. ROTATE THE CONNECTOR TO ALIGN THE KEYS WITH THE CORRESPONDING KEYS IN THE BACKSHELL (FIGURE 4B)




FIGURE 4A




FIGURE 4B




FIGURE 4C

FIGURE 4

3.7 ROUTE THE INDIVIDUAL CONDUCTORS PER THE APPLICABLE WIRING TABLE. ENSURE THAT THE LONGEST ROUTED CONDUCTOR HAS SUFFICIENT LENGTH AT THE REQUIRED POSITION PRIOR TO CUTTING ANY CONDUCTION (FIGURE 4C)

SH 132317372

FIGURE 5F2. MIL-C-27599 connector assembly procedure.

NOTES:
1. THIS FIGURE SUPERSEDES SHEET 5F3 OF DWG 803-500 1027.

- 10 FINAL TEST AND DOCUMENTATION.
- 10.1 USING ESTABLISHED SHIPYARD PROCEDURES PERFORM ELECTRICAL/ELECTRONIC CHECKS ON THE ASSEMBLED CONNECTOR.
- 10.2 INSTALL A PROTECTIVE DUST CAP ON THE CONNECTOR.
- 10.3 COMPLETE THE ASSEMBLY INSPECTION AND DOCUMENTATION AS REQUIRED BY LOCAL PROCEDURES.
- 11. IF NECESSARY LOCKWIRE THE CONNECTOR IN ACCORDANCE WITH FIGURE 5A21.

- 9.8 SLIDE THE RFI BACKSHELL COMPONENTS (PC 4, 5) OVER ANY PIGTAILS, LOOPED GROUND WIRE OR SPARE CONDUCTORS.
- 9.9 SLIDE THE SLEEVE (PC 6) OVER THE RFI ASSEMBLY AND SCREW IT ONTO THE ELBOW.
- 9.10 TORQUE THE SLEEVE TO THE VALUE PROVIDED IN TABLE 2 FOR THE APPROPRIATE SHELL SIZE USING A TORQUE WRENCH AND STRAP WRENCH.
- 9.11 MARK A LINE ON THE CABLE 1/4-1/2 INCH ABOVE THE BACKSHELL SLEEVE (SEE FIGURE 6). CAREFULLY PUSH THE CABLE INTO THE BACKSHELL 1/4-1/2 INCH AND MAINTAIN CONTINUOUS PRESSURE TO THE POSITION FOR THE NEXT FOUR STEPS (LINE MARKED ON BACKSHELL IS PARALLEL WITH BACKSHELL SLEEVE END).
- 9.12 VERIFY THE CABLE JACKET IS POSITIONED COMPLETELY THROUGH THE GLAND.
- 9.13 SLIDE THE GLAND (PC 7) AND RING (PC 8) INTO POSITION BEHIND THE SLEEVE.
- 9.14 SCREW THE CABLE CLAMP (PC 9) ONTO THE SLEEVE USING A TORQUE WRENCH AND STRAP WRENCH.
- 9.15 ALTERNATELY TIGHTEN THE CLAMPING BAR SCREWS UNTIL REACHING THE TORQUE VALUE LISTED IN TABLE 3. USING A TORQUE WRENCH AND STRAP WRENCH TO CONTROL TORQUE. TORQUE SCREW DRIVER CONTROL IS NOT TO BE USED. ENSURE A MINIMUM GAP OF 1/16 INCH EXISTS BETWEEN THE CLAMP SUPPORT AND CLAMP SADDLES.




FIGURE 6
MARKING THE CABLE

TABLE 3

CLAMP SCREWS

CABLE DIAMETER	TORQUE VALUE
0.0 TO 0.5 IN	25 ± 2 IN / OZ
0.0 TO 1.0 IN	40 ± 2 IN / OZ
1.0 TO 2.0 IN	50 ± 2 IN / OZ




FIGURE 7

NOTE: IF REQUIRED, INSTALL PERSONNEL SAFETY GROUND UNDER CLAMPING BAR SCREW.

FIGURE 5F3. MIL-C-27599 connector assembly procedure.

SH 1323 17373

NOTES:
1. THIS FIGURE SUPERSEDES SHEET 5G1 OF DWG. 803-5001027.




FIGURE 3
CONNECTOR SEATED IN ASSEMBLY FIXTURE

- 3.1.3 SEAT THE CONNECTOR IN THE CONNECTOR CLAMP AND ADJUST THE WING NUTS TO SECURE IT IN PLACE
- 3.1.4 PLACE THE PREPARED CABLE IN THE FIXTURE CLAMP SO THAT THE FIRST CONTACTS TO BE SOLDERED WILL BE AT THE BACK OF THE CONNECTOR AS IT IS HELD IN THE CONNECTOR CLAMP





FIGURE 2
ASSEMBLY FIXTURE

- 3.1 PREPARE THE CONNECTOR AND CABLE FOR SOLDERING AS FOLLOWS:

- 3.1.1 SECURE THE ASSEMBLY FIXTURE TO A VISE OR SIMILAR HOLDING DEVICE
- 3.1.2 USE OF THIS ASSEMBLY FIXTURE NEGATES THE NEED FOR A DUMMY RECEPTACLE. FIGURE 3 ILLUSTRATES HOW THE CONNECTOR IS FIRMLY SEATED IN THE CONNECTOR CLAMP

1. VISUAL INSPECTION AND VERIFICATION
 - 1.1 DISASSEMBLE THE CONNECTOR/BACKSHELL ASSEMBLY
 - 1.2 VERIFY THAT THE CONNECTOR IS OF THE CORRECT TYPE AND CONFIGURATION FOR THE CABLE BEING TERMINATED IN ACCORDANCE WITH THE SYSTEM CABLING DIAGRAM
 - 1.3 VERIFY THAT THE BACKSHELL CONFIGURATION IS OF THE CORRECT TYPE AS SPECIFIED ON THE SYSTEM CABLING DIAGRAM
 - 1.4 VERIFY THAT ALL COMPONENTS PARTS OF THE CONNECTOR AND BACKSHELL HARDWARE ARE PRESENT (SEE FIGURE 1 FOR A TYPICAL CONNECTOR/BACKSHELL CONFIGURATION). REFERENCE MIL SPECS. MIL C 22992 FOR CONNECTOR AND 85049 M.S. DWGS. FOR BACKSHELLS FOR VENDOR DATA FOR SPECIFIC CONFIGURATIONS
 - 1.5 VISUALLY INSPECT THE COMPONENTS FOR DAMAGE SUCH AS DEFORMED PARTS, GOUGES, DAMAGES THREADS, CUT O-RINGS, BURRS, OR SURFACE DAMAGE
 - 1.6 VERIFY THAT CONTACTS MEET THE REQUIREMENTS OF MIL C 22992
 - 1.7 IF THE CONDUCTORS ARE RETWISTED DURING LEAD PREPARATION, ENSURE THEY ARE TWISTED AS TIGHT AS ORIGINALLY TIGHT AND MAINTAINED AS TIGHT AS POSSIBLE. INSURE THAT THE CONTACT CONDUCTORS WILL FIT INSIDE THE CONTACT BARREL
2. PREPARE THE CABLE IN ACCORDANCE WITH FIGURE 5A1.
3. WHILE SOLDERING THE CONDUCTORS TO THE CONTACT, AN ASSEMBLY FIXTURE SHOULD BE UTILIZED IN ORDER TO IMMOBILIZE THE CABLE, CONDUCTORS, AND CONNECTOR (FIGURE 2) THE CRITERIA FOR AN ACCEPTABLE ASSEMBLY FIXTURE ARE AS FOLLOWS:
 - A. DUMMY RECEPTACLE, WITHOUT CONNECTOR INSERT, TO HOLD THE CONNECTOR BEING WORKED ON SECURELY OR A CLAMPING DEVICE THAT WILL NOT DAMAGE THE CONNECTOR
 - B. A CABLE CLAMPING FIXTURE TO HOLD THE CABLE IN A SECURE, FIXED RELATIONSHIP TO THE CONNECTOR WHILE PERMITTING ACCESS TO THE REAR FACE OF THE CONNECTOR FOR THE SOLDERING IRON
 - C. A DEVICE FOR HOLDING THE WIRE BUNDLE OUT OF THE WORK AREA

NOTE: THE ASSEMBLY FIXTURE REFERRED TO IN THIS PROCEDURE IS THAT DEVELOPED BY CHARLESTON NAVAL SHIPYARD (FIGURE 2). EQUIVALENT TOOLING FROM ALTERNATE SOURCES IS ACCEPTABLE, HOWEVER, THE USE OF OTHER TOOLS MAY AFFECT THE PROCEDURAL STEPS OUTLINED BELOW



MIL-C-22992 CONNECTOR / MS 17340
BACKSHELL CONFIGURATION
FIGURE 1

SH 132317374

FIGURE 5G1. MIL-C-22992 connector assembly procedure (excluding class L).

6 SOLDER THE CONDUCTORS TO THE CONTACTS IN ACCORDANCE WITH SHEET 5A15. SOLDERING SHOULD START WITH THE CONTACT ROW(S) FURTHEST AWAY FROM THE OPERATOR. A PIECE OF STIFF FIRE RETARDANT PAPER SHOULD BE INSERTED BETWEEN THE ROWS AS THE SOLDERING IS COMPLETED TO PREVENT THE WORK ALREADY ACCOMPLISHED (SEE FIGURE 3 FOR EXAMPLE).

WARNING DO NOT MOVE THE CONDUCTOR AFTER THE SOLDERING IS COMPLETED. IF THE SOLDER IS REMOVED OR A COLD SOLDER JOINT COULD RESULT.




FIGURE 5
PROTECTING SOLDERED CONTACTS

7 REMOVE THE CABLE AND CONNECTOR FROM THE ASSEMBLY FIXTURE.

8 CONDUCT A VISUAL CHECK OF THE CONNECTOR AND VERIFY WIRE LOCATION AGAINST THE WIRING TABLE. ENSURE NO DEBRIS IS INSIDE SOCKET CONTACTS.

9 BACKSHELL ASSEMBLY.

NOTE THE FOLLOWING ASSEMBLY PROCEDURE IS BASED ON THE NOMENCLATURE AND HARDWARE CONFIGURATION OF THE PARTS LISTED. ANY DEVIATIONS MAY OCCUR AND CAUSE MINOR DEVIATIONS FROM THIS PROCEDURE. THE APPLICABLE MANUFACTURER'S INSTRUCTIONS SHOULD BE UTILIZED TO RESOLVE ASSEMBLY PROCEDURES FOR CONFIGURATIONS NOT COVERED IN THIS PROCEDURE.

9.1 LUBRICATE THE THREADS OF ALL BACKSHELL COMPONENTS WITH PETROLATUM (VV-P-238) PRIOR TO ASSEMBLY.

9.2 FOLD SPARE WIRES BACK ONE-HALF THE DISTANCE BETWEEN THE CONNECTOR AND THE JACKET END.

9.3 SLIDE A 1 INCH LONG PIECE OF APPROPRIATELY SIZED SHRINK TUBING OVER EACH FOLDED PAIR AND SHRINK IN PLACE.

9.4 POSITION AND LUBRICATE ALL O-RINGS.

9.5 SLIDE THE GLAND HOUSING (PC 2) DOWN THE CABLE AND SCREW IT ONTO THE CONNECTOR. TIGHTEN THE GLAND HOUSING TO THE TORQUE VALUE PROVIDED IN TABLE 2 FOR THE APPROPRIATE SHELL SIZE.

3.1.5 POSITION THE CABLE AT THE ANGLE SIMILAR TO THE BACKSHELL DESIGN (IE 45° 30' OR STRAIGHT) SECURE THE CABLE IN THE FIXTURE CLAMP (FIGURE 4A).

3.1.6 POSITION THE CONNECTOR SO THAT THE CONNECTOR TO CABLE JACKET DISTANCE IS THAT MEASURED IN STEP 9.2 OF FIGURE 5A1. MOVE THE CONNECTOR TO ALIGN THE KEYWAY WITH THE BACKSHELL (FIGURE 4B).

3.1.7 ROUTE THE INDIVIDUAL CONDUCTORS PER THE APPROPRIATE WIRING TABLE. ENSURE THAT THE LONGEST ROUTED CONDUCTOR HAS SUFFICIENT LENGTH AT THE REQUIRED POSITION. TERMINATION PRIOR TO CUTTING ANY CONDUCTOR (FIGURE 4C).




FIGURE 4
LONGEST CONDUCTOR BEFORE CUTTING
DETERMINING CONDUCTOR LENGTH

3.2 CUT THE CONDUCTORS AS REQUIRED TO PROVIDE EVEN CONDUCTOR LENGTHS AT THE CONNECTOR INSERT.

NOTE LEAVE THE SPARES FULL LENGTH.

4 STRIP THE INDIVIDUAL CONDUCTORS IN ACCORDANCE WITH FIGURE 5A5. (FOR CONTACT WIRE BARREL DEPTHS SEE TABLE 1)

CONTACT SIZE	WIRE BARREL DEPTH (IN)
16	250-313
12	375-438
8	500-563
6	625-688
0	625-688

5 TIN THE CONDUCTORS IN ACCORDANCE WITH FIGURE 5A13.

5.1 ENSURE CONDUCTOR STRANDS ARE TWISTED TIGHT PRIOR TO TINNING.

5.2 IF REMORK SHORTENS A CONDUCTOR'S INITIAL LENGTH BY GREATER THAN 1/8 INCH THE JACKET MUST BE CUT BACK AGAIN AND ALL LEADS RETRIMMED TO PRECLUDE STRESS.

SH 132317375

TABLE 2

SHELL SIZE	CONNECTOR BEAR THREAD AND CABLE CLAMP TORQUE IN IN./LBS. (± 5 IN./LBS)
8	45
8S	45
10	45
10S	45
10SL	45
12S	50
14	50
14S	50
16	60
16S	60
18	70
18S	70
20	70
22	70
24	70
24S	80
26	80
32	100
36	120
40	140
44	140
48	140

9.6 SLIDE THE GLAND WASHER (PC 3) AND GLAND (PC 4) INTO THE GLAND HOUSING. ENSURE THE CABLE JACKET EXTENDS THROUGH THE AREA UNDER THE GLAND.

9.7 SCREW THE CABLE CLAMP (PC 5) INTO THE GLAND HOUSING AND TORQUE TO A VALUE SPECIFIED IN TABLE 2.

9.8 ALTERNATELY TIGHTEN THE CLAMPING BAR AND THE TIGHTENING TORQUE SCREW AS SPECIFIED IN TABLE 3. THE TORQUE DRIVER (TORQUE CONTROL OR EQUIVALENT) (FIGURE 6) ENSURE A MINIMUM GAP OF 1/16 INCH EXISTS BETWEEN THE CLAMP SUPPORT AND CLAMP SADDLES.

NOTE UNDER CLAMPING BAR SCREW

TABLE 3
CLAMP SCREWS

CABLE DIAMETER	TORQUE VALUE
0.0 TO 0.5 IN	25 ± 2 IN./OZ
0.5 TO 1.0 IN	40 ± 2 IN./OZ
1.0 TO 2.0 IN	50 ± 2 IN./OZ




FIGURE 6

10 FINAL TEST AND DOCUMENTATION

10.1 USING ESTABLISHED SHIPYARD PROCEDURES PERFORM ELECTRICAL/ELECTRONIC CHECKS ON THE ASSEMBLED CONNECTOR.

10.2 INSTALL A PROTECTIVE DUST CAP ON THE CONNECTOR.

10.3 COMPLETE THE ASSEMBLY INSPECTION AND DOCUMENTATION AS REQUIRED BY LOCAL PROCEDURES.

11 IF NECESSARY LOCKWIRE THE CONNECTOR IN ACCORDANCE WITH FIGURE 5A24.

FIGURE 5G2. MIL-C-22992 connector assembly procedure (excluding class L).

APPLICABLE CONNECTORS	
MS27467	
MS27468	
MS27469	
MS27470	
MS27471	
MS27472	
MS27473	
MS27474	
MS27475	
MS27476	
MS27477	
MS27478	
MS27479	
MS27480	
MS27481	
MS27482	
MS27483	
MS27484	
MS27485	
MS27486	
MS27487	
MS27488	
MS27489	
MS27490	
MS27491	
MS27492	
MS27493	
MS27494	
MS27495	
MS27496	
MS27497	
MS27498	
MS27499	
MS27500	
MS27501	
MS27502	
MS27503	
MS27504	
MS27505	
MS27506	
MS27507	
MS27508	
MS27509	
MS27510	
MS27511	
MS27512	
MS27513	
MS27514	
MS27515	
MS27516	
MS27517	
MS27518	
MS27519	
MS27520	
MS27521	
MS27522	
MS27523	
MS27524	
MS27525	
MS27526	
MS27527	
MS27528	
MS27529	
MS27530	
MS27531	
MS27532	
MS27533	
MS27534	
MS27535	
MS27536	
MS27537	
MS27538	
MS27539	
MS27540	
MS27541	
MS27542	
MS27543	
MS27544	
MS27545	
MS27546	
MS27547	
MS27548	
MS27549	
MS27550	
MS27551	
MS27552	
MS27553	
MS27554	
MS27555	
MS27556	
MS27557	
MS27558	
MS27559	
MS27560	
MS27561	
MS27562	
MS27563	
MS27564	
MS27565	
MS27566	
MS27567	
MS27568	
MS27569	
MS27570	
MS27571	
MS27572	
MS27573	
MS27574	
MS27575	
MS27576	
MS27577	
MS27578	
MS27579	
MS27580	
MS27581	
MS27582	
MS27583	
MS27584	
MS27585	
MS27586	
MS27587	
MS27588	
MS27589	
MS27590	
MS27591	
MS27592	
MS27593	
MS27594	
MS27595	
MS27596	
MS27597	
MS27598	
MS27599	
MS27600	
MS27601	
MS27602	
MS27603	
MS27604	
MS27605	
MS27606	
MS27607	
MS27608	
MS27609	
MS27610	
MS27611	
MS27612	
MS27613	
MS27614	
MS27615	
MS27616	
MS27617	
MS27618	
MS27619	
MS27620	
MS27621	
MS27622	
MS27623	
MS27624	
MS27625	
MS27626	
MS27627	
MS27628	
MS27629	
MS27630	
MS27631	
MS27632	
MS27633	
MS27634	
MS27635	
MS27636	
MS27637	
MS27638	
MS27639	
MS27640	
MS27641	
MS27642	
MS27643	
MS27644	
MS27645	
MS27646	
MS27647	
MS27648	
MS27649	
MS27650	
MS27651	
MS27652	
MS27653	
MS27654	
MS27655	
MS27656	
MS27657	
MS27658	
MS27659	
MS27660	
MS27661	
MS27662	
MS27663	
MS27664	
MS27665	
MS27666	
MS27667	
MS27668	
MS27669	
MS27670	
MS27671	
MS27672	
MS27673	
MS27674	
MS27675	
MS27676	
MS27677	
MS27678	
MS27679	
MS27680	
MS27681	
MS27682	
MS27683	
MS27684	
MS27685	
MS27686	
MS27687	
MS27688	
MS27689	
MS27690	
MS27691	
MS27692	
MS27693	
MS27694	
MS27695	
MS27696	
MS27697	
MS27698	
MS27699	
MS27700	
MS27701	
MS27702	
MS27703	
MS27704	
MS27705	
MS27706	
MS27707	
MS27708	
MS27709	
MS27710	
MS27711	
MS27712	
MS27713	
MS27714	
MS27715	
MS27716	
MS27717	
MS27718	
MS27719	
MS27720	
MS27721	
MS27722	
MS27723	
MS27724	
MS27725	
MS27726	
MS27727	
MS27728	
MS27729	
MS27730	
MS27731	
MS27732	
MS27733	
MS27734	
MS27735	
MS27736	
MS27737	
MS27738	
MS27739	
MS27740	
MS27741	
MS27742	
MS27743	
MS27744	
MS27745	
MS27746	
MS27747	
MS27748	
MS27749	
MS27750	
MS27751	
MS27752	
MS27753	
MS27754	
MS27755	
MS27756	
MS27757	
MS27758	
MS27759	
MS27760	
MS27761	
MS27762	
MS27763	
MS27764	
MS27765	
MS27766	
MS27767	
MS27768	
MS27769	
MS27770	
MS27771	
MS27772	
MS27773	
MS27774	
MS27775	
MS27776	
MS27777	
MS27778	
MS27779	
MS27780	
MS27781	
MS27782	
MS27783	
MS27784	
MS27785	
MS27786	
MS27787	
MS27788	
MS27789	
MS27790	
MS27791	
MS27792	
MS27793	
MS27794	
MS27795	
MS27796	
MS27797	
MS27798	
MS27799	
MS27800	

- 1 VISUAL INSPECTION AND VERIFICATION
 - 1.1 DISASSEMBLE THE CONNECTOR BACKSHELL ASSEMBLY
 - 1.2 VERIFY THAT THE CONNECTOR IS OF THE CORRECT TYPE AND CONFIGURATION FOR THE CABLE BEING TERMINATED IN ACCORDANCE WITH THE SYSTEM CABLING DIAGRAM
 - 1.3 VERIFY THAT THE BACKSHELL CONFIGURATION IS OF THE TYPE AS SPECIFIED ON THE SYSTEM CABLING DIAGRAM
 - 1.4 VERIFY THAT ALL COMPONENTS PARTS OF THE CONNECTOR AND BACKSHELL HARDWARE ARE THE CORRECT TYPE AND CONFIGURATION FOR THE CABLE BEING TERMINATED IN ACCORDANCE WITH THE SYSTEM CABLING DIAGRAM. REFERENCE MIL-SPECS MIL-C-38989 FOR CONNECTOR, MIL-C-89049 FOR BACKSHELL, OR VENDOR DATA FOR SPECIFIC CONFIGURATIONS
 - 1.5 VISUALLY INSPECT THE COMPONENTS FOR DAMAGE SUCH AS DEFORMED PARTS, GOUGES, DAMAGES THREADS, CUT O-RINGS, BURRS, OR SURFACE DAMAGE
 - 1.6 VERIFY THAT THE CRIMP CONTACTS MEET THE REQUIREMENTS OF MIL-C-39029/58 FOR SERIES 1, 2, 3 AND 4 PIN, MIL-C-39029/56 FOR SERIES 1, 3, AND 4 SOCKET, AND MIL-C-39029/57 FOR SERIES 2 SOCKET CONTACTS AND ARE THE CORRECT TYPE AND TYPE FOR THE CONNECTOR BEING ASSEMBLED
 - 1.7 VERIFY THAT THE SOLDER CONTACTS MEET THE REQUIREMENTS OF MIL-C-38999 AND MATE PROPERLY WITH THEIR COUNTERPART CONTACTS
 - 1.8 IF THE CONDUCTORS ARE RETWISTED DURING LEAD PREPARATION, ENSURE THEY ARE TWISTED AS TIGHT AS ORIGINALLY CONSTRUCTED, THE NATURAL LAY OF THE CONDUCTOR IS MAINTAINED, AND THE CONDUCTORS WILL FIT INSIDE THE CONTACT BAR-REL Z
- 2 PREPARE THE CABLE IN ACCORDANCE WITH FIGURE 5A.1.
- 3 INSERTION SETUP OWING TO THE MANY POSSIBLE VARIATIONS FOR ACCEPTABLE CONFIGURATIONS, THE FOLLOWING PARTICULAR TYPE OF SPECIFICATIONS MADE AS TO A PARTICULAR TYPE OF ASSEMBLY WHICH ARE DESIRABLE FOR AN ACCEPTABLE ASSEMBLY FOLLOWS
 - A. DUMMY RECEPTACLE WITHOUT CONNECTOR INSERT TO HOLD THE CONNECTOR BEING WORKED ON SECURELY ON A CLAMPING DEVICE THAT WILL NOT DAMAGE THE CONNECTOR
 - B. A CABLE CLAMPING FIXTURE TO HOLD THE CABLE IN A SECURE FIXED RELATIONSHIP TO THE CONNECTOR WHILE PERMITTING ACCESS TO THE REAR FACE OF THE CONNECTOR FOR THE CONTACT INSERTION TOOL OR SOLDERING IRON
 - C. A DEVICE FOR HOLDING THE WIRE BUNDLE OUT OF THE WORK AREA

THE ASSEMBLY FIXTURE REFERRED TO IN THIS PROCEDURE IS THAT DEVELOPED BY CHARLESTON NAVAL SHIPYARD (FIGURE 2).

NOTE EQUIVALENT TOOLING FROM ALTERNATE SOURCES IS ACCEPTABLE. HOWEVER THE USE OF OTHER TOOLS MAY AFFECT THE PROCEDURAL STEPS OUTLINED BELOW.

3.1 SECURE THE ASSEMBLY FIXTURE TO A VISE OR SIMILAR HOLDING DEVICE IN ORDER TO PROVIDE A STABLE WORK AREA.




FIGURE 2
ASSEMBLY FIXTURE

- 3.2 USE OF THIS ASSEMBLY FIXTURE NEGATES THE NEED FOR THE DUMMY RECEPTACLE AND THE CONNECTOR IS FIRMLY SEATED IN THE CONNECTOR CLAMP.
- 3.3 SEAT THE CONNECTOR IN THE CONNECTOR CLAMP AND ADJUST THE WING NUTS TO SECURE IT IN PLACE.
- 3.4 PLACE THE PREPARED CABLE IN THE FIXTURE CLAMP SO THAT THE FIRST CONTACTS TO BE INSERTED WILL BE AT THE BACK OF THE CONNECTOR AS IT IS HELD IN THE CONNECTOR CLAMP.





FIGURE 3
CONNECTOR SEATED IN ASSEMBLY FIXTURE

NOTES:
1. THIS FIGURE SUPERSEDES SHEET 5H1 OF DWG 803-5001027.



MIL-C-38999 CONNECTOR WITH
COMPATIBLE BACKSHELL CONFIGURATION
FIGURE 1

SH 132317376

FIGURE 5H1. MIL-C-38999 connector assembly procedure.

3.8 CUT THE CONDUCTORS AS REQUIRED TO PROVIDE EVEN CONDUCTOR LENGTHS AT THE CONNECTOR INSERT.

NOTE: LEAVE THE SPARLS FULL LENGTH.

4 STRIP THE INDIVIDUAL CONDUCTORS IN ACCORDANCE WITH FIGURE 5A5 (FOR CONTACT WIRE BARREL DEPTHS SEE TABLE 1).

TABLE 1

CONTACT BARREL SIZE	WIRE BARREL DEPTH (IN)	
	FRONT RELEASE	REAR RELEASE
12-12	208-239	141-172
16-16	209-239	125-156
20-20	209-239	141-157
22-22	141-157	094-125
22-22M	141-157	094-125
22-22D	141-157	094-125

NOTE: FOR SOLDER CONTACTS PROCEED TO STEP 6

5 CRIMP CONTACT TERMINATION TO CONNECTOR

5.1 PRIOR TO CRIMPING, A CONTACT SIZING TEST SHOULD BE ACCOMPLISHED FOR ALL SOCKET CONTACTS (PIN CONTACTS PREVIOUSLY VERIFIED IN STEP 1 & DO NOT NEED FURTHER TESTING).

5.1.1 SOCKET CONTACTS SHOULD BE INSPECTED FOR PROPER SIZE USING MS3197 WHEN GAGE CONFORMING TO MS3197 WHEN TESTED THE MINIMUM SEPARATION FORCE MEASURED WITH A TENSION COMPRESSOR GAGE (CATALOG DPT 16 OR EQUIVALENT) SHOULD BE AS SPECIFIED IN TABLE 1.

3.5 POSITION THE CABLE AT THE ANGLE SIMILAR TO THE BACKSHELL DESIGN (I.E. 45°, 90°, OR STRAIGHT) SECURE THE CABLE IN THE FIXTURE CLAMP (FIGURE 4A).

3.6 POSITION THE CONNECTOR SO THAT THE CONTACTOR TO CABLE JACKET DISTANCE IS THAT MEASURED IN STEP 9.2 OF FIGURE 5A1. ROTATE THE CONNECTOR TO ALIGN THE KEYWAY POSITION IN PROPER RELATIONSHIP TO THE BACKSHELL (FIGURE 4B).

3.7 ROUTE THE INDIVIDUAL CONDUCTORS PER THE APPLICABLE WIRING TABLE. ENSURE THAT THE LONGEST INDIVIDUAL CONDUCTOR HAS SUFFICIENT LENGTH TO BE INSERTED INTO THE CONTACT PRIOR TO CUTTING ANY CONDUCTOR (FIGURE 4C).




FIGURE 4A




FIGURE 4B




FIGURE 4C

FIGURE 4
DETERMINING CONDUCTOR LENGTH
SH 132317377

TABLE 2

CONTACT SIZE	SERIES 1, 2, 3, 4 PIN CONTACT		SERIES 1, 2, 3, 4 SOCKET CONTACT		MINIMUM SEPARATION FORCE (OZ)
	BASIC CRIMPING TOOL	POSITIONER	BASIC CRIMPING TOOL	POSITIONER	
12-12	M22520/1-01 YELLOW	M22520/1-04 YELLOW	M22520/1-01 YELLOW	M22520/1-04 YELLOW	7.5
16-16	M22520/1-01 BLUE	M22520/1-04 BLUE	M22520/1-01 BLUE	M22520/1-04 BLUE	1.5
20-20	M22520/1-01 RED	M22520/1-04 RED	M22520/1-01 RED	M22520/1-04 RED	0.6
22-22	M22520/2-01	M22520/2-10	M22520/2-01	M22520/2-10	0.6
22-22M	M22520/2-01	M22520/2-09	M22520/2-01	M22520/2-07	0.6
22-22D	M22520/2-01	M22520/2-07	M22520/2-01	M22520/2-05	0.6
			M22520/7-01	M22520/7-06*	0.6

*SERIES 2 SOCKET CONTACTS ONLY

5.3 INSERTING CONTACTS (FIGURE 6)

5.3.1 USING THE PROPER WIRING TABLE, PROPER CRIMPING TOOL, AND CRIMPING TOOL BASED ON CONTACT TYPE (SEE TABLE 1), INSERT THE CONTACTS INTO THE REAR OF THE FRONT OF THE ASSEMBLY FIXTURE. INSERT THE CONTACTS INTO THEIR DESIGNATED LOCATIONS IN THE CONNECTOR AS FOLLOWS:

TABLE 3

CONTACT SIZE	INSTALLING TOOL	REMOVAL TOOL
12-12	M81969/8-09 M81969/14-04	M81969/8-10 M81969/14-04
16-16	M81969/8-07 M81969/14-03	M81969/8-08 M81969/14-03
20-20	M81969/8-05 M81969/14-02	M81969/8-06 M81969/14-02
22-22	M81969/8-03	M81969/8-04
22-22M	M81969/8-01 M81969/14-01	M81969/8-02 M81969/14-01
22-22D	M81969/8-01 M81969/14-01	M81969/8-02 M81969/14-01

NOTES:

1. THIS FIGURE SUPERSEDES SHEET 5H2 OF DWG 803-5001027.




FIGURE 5
SOCKET CONTACT SIZING TEST

5.2 TERMINATE INDIVIDUAL CONDUCTORS WITH CRIMP CONTACTS IN ACCORDANCE WITH SHEET SA11. (SEE TABLE 2 FOR PROPER CRIMPING TOOL). IF CONTACT REWORK SHORTENS A CONDUCTOR'S INITIAL LENGTH CUT BACK TO A MINIMUM 1/4 INCH. THE JACKET MUST BE CUT BACK AND ALL CONDUCTORS RE-TRIMMED TO PRECLUDE STRESS.





FIGURE 6
CONTACT INSERTION

FIGURE 5H2. MIL-C-38999 connector assembly procedure.

NOTES:
1. THIS FIGURE SUPERSEDES SHEET 5H3 OF DWG 803-500127.



A INSERTING THE TOOL INTO THE CONNECTOR



B REMOVING THE TOOL AND CONTACT

5.3.1.1 POSITION THE CONTACT IN THE TOOL. THE TOOL TIP SHOULD BE AGAINST THE CONTACT. SOLDER JUST FORWARD OF THE WIRE BARREL.

5.3.1.2 INSERT THE CONTACT AND TOOL TIP INTO THE CONTACT CAVITY WITH A FIRM STEADY PRESSURE.

5.3.1.3 SLIDE THE INSERTION TOOL BACK ALONG THE WIRE UNTIL IT CLEARS THE CONNECTOR INSERT.

5.3.1.3.1 LIGHTLY PULL ON THE INSERTED LEAD TO ENSURE THE CONTACT IS LOCKED IN THE CONNECTOR.

5.3.1.4 ADJUST THE FIXTURE CLAMP AS REQUIRED DURING THE INSERTION PROCESS TO EASE STRESS ON THE CONDUCTORS.

5.3.1.5 ENSURE THAT THE SHIELD GROUND TACT IS TERMINATED TO A CONTACT LOCATION.

5.3.1.6 UPON INSERTION OF EACH TWO CONTACTS, VISUALLY INSPECT THE CONNECTOR FACE TO ENSURE THAT THE CONTACTS ARE PROPERLY INSERTED AND DO NOT "GROSS OVER" INTO ADJACENT CONTACTS. WHEN COMPARED TO THE PROPERLY INSERTED CONTACTS.

5.3.1.7 INSERT SEALING PLUGS MEETING MILITARY STANDARD MS27488 INTO ALL UNWIRED CONTACT HOLES.

5.4 REMOVE THE CONNECTOR AND CABLE FROM THE ASSEMBLY FIXTURE.

5.5 CONDUCT A VISUAL CHECK OF THE CONNECTOR AND VERIFY WIRE LOCATION AGAINST THE WIRING TABLE. ENSURE NO DEBRIS IS INSIDE SOCKET CONTACTS.

5.6 CONTACT REMOVAL PROCEDURE (AS REQUIRED)

5.6.1 CONDUCT A VISUAL INSPECTION OF THE CONNECTOR FACE TO IDENTIFY ANY UNSEATED CONTACTS.

5.6.2 IF REQUIRED TO REMOVE CONTACTS PROCEED AS FOLLOWS (FIGURE 7)

5.6.2.1 SELECT THE CORRECT REMOVAL TOOL FROM TABLE 3.

5.6.2.2 STRADDLE THE WIRE OF THE CONTACT TO BE REMOVED WITH THE REMOVAL TOOL.

5.6.2.3 SLIDE THE TOOL INTO THE INSERT UNTIL BOTTOMED AROUND THE CONTACT.

CAUTION: DO NOT TWIST THE EXTRACTION TOOL.

5.6.2.4 REMOVE THE CONTACT AND TOOL SLOWLY FROM THE CONNECTOR.

5.6.2.5 EXAMINE THE CONNECTOR AND CONTACT FOR DAMAGE.

5.6.2.6 REINSERT ALL EXTRACTED CONTACTS AND REPEAT THE SEALING CHECKS.

SH 132317378




FIGURE 8
PUSH TEST ADAPTER
TENSION/COMPRESSION GAUGE

6.1.2 IF REMOVED SHORTENS A CONDUCTOR'S INITIAL LENGTH BY GREATER THAN 1/4 INCH THE JACKET MUST BE CUT BACK AGAIN AND ALL LEADS RETRIMMED TO PRECLUDE STRESS.

6.2 SOLDER THE CONDUCTORS TO THE CONTACTS IN ACCORDANCE WITH FIGURE 5A15. SOLDERING SHOULD START WITH THE CONTACT ROW(S) FURTHEST AWAY FROM THE OPERATOR. A PIECE OF STIFF PAPER SHOULD BE PLACED OVER THE CONTACTS AS THEY ARE COMPLETED TO AID IN PROTECTING THE WORK ALREADY ACCOMPLISHED (SEE FIGURE 9 FOR EXAMPLE).




FIGURE 9
PROTECTING SOLDERING CONTACTS

WARNING: DO NOT MOVE THE CONDUCTOR AFTER THE SOLDERING IRON HAS BEEN REMOVED OR A COLD SOLDER JOINT COULD RESULT.

6.3 REMOVE THE CABLE AND CONNECTOR FROM THE ASSEMBLY FIXTURE.

6.4 CONDUCT A VISUAL CHECK OF THE CONNECTOR AND VERIFY WIRE LOCATION AGAINST THE WIRING TABLE. ENSURE NO DEBRIS IS INSIDE SOCKET CONTACTS.

FIGURE 7
CONTACT REMOVAL (REAR RELEASE)

5.6.3 IF A CONTACT FAILS TO RESET AFTER THREE ATTEMPTS, REPLACE THE OFFENDING CONTACT IF THE SAME CONTACT LOCATION CONTINUES TO GIVE DIFFICULTY. THE CONNECTOR IS PROBABLY DAMAGED OR FAULTY AND MUST BE REPLACED.

5.7 CONTACT PUSH TEST

5.7.1 USING THE COMBINATION TENSION/COMPRESSION GAGE (CHATILLON DRUM SOCR EQUIV. (671)) PUSH TEST EACH CONTACT (FIGURE 8). EVALUATE CONTACT RETENTION (FIGURE 8).

5.7.1.1 SEE TABLE 4 FOR PUSH TEST VALUES.

TABLE 4

CONTACT SIZE	PUSH TEST VALUE (LBS.)
12-12	25
16-16	15
20-20	10
22-22	10
22-22M	10
22-22D	10

5.7.1.2 ENSURE THE CORRECT PUSH TEST ADAPTER/PROBE IS UTILIZED FOR THE CONTACT SIZE BEING TESTED.

5.7.1.3 THE FORCE SHALL BE APPLIED TO THE MATING END OF THE CONTACT IN A FIRM, SLOW MANNER. DO NOT INSTANTANEOUSLY APPLY THE FORCES LISTED IN TABLE 4.

5.8 PROCEED TO STEP 7.

6. SOLDER TERMINATION TO CONNECTOR

6.1 TIN THE CONDUCTORS IN ACCORDANCE WITH SHEET 5A13.

6.1.1 ENSURE CONDUCTOR STRANDS ARE TWISTED TIGHT PRIOR TO TINNING.

FIGURE 5H3. MIL-C-38999 connector assembly procedure.

DOD-STD-2003-5 (NAVY)
24 JUNE 1987

NOTES:
1. THIS FIGURE SUPERSEDES SHEET 5H4 OF DWG 803-5001027.

TABLE 6
CLAMP SCREWS

CABLE DIAMETER	TORQUE VALUE
0.0 TO 0.5 IN	25 ± 2 IN / OZ
0.0 TO 1.0 IN	40 ± 2 IN / OZ
1.0 TO 2.0 IN	50 ± 2 IN / OZ




FIGURE 11

8 FINAL TEST AND DOCUMENTATION

- 8 1 USING ESTABLISHED SHIPYARD PROCEDURES PER LOCAL ELECTRONIC CHECKS ON THE ASSEMBLED CONNECTOR
- 8 2 INSTALL A PROTECTIVE DUST CAP ON THE CONNECTOR
- 8 3 COMPLETE THE ASSEMBLY INSPECTION AND DOCUMENTATION AS REQUIRED BY LOCAL PROCEDURES
- 8 4 IF NECESSARY LOCKWIRE THE CONNECTOR IN ACCORDANCE WITH SHEET 5A24




FIGURE 10
MARKING THE CABLE

- 7 6 3 GENTLY FORCE THE CABLE TOWARD THE CONNECTOR PLUG UNTIL THE SHIELD CONTACTS THE TAPERED SURFACE ON THE RFI RING
- 7 6 4 SLIDE THE GROUND RING (PC 4) ONTO THE RFI RING WHILE APPLYING FORWARD PRESSURE ON THE CABLE
- 7 6 5 COMPRESS THE SHIELD BETWEEN THE RFI RING AND GROUND RING WITH A BAK AND FORTH MOVING FORWARD MOTION ON THE GROUND RING
- 7 7 IF THE GROSS SHIELD IS FLOATED OR TERMINATED AT THE CONNECTOR CONTACT SLIDE THE BACKSHELL OVER THE CONNECTOR CONTACTS. LOOPED GROUND WIRE AND SPARE CONDUCTORS.
- 7 8 SLIDE THE TRANSITION SHELL (PC 5) OVER THE RFI ASSEMBLY AND SCREW IT ONTO THE ELBOW
- 7 9 TORQUE THE TRANSITION SHELL TO THE VALUE PROVIDED IN TABLE 5 FOR THE APPROPRIATE SHELL SIZE
- 7 10 MARK A LINE ON THE CABLE 1/4 INCH TO 1/2 INCH FROM THE ELBOW. THE LINE SHOULD BE CLEARLY VISIBLE TO CAREFULLY PUSH THE CABLE INTO THE BACKSHELL 1/4-1/2 INCH AND MAINTAIN CONTINUOUS PRESSURE TO HOLD AT THIS POSITION FOR THE NEXT FOUR STEPS. A LINE MARKED ON JACKET IS EVEN WITH TRANSITION SHELL REAR EDGE
- 7 11 VERIFY THE CABLE JACKET IS POSITIONED COMPLETELY THROUGH THE GLAND
- 7 12 SLIDE THE WASHER (PC 8), GLAND (PC 7), AND GLAND COMPRESSION RING (PC 8) INTO POSITION BEHIND THE TRANSITION SHELL
- 7 13 SCREW THE CABLE CLAMP (PC 9) ONTO THE TRANSITION SHELL AND TORQUE TO THE VALUE SPECIFIED IN TABLE 5
- 7 14 UNTIL REACHING THE TORQUE VALUE SPECIFIED IN TABLE 5 USING A TORQUE SCREWDRIVER (TORQUE COEFFICIENT 1.5) TO THE ELBOW. MAINTAIN A MINIMUM GAP OF 1.16 INCH EXISTS BETWEEN THE CLAMP SUPPORT AND CLAMP SADDLES

NOTE: IF REQUIRED, INSTALL PERSONNEL SAFETY GROUND UNDER CLAMPING BAR SCREW

- 7 BACKSHELL ASSEMBLY
- NOTE THIS CONNECTOR SPECIFICATION DOES NOT PROVIDE FOR UNIQUE CONNECTOR ACCESSORY HARDWARE TO BE UTILIZED WITH THE CONNECTORS. THE FOLLOWING ASSEMBLY PROCEDURES ARE BASED ON THE MANUFACTURER'S DESIGN. VARIATIONS IN HARDWARE DESIGN, BASED ON MANUFACTURER MAY OCCUR AND CAUSE MINOR DEVIATIONS FROM THIS PROCEDURE. ASSEMBLY PROCEDURES SUPPLIED BY THE MANUFACTURER SHOULD BE UTILIZED WHEN CONFLICTS EXIST
- 7 1 FOLD SPARE WIRES BACK ONE HALF THE DISTANCE BETWEEN THE CONNECTOR AND THE JACKET END
- 7 2 SLIDE A 1 INCH LONG PIECE OF APPROPRIATELY SIZED SHRINK TUBING OVER EACH FOLDED PAIR AND SHRINK IN PLACE
- 7 3 LIGHTLY COAT THE TURREADS OF EACH BACKSHELL PART WITH PENTROLATUM (VV-P-236) JUST PRIOR TO ASSEMBLY
- 7 4 POSITION AND LUBRICATE (PENTROLATUM, VV-P-236) ALL O-RINGS
- 7 5 SLIDE THE 45° ELBOW (PC 2) DOWN THE CABLE AND SCREW IT ONTO THE CONNECTOR. TIGHTEN THE 45° ELBOW USING A STRAP WRENCH AND TORQUE WRENCH TO THE TORQUE VALUE PROVIDED IN TABLE 5 FOR THE APPROPRIATE SHELL SIZE

TABLE 5

SHELL SIZE	CONNECTOR REAR THREAD TORQUE IN IN. LBS (1.5 IN. LBS)
8	45
8S	45
10	45
10S	45
10SL	45
12	50
12S	50
14	50
14S	50
16	60
16S	60
18	60
20	70
20S	70
24	70
28	80
32	100
36	120
40	140
44	140
48	140

- 7 6 IF THE GROSS SHIELD IS TO BE FLOATED OR TERMINATED AT THE CONNECTOR CONTACT SLIDE THE BACKSHELL RFI HARDWARE AS FOLLOWS
- 7 6 1 SLIDE THE RFI RING (PC 3) AGAINST THE ELBOW
- 7 6 2 FLARE THE GROSS SHIELD OVER THE TAPERED END OF THE RFI RING

FIGURE 5H4. MIL-C-38999 connector assembly procedure.

SH 132317379

INSTRUCTIONS: In a continuing effort to make our standardization documents better, the DoD provides this form for use in submitting comments and suggestions for improvements. All users of military standardization documents are invited to provide suggestions. This form may be detached, folded along the lines indicated, taped along the loose edge (*DO NOT STAPLE*), and mailed. In block 5, be as specific as possible about particular problem areas such as wording which required interpretation, was too rigid, restrictive, loose, ambiguous, or was incompatible, and give proposed wording changes which would alleviate the problems. Enter in block 6 any remarks not related to a specific paragraph of the document. If block 7 is filled out, an acknowledgement will be mailed to you within 30 days to let you know that your comments were received and are being considered.

NOTE: This form may not be used to request copies of documents, nor to request waivers, deviations, or clarification of specification requirements on current contracts. Comments submitted on this form do not constitute or imply authorization to waive any portion of the referenced document(s) or to amend contractual requirements.

(Fold along this line)

(Fold along this line)

DEPARTMENT OF THE NAVY
COMMANDER
NAVAL SEA SYSTEMS COMMAND (SEA 5523)
DEPARTMENT OF THE NAVY
WASHINGTON, DC 20362-5101




NO POSTAGE
NECESSARY
IF MAILED
IN THE
UNITED STATES

OFFICIAL BUSINESS
PENALTY FOR PRIVATE USE \$300

BUSINESS REPLY MAIL
FIRST CLASS PERMIT NO. 12503 WASHINGTON D. C.

POSTAGE WILL BE PAID BY THE DEPARTMENT OF THE NAVY

COMMANDER
NAVAL SEA SYSTEMS COMMAND (SEA 5523)
DEPARTMENT OF THE NAVY
WASHINGTON, DC 20362-5101



STANDARDIZATION DOCUMENT IMPROVEMENT PROPOSAL*(See Instructions - Reverse Side)*

1. DOCUMENT NUMBER DOD-STD-2003-5 (NAVY)	2. DOCUMENT TITLE ELECTRIC PLANT INSTALLATION STANDARD METHODS FOR SURFACE SHIPS AND SUBMARINES (CONNECTORS) SECTION 5 OF 5
---	---

3a. NAME OF SUBMITTING ORGANIZATION

4. TYPE OF ORGANIZATION (*Mark one*) VENDOR USER MANUFACTURER OTHER (*Specify*): _____b. ADDRESS (*Street, City, State, ZIP Code*)

5. PROBLEM AREAS

a. Paragraph Number and Wording:

b. Recommended Wording:

c. Reason/Rationale for Recommendation:

6. REMARKS

7a. NAME OF SUBMITTER (*Last, First, MI*) - Optionalb. WORK TELEPHONE NUMBER (*Include Area Code*) - Optionalc. MAILING ADDRESS (*Street, City, State, ZIP Code*) - Optional

8. DATE OF SUBMISSION (YYMMDD)